



## EUT EXTERNAL PHOTOS

FRONT VIEW OF EUT




REAR VIEW OF EUT






FRONT VIEW OF EUT




REAR VIEW OF EUT



Note: The green bottom board is used to debug the module for testing



## Accessory-Host



## Accessory-Control Panel

