


RM-T1



ACCESORIOS

- 1.Cable Cargador Usb – 1 Pieza
- 2.Manual De Usuario – 1 Pieza

INSTRUCCIONES DEL PANEL DE CONTROL



- 1.USB Port
- 2.TF Card
- 3.DC interface
- 4.AUX input
- 5.ON OFF button
- 6.Signal input button
- 7.Previous/VOL-(Hold for 3 seconds to decrease volume)
- 8.PLAY/PUASE (In FM mode,hold for 3 seconds the device will enter into automatic scan)
- 9.Next/VOL+(Hold for 3 seconds to increase volume)
- 10.LED CHARGE STATUS:
RED = Charging
GREEN = Fully charged

POWER SOURCE

1. Please charge the unit at least 4 hours before first time using.
2. Long press the MODO button on the panel to switch on or off the speaker.

CHARGE THE BATTERY

When the battery is charging, the CHARGE STATUS lights red. After the battery has fully charged, the light turns to be green.

1. Connect the AC adaptor to the DC IN JACK of the speaker firmly, and plug it into a wall outlet.
2. When the battery is fully charged, first disconnect the AC adaptor from the speaker, then from the wall outlet.
3. The speaker works normally when charging.

SIGNAL INPUT BUTTON

Press MODO button on the front panel to select the mode(AUX,USB,TF, BT OR FM).

PREVIOUS/NEXT BUTTON

By pressing PREVIOUS/NEXT button on the front panel, you can select a specific song from the play list.

PAUSE/PLAY BUTTON

To stop playing the current track, please press PAUSE/PLAY button on the front panel.

Press it once again to continue playing.

AUX IN JACK

1. Connect an audio cable to the AUX IN JACK of the speaker and to the audio output socket on the external audio devices such as MP3 player, discman, etc, then select AUX by pressing the MODO button on the control panel.

2. Play from an external audio device.

USB JACK

Insert USB card directly for palying

POWER SOURCE

FM Operation

In FM mode, press the signal input button on the front panel control to enter FM, and press PREVIOUS or NEXT button on the front panel or the remote control to choose station; long press PLAY/PAUSE button on the front panel control to search stations automatically.

Bluetooth:

Press MODO button on panel or the bluetooth button control to select Bluetooth mode. Simultaneously open the Bluetooth setting on your phone, tablet or any other bluetooth enabled audio device and select "RM-T1"(no need to match code), the unit and device will then connected via Bluetooth. Press the "next song" and "previous song" button on the remote control to select the song, press "play/pause" button to control the playing status.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment