
73.4x75.5mm书写纸风琴折

正面





恢复出厂设置 当出现左右耳不互联或者设备无法配对时,可按照以下操作进行重置: ①先在手机端删除" \$12 " 耳机的配对信息。 ②耳机在开机未连接状态下,连续敲击左/右耳机功能键5下关机。 ③重置耳机后,耳机所记录的配对信息已经被清除。请按"篮牙配对" 步骤重新连接后使用。 其他功能 我加状 态下,长按功能键3秒,耳机开机。 开机状态下,长按功能键5秒,耳机会断开连接并关机。 超时未连接 耳机待配对状态下,5分钟内未成功与设备连接,则自动关机。 蓝牙断开连接 连接成功后,若关闭手机蓝牙或者超出蓝牙有效连接距离(无障碍环境 10m),则蓝牙断开连接,若5分钟内未成与设备进行连接,则自动关机。	按键操作 L L R	 音乐播放 播放/暂停音乐:双击功能键 上一曲:三击左耳功能键 下一曲:三击右耳功能键 音 量-:单击左耳功能键 音 量+:单击右耳功能键 通话管理 接听/挂断电话:双击功能键 抢接来电:长按功能键2秒 适音控制 长按左/右耳功能键2秒 《需手机支持此功能) 	耳机电池电量和充电 耳机电量显示 手机状态栏可显示耳机设备电量信息(需手机版本支持此功能) 耳机充电状态 耳机充电过程中,指示灯会有充电提示,充满后指示灯熄灭。 耳机低电量提醒 当耳机处于低电量状态时,耳机会有语音提示音提示电量不足,请及时 将耳机放入充电盒充电。 充电仓电量和充电 建议使用标准的充电器和随附的充电线对充电仓进行充电。 充电仓电量提醒 当充电仓电量过低时,请及时为充电仓充电。	 指示灯状态 耳机指示灯 ①开机:蓝灯长亮。 ②关机:蓝灯闪3下。 ③未配对:蓝灯长亮。 ④等待配对:主耳蓝灯闪烁,副耳灯灭。 ⑤配对成功:指示灯熄灭。 ⑥音乐状态:指示灯熄灭。 ⑥音乐状态:指示灯熄灭。 ⑦通话状态:指示灯熄灭。 ⑧充电状态:蓝灯快闪。 ⑨充电穴成:蓝灯熄灭。 ⑩充电完成:蓝灯熄灭。 ①充电中: 红灯闪烁。 ②充电完成: 红灯长亮。 ③电量低:蓝灯快闪。 ④对耳机充电:蓝灯熄灭。 ⑤耳机充满电:蓝灯熄灭。 	常见问题 ①耳机不能与手机配容 检查耳机是否处于配容 ②耳机无法开机? 请检查耳机的电量是召 ③耳机能否更换电池? 不可以,本耳机使用者 ④开车时能否使用本耳 可以在驾驶时使用本耳 并尽量减小音量。 ③耳机和手机断开连报 本耳机的有效距离是雪 多重障碍物,耳机和寻 机。 ④耳机连接计算机或引 由于蓝牙是一种无线热 请检查在连接范围内员 ⑦耳机与手机连接后, 设备应用程序的软件的 耳机控制。
--	---------------------	---	--	---	---

eset hen the left and right ears are not connected or the device nnot be paired, you can reset it according to the following erations: ① Delete the pairing information of the "S12" headset the mobile phone first. When the headset is turned on and not connected, tap the t/right headset function key 5 times to turn it off. ③After setting the headset, the pairing information recorded by the	Key operation	play music Play/pause music: double click the function key Previous song: triple click the left ear function key Next song: triple click the right ear function key Volume -: Click the left ear function key Volume +: Click the	Headphone battery level and charging headset power display The mobile phone status bar can display the battery information of the headset device (the mobile phone version needs to support this function) Headphone charging status During the charging process of the headset, the indicator light will give a charging prompt, and the indicator light will go off when it is fully charged.	Indicator status headphone indicator ①Turn on: the blue light keeps on. ②Shut down: the blue light flashes 3 times. ③Unpaired: the blue light flashes 3 times. ③Waiting for pairing: the blue fire light on the main ear flashes, and the secondary ear fires. ③Successful pairing: the indicator light goes out. ④Music status: the indicator light goes out. ③Call status: the indicator light is off. ⑧ Low battery: The blue light flashes quickly. ③Charging status: the blue light is always on. ③Charging is completed: the blue light goes out.	Common problem The headset cannot Check whether the he Bluetooth search func @The headset cannot Please check whether it for 30 minutes befor @Can the headset be battery.
ther functions inual on/off the off state, press and hold the function button for 3 seconds turn on the headset. the power-on state, press and hold the function button for 5 conds, the headset will be disconnected and turned off. Timeout t connected nen the headset is waiting to be paired, if it fails to connect with e device within 5 minutes, it will automatically shut down. Jetooth sconnect ter the connection is successful, if the Bluetooth of the mobile	R	Call management Answer/hang up a call: Double-click the function button to reject the call: long press the function button for 2 seconds voice control Long press the left/right ear function key for 2 seconds (needs the phone to support this function)	Headphone low battery reminder When the headset is in a low battery state, the headset will have a voice prompt to indicate that the battery is insufficient. Please put the headset in the charging box to charge in time. Charging in the charging compartment and charging in the charging compartment It is recommended to use a standard charger and the attached charging cable to charge the charging compartment. Low battery reminder in charging compartment When the charge in the charging compartment is too low, please charge the charging compartment in time.	Charging: the red light flashes. ①Charging: the red light flashes. ②Charging is complete: the red light is on. ③ Low battery: The blue light flashes quickly. ④Charge the headset: the blue light is on. ③The headset is fully charged: the blue light goes out.	 (a) Can I use this heads driving, but it is not re driving, and reduce th (b) The headset is discore The effective distance distance between the or there are multiple co be disconnected. Plea (c) After the headset is you hear different sou Because Bluetooth is a objects between the h whether there is meta connection range.

机配对?

于配对或回连状态,以及检查手机蓝牙搜索功能。

量是否充足,并充电30分钟后再开机。

电池?

使用不可拆式电池。

用本耳机?

用本耳机,但是不建议在驾驶中使用头戴式蓝牙耳机,

开连接?

离是室内10米,如果手机和耳机的距离超过10米或者有 机和手机会断开连接,请保持在有效距离以内使用本耳

机或手机后,听到不同的声音?

无线技术,因此对耳机与已连接设备间的物体很敏感, 围内是否有金属或其他影响连接的对像。

接后,可以使用耳机控制手机上的应用程序吗?

软件设定或有所不同,令个别应用程序的功能不支持由

安全问题 ①由于耳机里有电池,请尽量使本产品远离高温地带。 ②请尽量使用合格的充电器和充电线,尽量避免使用高电流和电压的快 充设备给本产品充电。 ③本产品请选择合适的场景使用本产品。

产品清单

耳机

充电线





产品保修卡 该卡为产品保修凭证,请妥善保管 产品名称 产品名称 购买日期

格证

C.Passed

联系方式

产品维修记录

日期	不良现象	解决方案

oblem

annot be paired with the mobile phone? the headset is paired or connected back, and check the h function of the mobile phone.

annot be turned on? ether the power of the headset is sufficient, and charge before turning it on.

et be replaced? No, this headset uses a non-detachable

headset while driving? You can use this headset while not recommended to use a Bluetooth headset while uce the volume as much as possible.

disconnected from the mobile phone? tance of this headset is 10 meters indoors. If the n the mobile phone and the headset exceeds 10 meters tiple obstacles, the headset and the mobile phone will I. Please keep the headset within the effective distance.

set is connected to the computer or mobile phone, do nt sounds?

oth is a wireless technology, it is very sensitive to n the headset and the connected device. Please check s metal or other objects that affect the connection in the

Security Question

③ Because there is a battery in the headset, please try to keep this product away from high temperature areas.
 ③ Please try to use qualified chargers and charging cables, and try to avoid using high current and voltage fast charging equipment to charge this product.

③Please choose a suitable scene to use this product.

Data line



earphone Charging compartment



	臣 a.c.Pi	ين assed		
	产品份	R修 卡	-	
	该卡为产品保修凭	毛证,诣	青妥善信	呆管
产品名称		产品	型号	
购买日期		客户	名称	
联系方式				
	产品维	修记录		
日期	不良现象			解决方案
	1			

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and

(2)This device must accept any interference received, including interference that may cause undesired operation.