

1

Button Introduction

LB

Indicator Light

RB

BACK

START

Left Stick/LS (press down)

A B X Y

Di-Pad

Right Stick/RS (press down)

Left Grip Indicator

Power Switch

Right Grip Indicator

RT

Profile Key

LT

H1

H2

H3

H4

Type-C Cable

1

Connect to Switch

1. Bluetooth Connection

(1) Turn on the Switch, open up the [Controller and Sensors - Charge Grip / Order] (This step can be ignored for non-first-time pairing.)

(2) Make sure the controller power switch is OFF, press and hold the FN + LB and turn the power switch to ON until the indicator light flashes in blue and then release.

(3) Connection is successful when controller vibrates, and the blue indicator light is always on.

2. Wired Connection

Connect to the Switch

(1) Turn the controller power switch to ON.

(2) Plug the USB cable of the controller into the Switch dock connector.

(3) Connection is successful when controller vibrates, and the indicator light is always on.

2

Wireless Receiver

3. Wireless Receiver

Connect to the Switch

(1) Turn the controller power switch to ON.

(2) Take out the OTG cable and connect one end to the Switch and the other end to the controller.

Connect to the Switch Dock

(1) Turn the controller power switch to ON.

(2) Plug the receiver of the controller into the Switch dock connector.

(3) Connection is successful when controller vibrates, and the red indicator light is always on.

4. Unable to Reconnect After Switch's System Updated Connection

(1) Turn on the Switch, open up [Indicator Settings Controller and Sensor Connection]

Connect to the Switch Dock

(1) Turn the controller power switch to ON.

(2) Plug the USB cable of the controller into the Switch dock connector.

(3) Connection is successful when controller vibrates, and the indicator light is always on.

3

Connect To PC

1. Bluetooth Connection (PC with Bluetooth reception is required)

(1) Make sure the controller power switch is OFF, press and hold the FN + RB and turn the power switch to ON until the indicator light flashes in blue and then release.

(2) Open the "Bluetooth and other devices" interface of PC, click "Add wireless controller" to connect.

(3) Connection is successful when controller vibrates and the yellow indicator light is always on.

2. Wired Connection

Connect to the PC

(1) Turn the controller power switch to ON.

(2) Plug the USB cable of the controller into the PC USB port.

(3) Connection is successful when controller vibrates, and the indicator light is always on.

4

Connect To Mobile

1. Connect to Android Mobile Connection

(1) Open the Bluetooth of device.

(2) Make sure the controller power switch is OFF, press and hold the FN + B and turn the power switch to ON until the indicator light flashes in green and then release.

(3) Open the BEITONG Gaming Hall, then open Bluetooth settings interface of the device, click "Add Bluetooth device" to connect.

(4) Connection is successful when controller vibrates, and the green indicator light is always on.

2. Connect to iPhone

(1) Open the Bluetooth of device.

(2) Make sure the controller power switch is OFF, press and hold the FN + B and turn the power switch to ON until the indicator light flashes in yellow and then release.

(3) Open the BEITONG Gaming Hall, then open Bluetooth settings interface of the device, click "Add Bluetooth device" to connect.

(4) Connection is successful when controller vibrates, and the green indicator light is always on.

5

Wireless/Bluetooth Mode Switching

BEITONG ZEUS Pro has 4 wireless modes can be switched: 2.4G Wireless Receiver, Virtual Bluetooth, Switch Bluetooth and BT+HID.

Press and hold the FN for 3s to switch modes or press key combination to enter the corresponding mode.

Enter a mode by pressing key combination is the forced connection state for that mode.

Wireless Bluetooth Mode	Indicator Color	Key Combination	Re-connecting	Re-connecting	Connected
2.4G Wireless Receiver	Red	FN + [OFF] + [ON]	Red indicator flash slowly	Red indicator flash slowly	Red indicator is always on
Virtual Bluetooth	Yellow	FN + [OFF] + [ON]	Yellow indicator flash slowly	Yellow indicator flash slowly	Yellow indicator is always on
Switch Bluetooth	Blue	FN + [B] + [OFF] + [ON]	Blue indicator flash slowly	Blue indicator flash slowly	Blue indicator is always on
BT+HID Bluetooth	Green	FN + [B] + [OFF] + [ON]	Green indicator flash slowly	Green indicator flash slowly	Green indicator is always on

6

Dual Hall, Innovation Upgrade

Official YouTube

Official Website

More products and game information, Please follow BEITONG Official social media accounts.

WWW.BETOP-CN.COM/EN

7

Replaceable Parts

Replaceable Joysticks

(Note: Joysticks of different heights need to be purchased additionally.)

Replaceable Face Shield

Attaching face shield firmly from the center of the top seam of the shell, and the shell can be removed by slightly bulging and detaching the shell.

Adjustable A & X Y Key Cap

After removing the face shield, take out the A & X Y key caps for position adjustment.

8

Other Function

Light Adjustment

(7) Level of lights effect, can be switched freely.

Vibration Adjustment

Dual Rumble Motors, 8-Shape Intensity adjustable.

Joystick Sensitivity

Can be switched freely depending on game type.

Trigger Setting

Trigger intensity and vibration mode adjustable.

Specific PROFILE Key

4 Sets of PC/PS configuration can be saved, switch freely.

9

Switch's Key Indicator Diagram

Switch's Key Indicator Diagram

Function Key	Press START + [X]	[HOME]	Double press START + Back to Resting	Long press START + Resting
Function Key	Press START + [X] <th>[HOME]</th> <th>Double press BACK + Resting</th> <th>Long press START + Resting</th>	[HOME]	Double press BACK + Resting	Long press START + Resting

10

Charge Instructions

Battery State

Battery is less than 20%

Charging

Full Charge

Indicator State

Customize light flashes quickly

Breathing

After the light is always on for 10s, it will switch to the custom light mode and turn off.

11

Product Specification

Product Name

BEITONG ZEUS Pro Elite Gamepad

Product Model

BT010204

Package Size

200\*200\*65mm

Product Size

255\*145\*55.5mm

Product Weight

225g

Adaptation Platform

PC and laptop (Windows 7 and above), Nintendo Switch, Android, Huawei GamePad, Android TV/Projector

12

Customer Service

Dear customer,

Thanks for using BEITONG gaming peripheral products.

We focus on providing game with a better gaming experience, please provide the information through your email for customer service.

(1) Purchasing Channel: Buyer ID - Order Number - Product Model

Please provide the below information for us according to the product situation.

Please provide service reason:

(1) Function is not good: 3-day experience - Can not use in my device, it can not play the game, I want to replace it with a different reason.

(2) Please provide the service you need: a Replacement, a Refund, a Return, etc.

Customer service contact: beitong-service@betop.com.cn

We also welcome our customer to provide suggestion so that to improve and upgrade our products. Any good idea for our products, please feel free to contact us. It's very grateful. Meanwhile we'll select the customer who in high-quality advice to experience our new products for free opportunity.

Sincerely,

BEITONG Customer Service Team

白卡纸 7 折页 单张尺寸： 8\*9cm 参考线为对折位置