

封面

封底





AX18


AX1800 Dual Band Wi-Fi 6 Smart Router



Victure Home







Connection Type Description

Dynamic IP

PPPoE

PPTP

the IP address).

Input the IP address, Subnet Mask, Default Gateway, DNS from your ISP.

No information required. Please confirm with your ISP if Dynamic IP is supported.

Input Server Address, User Name and Password from your ISP.

Input Server Address, User Name and Password from your ISP.

Input User Name and Password from your ISP.

FAQs

Please check if your Phone has connected to the Wi-Fi of the router, whether it

can connect to the Internet or not. And please make sure you have entered the

correct default url http://victurelink.net or IP address (you might have changed

If you have registered the router to your Victure Home APP account, you may


And also you may reset the router to factory default settings. Keep the route

1. Unable to log in the router's web page on Phone?

loain in this APP to find back the router's login password.

2. If I forget the router's login password?


the password would be resumed to admin.



ं के Made in China Version 1.0

背面

正面



(3) Activate the WLAN function on your Phone and connect to Victure-5G-XXXX or Victure-5G-XXXX. Note: The "XXXX" is the low four bits of the MAC address of this router. ® 44.ill 44.ill 45. ● (1) ♂ \$ 10193% 💌 10:07 Off >

*** * 1 ا**

(4) Time Zone Setting. According to your location, please select a appropriate option from the list.

Choose a suitable connection type from the list and fill in the information

(6) IPTV Setting, you can open the IPTV function in this page and select a suitable mode.

(7) Wireless Setting. Create passwords for 2.4G Wi-Fi and 5G Wi-Fi (Here users could also revise the default Wi-Fi name).

(8) For security, please create a new login password for your router.

(9) The coming page is the summary information for your setting. Please remember your Wi-Fi name and password. Then your router will restart automatically. This time your phone will be disconnected from the router. Please back to the WLAN list of your phone to choose the new Wi-Fi name and input the correct password. Now, you could 3. How to do if I forget the password of the Wi-Fi?

If you have registered the router to your Victure Home APP account, you may login in this APP to find back the password of Wi-Fi. And also you may find it back by using PC WEB Broswer. Connect any LAN port of the router to the computer with RJ45 cable and then open any web browser to

ireless—Wireless Settings. (Please ensure your computer has been set to "obtain an IP address automatically" in advance).

login the web management page to check the Wi-Fi password in the Basic—

4. How to open the function of Smart Integrated SSID to use the 2.4G and 5G Wi-Fi by a same SSID?

Login in Victure Home APP and turn on Smart Integrated SSID on Wi-Fi settings Page, or og in the router's web page on Phone or PC to turn on Smart Integrated SSID on Wiereless settings Page, then wait for the setting to complete. If Wi-Fi is disconnected, please reconnect.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installa-

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interferpowered on, then press and hold the RST/WPS button for 5-8 seconds until equipment off and on, the user is encouraged to try to correct the interference by system indicator becomes blinking quickly, then the router will reset to default, one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference (2) This device must accept any interference received, including interference that may cause undesired operation.

RF Radiation Exposure Statement This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.

当前页/全部页码 1/1

猿人创新
Apeman Innovations

本设计图纸版权归本公司所有, 未经本公司书 面同意不得复印. 本图纸应与说明,产品状况,产品结构设计图及有

关图纸协调使用,发现任何差异请立即通知设计师.

图档中所有尺寸比例为1:1. 公差: L(长)*(宽): +1/-1mm,H(高): ±1mm

项目信息 立项时间: 计划时间: 品牌: Victure AX18 说明书 版本号: V1.0 版本变 更描述:

切刀 ———
压线 ————
开槽 ———
半穿 ————
粘合 圖圖圖圖圖
夕汁

无印刷

尺寸: 89x119mm (6折页)	设计审核				
印刷颜色: 4色印刷	1. 设计师:		2. 销售确认:		
材质: 120g 进口双胶	3. 设计经理审核:		4. 项目经理确认:		
特种工艺:			>X 🗆 🗠 💮		
· 	5. 品牌总监审核:		日 期:	2020/10/20	