



\*

United States on Till

There are two steps to setup your account STEP 1. Register an account STEP 2. ADD your device to your account

STEP 1

1. Goto website kycslocate.com.

2. Click on Register. 3. Enter a valid email address.

Slide the blue box all the way to high
 Click next.
 Check email for code (spam folder).

7. Enter verification code click ok.
8. Enter an account name, contact name password, confirm password click next.
9. You will be directed to the login screen.

## STEP 2 (add device)

1. Use your email registerd above as login name
2. Enter password you created above.
3. Goto top menu and hover over Info Manage and click drop down option "Vehicle".
4. Goto top menu under home find and and click blue circle with star icon.
5. Enter your 15 digit Device ID#, click activate.

Device ID is located on the device and an your 6. Device ID is located on the device and on your

**⚠** DOWNLOAD THE KYCS LOCATE APP

Your KYCS Locate device will be activated within 48 hours after purchase and receipt of your registration.
Registration is provided by an authorized KYCS Locate dealer or representative.

Download the free KYCS Locate app from Apple App store and/or Google Play.

Login using your credentials.

 You are now ready to monitor your KYCS Locate device. Start by tapping on "User & Device" located on the bottom menu, then tap on the asset name to monitor its location. Note: the KYCS Locate device is pre-set to one (1) location ping



FOR MORE INFO AND TIPS VISIT: WWW.KYCS.CA/LOCATEGUIDE

EMAIL: CONTACTUS@KYCS.CA CUSTOMER: SERVICE 1-866-800-4111 WWW.KYCS.CA



Google Play

LOCATE

CRIME 141 STOPPERS

CRIME STOPPERS U-S-A





## ONLINE PLATFORM FEATURES:

- Historical and track reports.
- Search feature for quick access to
- Replay route feature.
- standby days remaining
- Battery level indicator and number of
- Status health check and temperature
- Speed and direction.
- Monitor all feature-view all your inventory with one click.
- GeoFence Alerts

# (i) PRODUCT INFORMATION

The KYCS Locate device is a self powered, simple to install location device for assisting in the recovery of stolen high value assets.

Locating Battery Tamper

KYCS LOCATE FEATURES:

Virtually undetectable by scanners

· Tracking where cellular coverage is available

One (1) pre-set location ping per day

Up to 7 year battery life

Weatherproof housing

Tamper alarm available
 Online battery monitor

PACKAGE INCLUDES:

One (1) KYCS Locate device

One (1) Lithium battery installed

No monthly fees









FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful Interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the

FCC STATEMENT

Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the decler or an experienced radio/TV technician for help.
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept rany interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

## Industry Canada

This device complies with Industry Canada licence-exempt RSS standard(s). 
Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device. To maintain compliance with RSS-102 RF Exposure guidelines, This equipment should be instelled and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.

Le présentappareilestconf orme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitationestautorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareiladio accepter tout brouillageradioellectriquesubi, mêmesi le brouillageset susceptible d'encompromettre le fonctionnement. Pour être conforme aux lignes directrices d'exposition RF RSS-102, cet équipement doit être installe et exploité à une distance minimale de 20cm entre le radiateur et votre corps: n'utilisez que l'antenne fournie.











## **GET** STARTED

INSTALLATION GUIDE









Please ensure that you have set-up your account and registered the KYCS Locate device before installation.

This process is required to ensure the KYCS Locate device is on

Please refer to the opposite side of this guide for further instructions to set-up your account.



FOR FURTHER INFORMATION: EMAIL: CONTACTUS@KYCS.CA CUSTOMER: SERVICE 1-866-800-4111



The KYCS Locate device is equipped with high powered magnets for a quick and easy installation on most metal surfaces. You may also use the provided 3M adhesive for installation on non-metal surfaces.

- The KYCS Locate device has a weatherproof casing and can be installed on most assets including vehicles, trailers, RV's, heavy equipment, generators, boats, powersports, motorcycles and more ...
- 2. Install the KYCS Locate device in a hidden place within the asset.
- Do not Install the KYCS Locate device Inside a metal enclosure as it might prevent the KYCS Locate signal from transmitting.
- 4. Once installed, you may use the KYCS Locate app or online portal to view its last pinged location. The KYCS Locate device will provide one [1] pre-set location ping per day.











### ORIENTATION FOR INTERIOR INSTALLS

TOP SIDE **BOTTOM SIDE** 



If access is available, the KYCS Locate device can be installed inside the upholstery of most assets. Other places to covertly install your Locate device may exist within your asset.

To not install the KYCS Locate device inside a metal enclosure as it might prevent the KYCS Locate signal from transmitting.



## ORIENTATION FOR UNDERCARRIAGE INSTALLS

TOP SIDE **BOTTOM SIDE** 



When installing the KYCS Locate device on the under carriage of an asset, please ensure the TOP side of the KYCS Locate device is facing the ground with no obstructions.

To not install the KYCS Locate device inside the frame of the asset as it might prevent the signal from transmitting.



The KYCS Locate device is also packaged with 3M 9448A double coated tape. When using the 3M adhesive on the BOTTOM side of the KYCS Locate device, please ensure the punch hole is matched up with the Tamper Sensor. If the Tamper Sensor is covered, the removal alert will not activate.

To obtain optimal adhesion, the bonding surface must be clean, dry and well unified.

The ideal 3M tape application temperature range is 70 °F to 100 °F (21 °C to 38 °C) Do not apply the 3M adhesive to surfaces at temperatures below 50 °F (10 °C).

