



# **EF02 MANUAL**



### Specifications

	I
Model	EF02
Frequency Response	20Hz-20KHz
Bluetooth Chipset	Qualcomm QCC3020
Bluetooth Version	BT 5.0
Bluetooth Profile	HFP / HSP / A2DP / AVRCP
Audio Codec	aptX / AAC / SBC
Charging Time	1H 30M (Charging Case) 1H (Earbuds)
Playtime	6 Hours(Max 30 Hours)
Charging Case Battery Capacity	3.7V / 450mAh
Earbuds Battery Capacity	3.7V / 40mAh
Bluetooth Range	15m
Waterproof Rating	IPX5
Color	Black, White
ECC ID	2AWXK=FF02

### **Quick Guide**

ON	Press and hold L/R MFB for 2 seconds	
OFF	Press and hold L/R MFB for 5 seconds	
Pairing	Auto Pairing	
Volume -	Press L MFB 3 times.	
Volume +	Press R MFB 3 times.	
Previous Track	Press L MFB twice.	
Next Track	Press R MFB twice.	
Siri/Goog <b>l</b> e Assistant	Press and hold L/R MFB for 2 seconds	
Play / Pause	Press L/R MFB once.	
Answer / End A Ca <b>ll</b>	Press L/R MFB once.	
Reject A Call	Press and hold L/R MFB for 2 seconds	

On / Off, Play / Pause / Answer / End / Reject Call

# Power On / Off

- 1. Powering On
- Method 1: Take out earbuds from the charging case. - Method 2 :Press and hold MFB for 2 seconds.
- Method 1 : Put the earbuds into the charging case and close the cover.
- Method 2 : Press and hold MFB for 5 seconds.

2. Both earbuds' LED blinks in red for awhile then only one earbud blinks in red and white

1. Delete "EF02" from the connected device's Bluetooth list.

3. The earbuds are paired when the LED blinks in purple

- 1. Delete "EFO2" from the connected device's Bluetooth list. 2. When the both earbuds are in the charging case.

### Pairing (Connecting for the first time)

- 1. Open the charging case. (When connecting for the first time, please remove the plastic film on the earbuds and put them back into the charging case. Fully charge the earbuds before using them
- 3. Search for a Bluetooth device from a smartphone or a tablet and select "EF02" to connect.

- 2. Press and hold both earbuds at same time for 9 seconds.
- press the earbuds 6 times and hold on the 6th touch.

# Google Assistant / Apple Siri

### Music Controls

- Press left MFB twice.

### Controls

- Answering Calls / Ending Calls
- · Answer: Press MFB once when phone rings. · End: Press MFB once while on call.

Call

Press and hold MFB for 2 seconds when phone rings.

- Next Track
   Press right MFB twice.
- Volume Press L MFB 3 times.
- Press R MFB 3 times.

### Charging & Battery Indicator

- Put the earbuds into the charging case and close the cover to start charging. · When charging, the earbuds' LED blinks in red then turns off when they are fully charged.
- It takes around 60 minutes to fully charge the earbuds Time varies depending on the battery status.

- Connect the USB Type-C cable to the back of the charging case or place the case on a wireless charging pad to charge.
- $\boldsymbol{\cdot}$  The charging state is indicated by LED (3 Levels) on the charging case.
- · It takes around 90 minutes to fully charge the charging case. Time varies depending on the charging adapter, wireless charging pad and cable.

## to try to correct the interference by one or more of the following measures:

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which

guarantee that interference will not occur in a particular installation.

Federal Communications Commission (FCC) Statement

a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are

residential installation. This equipment generates uses and can radiate radio

requency energy and, if not installed and used in accordance with the instructions

may cause harmful interference to radio communications. However, there is no

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encourage

- Consult the dealer or an experienced radio/TV technician for help.
- ompliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) this device may not cause harmful interference, and including interference that may cause undesired operation

stomer care technician. If you have any inquiry, please visit our website or email us.

### Website: https://abkoglobal.com/contact-us/ E-mail : cs\_support@abko.co.kr

For the period of 1 year from the date of the original purchase ( \* 6 months for motors )

### What ABKO will not cover

within 48 hours of delivery.

- Failure of the product if it is abused, misused, modified, or used for other than the intended purpose or used commercially.
   Damage to the product caused by accident, fire, floods, any natural disasters or acts of God.
- Damage to finish, such as surface rust, tarnish, or small blemishes not reported.
- · Service to repair or replace lights bulbs, except for LED lamp.

# EXCLUSION OF IMPLIED WARRANTIES

consumer affairs office or your Attorney General

Your sole and exclusive remedy is product repair as provided in this Limited Warranty.

Any implied warranties, including the implied warranties of merchantability or fitness for a particular purpose, are limited to one year or the shortest period allowed by law.

an area where service by a ABKO is not available, you may be responsible for a

thip charge or you may be required to bring the product to an authorized ABKO service location for service. Some regions/countries do not allow the exclusion or limitation of incidental or consequential damages. This limited warranty gives you specific legal rights, and you may also have other rights which vary from country

to country. To know what your legal rights are, consult your local/region or country

**UBKO**