


tianhoo

**M50-68 & M50-61
Smart Base**


user's manual

Setup BT Speaker Charger cradle


Search the Bluetooth device when connect as the first time..




1. Open settings.



2. Connected devices.




3. Bluetooth On



4. + Pair new device

5. Connect the power source of Speaker Charger Cradle.




6. Press and hold in the Speaker Charger Cradle recess black rubber button, do not release. Then the blue light blinks. It's under the search status.



7. The device named 'M50 Smart Base' appears on the phone. Press OK to connect. The light turns green after connecting successful and the voice prompt

Release the black rubber button.



8. Put the phone in after setting. The Speaker Charger Cradle, then it will connect automatically. The phone disconnects automatically when you take it out.



M50-61




M50-68

Keypad overview & functions

1. Bluetooth switch
2. Power connecting point
3. Volume Increase or decrease
4. Indicator light
5. Short press: answer, hang up /

Hold down 3 seconds :
disconnect.



BT Speaker Charger cradle is equipped with high-quality high-power speakers and high-sensitivity noise reduction microphones. Provide you with perfect sound quality and high volume. You can play music in your phone and make hands-free calls through this device.

**** When making a hands-free call, the sound reception effect will attenuate as the distance increases. The recommended distance is within 2 meters.***

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.
- 2AXAX-M5068