
# **BALANCE** 3-in-1 Wireless Charger User Manual

### What's in the box:

BALANCE 3-in-1 Wireless Charger \*1 30W QC Power Adapter \*1 USB-C to USB-A cable \*1 User Manual \*1



# Compatibility

#### Phones

iPhone 14/Pro/ProMax/Plus / 13/Pro/ ProMax/mini 12/Pro/ProMax /mini / 11/Pro/ProMax / SE(2) XS /XS Max/XR / X / 8/ 8Plus

Galaxy S22/S22 Ultra/S21/S20/S10/S10 Plus/ S10E/S9/S9 Plus/Note 9/S8/S8 Plus/ Note 8/S7 Edge/S7/S6 Edge plus/Note 5

Google Pixel 6/6XL/5/5XL/4/4 XL/3/3 XL LG V60 / V50 / V40 / V35 /V30+ /V30/G8

#### Wireless Earbuds

Wirless Earbuds AirPods Pro (1/2) AirPods (3) —AirPods With Wirless Charger—

-Galaxy Buds, Buds2, Buds Live, Buds Pro

Soundcore Liberty

Soundcore Liberty Air2 /Air2 Pro/2 Pro

#### AppleWatch

Apple Watch Series (1-8) Apple Watch SE Apple Watch Ultra

·	iPhone 12/13/14 Without Case	iPhone (12/13/14) + Mag <u>net</u> ic Ca <u>se</u>	iPhone (12/13/14) + _Non-Magnetic Case	iPhone (8/X/11/ SE2/3) & Other Phones With <u>Wirel</u> ess <u>Cha</u> rger	AirPods 3 AirPods Pro 2	AirPods Pro 1 AirPods 2 <u>Othe</u> r TW <u>S E</u> arph <u>one</u>
Magnetic Charging Pad			×	×		8
Non-Magnetic Charging Pad	<b>I</b>		<ul> <li>Image: A start of the start of</li></ul>			0

Compatible perfectly. Sincompatible

## Attention

\* Please do not place any debris between your smartphone and the wireless charger, such as credit cards, keys, coins, rings, NFC cards, etc. \* Use only original power adapters and cables.

\* Cases with a thickness exceeding 5mm, metal cases, and cases with uneven surfaces cannot be used.

\* Do not place the wireless charger in direct sunlight or near hot objects.

\* Do not get wet.

\* Do not use in temperatures below 0°C or above 40°C.







0



Ventilated

No direct sunlight

Keep cool Keep away from heat

Don't get wet

