

C5S

English

v02



User Manual

brief introduction

Thank you for purchasing the C5S wireless earbuds !

The C5S has newest technology and exceptional audio quality to reach for all touch control function. The C5S focus on improving and enhancing user experience by providing a comfortable and ergonomic in-ear design. For wearing freely that the earbuds adopt soft in-ear design to fit user perfectly. With the portable charging, you can enjoy charging anytime and anywhere. For the best user experience, please read this manual carefully before use of the C5S earbuds.

Safety Rules

1. For safety, please comply with the rules mentioned in this manual
2. Keep device away from sharp edges, uneven surfaces, metal objects, and knock out.
3. Do not open, dismantle or attempt to repair the earbuds. Doing so may cause accidental fire, electronic board failure, or damage to the earbuds. All warranty will be cancel.
4. Do not wipe or clean the earbuds with oils or any volatile liquids.
5. Do not use the earbuds in places where potential personal safety is atrisk or in danger.

Packing details

— C5S Bluetooth headset	1 pair
— Charging Cable	1
— Medium silicone ear cap	1 pair
— Small silicone ear cap	1 pair
— Instruction manual	1 serving
— Charging storage box	1
— Hanging rope	1
— Packing box	1 set

Product Information



① charging storage box

② cavity

③ battery display



④ charging display

⑤ microphone



⑥ silicone ear cap


⑦ silicone plug

⑧ headphone work indicator

Operation Guide

1. Headphone wearing method

R/L is printed on the earphone case, please wear it in the correct direction, the sound quality will be better!



2. Connect to Phone:

A. Take out the earbuds from charging case and remove the PET insulator. Put the earbuds back in the charging case to activate. The earbuds will power on automatically once you take them out of the case

B. Put the L and R earbuds into your ears. The L and R earbud will connect to each other and pairing. Next, the prompts of voice "connected" will be heard


C. Open Bluetooth on your phone. When the two earbuds have paired successfully, the prompts of voice "Left channel, Right channel" will be heard. On the device list, connect to the "Touch Two C5S" and then the voice "second device connected" will be heard

D. How to use the single ear: The L/R Earbud can use alone. When you first use this earphone and you want to use the L/R earphone alone. You must double-click the L/R ear touch surface. Then you can find the "Touch Two C5S" in the Bluetooth device connection list. If you have connected your phone with the two earphones. When you use L/R earphone alone. Put one of the L/R earphone back into the charging box.

3.Touch Functions:

Previous: Double click on the right ear touch surface.

Volume reduction: Long press of right ear touch surface.



Next: Double click on the left ear touch surface

Volume increase: Long press of left ear touch surface.

To turn off the earbuds: In standby mode, press and hold the touch area for 5S to turn off the earbuds. (Note: The earbuds can be used individual To turn off a single earphone which does not affect to use another earphone)

(Note: left and right can be operated separately)

Activate voice assistant: Standby mode, Continuous click

Touch panel three times

Call function: click once on the touch panel to answer

Or hang up the phone.

Reject the call: double click on the touch panel

Play or pause music: Click once in the touch panel

ATTENTION:

PLEASE REMOVE THE PROTECTIVE COVER ON THE EARBUDS BEFORE OPERATION. PLEASE KEEP AWAY FROM RADIO INTERFERENCE AND AVOID NOISY ENVIRONMENTS WHEN USING EARBUDS PLEASE REPLAY THE HIGH QUALITY FORMAT OF MUSIC OR LOCAL MUSIC OF THE DEVICE

4. Charging Case

- A. Put the earbuds into the case exactly, the battery box will automatically charge the earphones until they are full.
- B. The charging box has a smart switch function. Place the earbuds in the charging box and cover the case which is charged. When the charging box is opened, the charging will be turned off automatically. The earphone will start to pair and connect back to the mobile phone when you pick up the earbuds from the open box. Then you can listen to music and enjoy the intelligence of this product.
- C. USB outlet supports 5V/1.5A output, which can provide emergency charging for mobile phones and other electronic products

ATTENTION:

REMOVE THE INSULATION COVER BEFORE INITIAL USE. RECHARGE THE CHARGING CASE IF NOT USED FOR OVER 90 DAYS. ONLY USE GOOD QUALITY WIRELESS CHARGING TRANSMITTER AND CHARGING CABLE. THE EARBUD LED LIGHT WILL TURN BLUE WHEN IT IS FULLY CHARGED

5. Single Earbud Mode:

The L/R Earbud can be used alone to connect to your Phone. On your phone, enter the Bluetooth device connection list and remove the "Touch Two C5S" from the list. Redo the steps for "Connect to Phone" but with only the L/R earbud.

Product Parameter

1. Earbud parameters:

Bluetooth Version: 5.0

Operation Voltage: 3.2V~4.2V

Impedance: 32Ω

Speakersensitivity: 105db

Speaker Bandwidth: 20~20 KHZ

Microphone Sensitivity: -42+-2db

Earbud frequency: 2.4~2.48GHZ

Compatible : A2DP/HFP/HSP/AVRCPEarbud

working range: 10M

Single eartalk time: 6hrs

Music play : 4~5hrs

Single earbud standby time: 80 hrs

2. Charging case Parameters:

Large capacity battery

DC Charging Voltage: DC5V

DC charge Current: 1A

DC output Current: Maximum 1.5A

Troubleshooting Guide

malfunction	the reason	Solution
Unable to start	Low battery	Charge the headset
Silent after matching	Match operation is incorrect	Rematch
Can talk, but red indicator illuminates	The battery is low, Bright red indicator	Clear the headset immediately
Charging without prompt	The headphones are not put well	Check if the headphones are in place
Headset Automatic shut-down	Low battery	Charge the headset
Headphones have echo	The volume is too high or the environment is too noisy	volume adjustment Or change places
The call has a noise	Caused by environmental interference or Sound source equipment is far away	Change place or will The distance of the source device is close
The other party's voice is small	The headset is not worn correctly	Adjust the position of the headset And adjust the volume
Bad signal, Intermittent	Too far or outside interference	Put the phone closer to the main earbud or keep it from the outer interference signal

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID:2AXEL-C5S

C5S

English