

## C56 User Manual

### EN

#### Product Usage

##### Boot:

Press and hold the multi-function button until the LED flashes blue

##### Shutdown:

Press and hold the multi-function button until the LED flashes red

##### pairing:

Turn on the power to automatically enter the pairing mode, turn on the Bluetooth mode of the phone and search for the pairing name BTto select the link

##### Standby status prompt:

In standby mode, flashing blue indicates sufficient power, and flashing red indicates insufficient battery

##### Charging status indication:

The red light is solid when charging, and the blue light is on when it is fully charged

##### Answer/hang up incoming calls:

Press Multi-Function once to answer the call, and then press again to hang up

##### Previous Song/Next Song:

Press and hold the volume (+) to build a song, and press and hold the volume (-) to build the next song

##### Pause/play the song:

Press the multi-function button once to pause /play

##### Volume up or down:

Press the volume (+) to increase the volume, press the volume (—) to press the volume to decrease the volume.

##### Call back:

Quickly double-click the function key 2 times

##### Reject an incoming call:

Double-tap the call button 2 times to reject the call

### FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirement. This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.