



Tenera 2 by LOVENSE

Charging




Once it is fully charged, the solid red light will turn off.


Turning On/Off & Changing setting



Self Cleaning




Usage



Visit lovense.com for a complete user manual.

Lovense Remote



Warning

- Ne pas exposer à une chaleur ou un froid extrême.
 - NE PAS utiliser le jouet pendant le chargement.
 - Veuillez vous assurer de ne pas attacher le câble de charge à des matériaux métalliques ou en acier inoxydable.
 - Ne pas immerger dans l'eau à plus de 1 mètre de profondeur lors du nettoyage ou pendant l'utilisation.
- FCC Compliance Statement:
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) this device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and stores radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- FCC Radiation Exposure Statement:
The device has been evaluated to meet general RF exposure requirement.
- The device can be used in portable exposure condition without restriction

Avertissement

- NE PAS faire bouillir dans l'eau (risque d'explosion de la batterie ou de l'eau pourrait pénétrer dans le jouet).
- Assurez-vous que votre jouet soit rechargeé au moins tous les six mois.

Atenção

- NÃO fervor em água (a bateria pode explodir ou a água pode entrar no brinquedo).
- Manter longe do frio e do calor extremo.
- Certificar que o brinquedo seja carregado pelo menos uma vez a cada seis meses.
- NÃO suar o brinquedo enquanto carrega.
- NÃO mergulhar em água com profundidade superior a 1 metro ao longo ou durante o uso.

Advertencia

- NO hervir en agua (la batería puede explotar o podría entrar agua en el juguete).
- Mantener la unidad alejada de temperaturas extremas.
- Cargar el juguete por lo menos una vez cada seis meses.
- NO USAR la unidad mientras se encuentra cargando.
- Asegúrese de no sujetar el cable de carga a ningún material metálico o de acero inoxidable.
- NO lo sumerja en agua a más de 1 metro de profundidad al limpiarlo o durante su uso.

IPX7 Waterproof

-- Consult the dealer or an experienced radio/TV technician for help.