QUICK START GUIDE
P5

Product Details

- Printer Paper Cabin
- NFC Recognition Area
- Indicators
- Magnetic Card Reader
- Camera(optional)
- Scan
- Power
- Charging Interface
- Screen
- IC Card Slot
- Camera
- Speaker
- Charging Base Connector
- Battery Cabin

1.**NFC Recognition Area:** to recognize NFC card
2.**Printer Paper Cabin:** to insert printing paper
3.**Indicators:** indicating terminal working status
4.**Screen:** display and touch operation
5.**Power:** long press to power on/off; short press to activate or shut down the screen
6.**IC Card Slot:** to swipe IC card
7.**Magnetic Card Reader:** to swipe magnetic Card
8.**Scan:** press this button to scan
9.**Charging Interface:** to insert micro USB 5 pin plug of charger
10.**Speaker:** to play sound
11.**Camera:** scanning and photography
12.**Charging Base Connector:** to connect with the charging base
13.**Battery Cabin:** to place and protect the battery

Main Specifications

Operation System	Android OS
CPU	Qualcomm Quad-Core
Communications	TDD/FDD/WCDMA/HSPA/ GSM/EDGE/WIFI/4.4+5G/
Memory	2GB RAM,16GB ROM
Screen	5.5"LCD

Camera	Front camera 2 Mega Fixed Focus(Optional) Rear camera 5 Mega Auto Focus
BT	BT4.0, Dual Mode
Wi-Fi	WLAN802.11a/b/g/n/ac
NFC	13.56MHz
Magnetic Card Reader	Track 1/2/3
IC Card Reader	ISO7816,Encrypted Head
PSAM Card Slot	2 Slots
SIM Card Slot	2 Slot, 3V/1.8V
Printer	2 inch thermal printer, paper cabin diameter 40mm
Battery	7.4V,2620mAh, Li-polymer

Safety Alert

- Do not place the terminal in extremely hot or cold conditions.
- Do not place terminal together with computer disc, credit card, travel card or any other magnetic items; otherwise, the information stored in magnetic cards will be affected.
- Do not place the terminal in fire.
- Do not disassemble the terminal or any accessories by yourself.
- Please use a moist and anti-static cloth to clean the terminal screen.
- Warning: Please replace the batteries with the same type and rating to avoid battery explosion.
- Do not expose the battery in strong direct sunlight, near heat sources or any similar conditions.
- Please recycle or dispose of old, weak, or worn batteries in accordance with local, regional or national law or regulation.
- Do not use detergent with chemical or scrub particle which may damage the terminal body or screen.
- Please keep the terminal in a safe place and avoid crush or squeeze that may cause a damage on screen or camera.
- When the user use the third party's root tool or update with unauthorized operation system, it will bring risk to the normal operation system.

Open Printer LID

Step 1:

Step 2: