

# OUTAD

LJ-160  
True Wireless Stereo Earbuds

User Manual



## Included in the package

- Earbuds × 1 Pair
- Charging Case × 1 Pcs
- Type C Cable × 1 Pcs
- User Manual × 1 Pcs

## Product Overview



## Wearing



1. Insert the earbuds into the inner canal of your ears.
2. Turn and find the most comfortable position.

## Charging

1. Connect the charging case to a branded charger or a computer to charge it. Put the earbuds in the charging case, the magnetic pins will automatically lock them in position and start the charging.
2. When connected to a power source or put back the earbuds in or take them out of the charging case, the battery status display will be activated and show the remaining power of the charging case in numbers, as well as the charging status to the earbuds.
3. If the earbuds battery is low, you will hear a “Battery low” prompt.
4. When you are not to use the earbuds for a long time, we suggest you to charge the case and earbuds every 3 months to provide good protection for the battery, and make sure to charge them before using.

## Power On / Off

1. **Power On:**  
The earbuds switch on automatically when taken out of the charging case. To manually switch on, hold the multifunctional touchpad for about 2 seconds until you hear a voice prompt “Power On” and blue light flashes 1 time.
2. **Power Off:**  
The earbuds switch off automatically when placed back in the charging case. To manually switch off, hold the multifunctional touchpad for about 3 seconds until you hear a voice prompt “Power Off” and red light flashes 3 time. Turn off one earphone, the others will also turn off.  
If you leave the earbuds idle without connecting to a device, the earbuds will automatically power off after 3 minutes.

## Pairing

1. **First time use**  
Take the earbuds out of the charging case, the earbuds will automatically switch on, pair with each other and enter pairing mode.  
Turn on Bluetooth on your mobile phone or other devices, search for “LJ-160”, and tap on it to connect.  
If you can't find “LJ-160”, place the earbuds back into the charging case, reboot your device, take out the earbuds and try pairing again.
2. **Second time use**  
Once taken out of the charging case, the earbuds will automatically connect to a previously connected device in range, and prompt “Bluetooth Connected”.
3. **Single Mode**  
Once connected to your device, each of the earbud can be used separately, take any of them out of the charging case, it will automatically connect to a previously connected device in range.

## Controls

The multifunctional touchpads perform differently with different earbuds, times of tapping, and frequency of tapping, during music play and phone calls.

### Music Playing Mode

Play / Pause	Quick tap once (1) on any earbud	R / L X1
Volume -	Quick tap twice (2) on the left earbud	L X2
Volume +	Quick tap twice (2) on the right earbud	R X2
Previous track	Quick tap thrice (3) on the left earbud	L X3
Next track	Quick tap thrice (3) on the right earbud	R X3

### Phone Call Mode

Answer Call	Quick tap once (1) on any earbud with an incoming call	R / L X1
Reject Call	Tap and hold for 1 second on any earbud with an incoming call	R / L X1"
Hang Up Call	Quick tap once (1) on any earbud during a call	R / L X1

### Single Earbud Mode

Next track	Quick tap thrice (3) on any earbud	R / L X3
Redial last call	Quick tap twice (2) on any earbud	R / L X2

## General

Activate voice assistant	Tap and hold for 2 seconds on any earbud , you will hear a “Ding” prompt	R / L X2"
Manually Power On	Tap and hold for 2 seconds on the earbud you want to power on	R / L X2"
Manually Power Off	Tap and hold for 3 seconds on the earbud you want to power off	R / L X3"

## Specifications

Specifications are subject to change without notice.

- Weight  
Charging case: 29 g / 1.02 oz  
Earbud (single): 3g / 0.11 oz
- Impedance: 32 Ω
- Driver (full range): 10 mm × 2
- Frequency response: 20 Hz - 20 KHz
- Music play time: About 3-4 hours (at 80% volume)
- Phone call time: About 3-4 hours (at 80% volume)
- Standby Time: About 35 days
- Charging input: USB - C, 5V / 1A
- Charging case battery capacity: 300 mA
- Earbud battery capacity: 30 mA
- Charging time  
Charging case : About 1.5 hour  
Earbuds: About 40 minute
- Bluetooth version: 5.0
- Connection range: About 33 feet / 17 meters without obstacles

## Warning

1. Please keep or use the earbuds in normal temperature.
2. Please keep the earbuds and charging case away from damp environments or submerged in liquid.
3. Please don't disassemble, repair or modify by an unauthorized person.
4. Fully charge the earbuds before the first time using, or after not using for a long time.
5. This product should be kept away from children.
6. When discharging this product and its package, please hand it over to a competent facility for recycling or appropriate treatment.

## FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.  
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/ TV technician for help.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.