



### **Instructions: JAZZMAN Bluetooth Speaker Alarm**

**To set the alarm:** Use the button at the back of the unit to set the desired alarm time. Switch the alarm on and off with the set top alarm on/off button, a green light is on and red is off.

**To view the time at night :** Press the green light switch at the front of top panel. For a 5 minute snooze when the alarm is ringing, press the snooze button.

### **To Power on and connect to the Bluetooth:**

To power on the **JAZZMAN**, press the Blue button for 3 seconds, so that it starts flashing. This will also put it into Bluetooth pairing mode. To disconnect the bluetooth, press the blue button and it will disconnect so another user can connect. To power off and off the blue light, press the blue button for 3 seconds. The unit will go into auto-off after one hour of no use.

**Charging Wirelessly:** Place your phone on the wireless charging panel on top, and see the blue light to confirm connection. **Charging with USB:** Use either of the 2 USB C charging ports on the left side.

## **FCC statement:**

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **Wireless charging Radiation Exposure Statement**

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.

### **Bluetooth FCC Radiation Exposure Statement:**

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.