America's Longest Running Catalog

Hammacher Schlemmer

Offering the best, the only and the Unexpected Since 1848

Ball Launching RC Robot Car



USER GUIDE & OPERATING MANUAL

INCLUDE IMPORTANT SAFETY INFORMATION

READ ALL INSTRUCTIONS BEFORE USING DEVICE

SAVE THESE INSTRUCTIONS



REMOTE CONTROL



PRESS THE BUTTON TILL THE POWER LED OF THE TARGETED MECHANICAL VEHICLE LIGHTS UP AND RELEASE THE BUTTON IMMEDIATELY TO CONTROL THIS VEHICLE. KEEP PRESSING THE BUTTON TO REPEAT ABOVE-MENTIONED OPERATIONS TO SWITCH TO OTHER MODELS CYCLICALLY.

②PUBLIC CHANNEL DOUBLE-CLICK: DOUBLE CLICK THE BUTTON, THE POWER LED OF THE MECHANICAL VEHICLE AFTER CORRESPONDING FREQUENCY LIGHTS UP, THE PLAYER IS ABLE TO KEEP TAKING CONTROL.

③DOUBLE CLICK THE BUTTON OF CHANNEL 1 TO SWITCH FROM OTHER MECHANICAL VEHICLES TO K1/K4 MECHANICAL VEHICLE UNDER THE CONDITION OF CORRESPONDING FREQUENCY.

4 DOUBLE CLICK THE BUTTON OF CHANNEL 2 TO SWITCH FROM OTHER MECHANICAL VEHICLES TO K2 MECHANICAL VEHICLE UNDER THE CONDITION OF CORRESPONDING FREQUENCY.

Operation steps: first turn on the mechanical power, then turn on the remote power switch, the mechanical indicator and the remote indicator light change from blinking to steady light, and thefre quency is completed.

60 minutes and the cruise The vehicle battery voltage is 3.7V.









attention

Store the small parts properly.

- If there is interference of wave, please move the robot to another area.
- 3. When the car gets slower or the light turns dimmer, it's time to change
- 4. Do not expose the product in a place where nears fire, high temperature
- Make sure to turn off the power switch after use and remove the batteries.
- Use 1.5V AAA batteries and install them properly.
- Please get the chargeable batteries charged under adult's suspension.
- Do not mix different types of batteries or the old and new battery.
- Install the battery properly.
- Remove the battery from the toy when it's exhausted.
- Please check the cable, plug and box of battery box regularly. For proper woeking order.



with a white connector on the battery. The light does not light during charging, and the light is on when the battery is fully charged.



use 3 AAA batteries (not included)







INSPIRATIONAL ROBOT

The robot will not only improve children's concentration and stimulate their curiosity, but also explore their potentiality.





MOVE FORWARD / BACK






MOVE FORWARD / BACK





PRESS THE ARM
TO RELEASE


PRESS THE ARM
TO CLOSE





PRESS UP, HEAD CAR RISES

PRESS DOWN, HEAD CAR DROPS





SHOOTING



The Hammacher Schlemmer Lifetime Guarantee

We make an unconditional and unwavering promise: our merchandise is guaranteed for life. In any product purchased directly from us ever disappoints you, for any reason, you can return it for exchange, credit or refund. Even if you receive the item as a gift. Hammacher Schlemmer will exchange it for another item or gift certificate of equal value

Phone: call us Toll-Free 1-800-321-1484 to speak with a Hammacher Schlemmer associate for assistance 7 day a week 8 AM to Midnight, Eastern time. International customers please call 1-513-860-3397

E-mail customer service at customerservice@hammacher.com and we will respond within 1-2 business days.

Address:
Hammacher Schlemmer
9180 LeSaint Dr.
Fairfield, OH 45014

4

WARNING

- 1.Do not operate the model in the vicinity of another model using the same frequency.
- 2.Otherwise, radio signals may interfere with each other and the model cars may become out of control, causing accidents
- 3.Use alkaline battery and rechargeable battery correctly.
- 4. Always turn off power of the model car and the remote controller in sequence after use.
- 5.If this model is to be stored for a long time, all batteries in the model car and the remote controller should be removed to avoid battery leakage.

Consumer should read!

- 1.Please take care not damaging any furniture or glass as indoor play.
- 2.Do not play it among crowd or public road to avoid some accident, please choose a safe outdoor site to play.
- 3. Stop playing it immediately when thundering as outdoor play.
- 4.Do not play this car on a wet site or sand lot to avoid some electronic circuit problems.
- 5.Do not fold the antenna rudely, since a broken antenna may cause personal injury.
- 6.Do not drag or pull the wire on car body, since a broken wire will lose car function.
- 7.Do not touch the car wheel with finger or hand to avoid accident.
- 8.Do not run this car toward people.
- 9. This car cannot be thrown or impacted rudely.
- 10. When keeping this car, please keep it away from fire and high temperature.
- 11.A great number of electronic elements and circuits have been adopted inside this car, please do not attempt to dismantle or modify such circuit board.
- 12. When the car or controller lacks enough power, an obvious slowdown or out of control condition will happen, please replace the batteries.
- 13.If this car is idle for a long time, please take out the batteries, so its durability will be extended.

This device complies with Parth 15 of the FCC Rules. Opertion is subject to the foilowing two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interfeience that may cause undesired operation.

Warming: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits fora Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.