

Block diagram of X weighing scales.

Typ name: xx yyy.Xi (PLUS) (e.g. AS 110.X2 PLUS)
Type description:
R – family name
i - 2 stands for internal calibration version, 1 for version without internal calibration
xx – sub family name (AS or PS)
yyy – weighing range (in grams)
PLUS – always with AS version, never with PS

