

Other instructions

Music box repertoire

- 1 City of sky
- 2 Thousand and thousand and thousand
- 3 Happy birthday!
- 4 Merry Christmas5 Sweet home
- 6 Love is the flower, you are the seed
- 7 Sunny day
- 8 No matter how many times

Charging time: 2-3 hours, micro charging port, the indicator light is red when charging, and the indicator light is green when fully charged.

Discharge time: 5-6 hours for white light, 4-5 hours for colorful.

The built-in lithium battery protection board will automatically protect and shut down the power when the battery is low. Please activate it at this time.

Precautions

1.Please use a qualified power adapter (5V)

2.Please charge before use.

3.If it is not used for a long time, it is recommended to charge the setting once every 30 days.

4.Do not let children under 3 years old use alone.

5.Please use it on a stable surface.

6.Do not use in humid or high temperature environment

This product can replace the projection film, use a new projection film, first tear off the protective film of the projection film, twist and pull to remove the outer lamp cover, turn clockwise and then pull up to remove the inner lamp cover, pull it vertically to remove the inner lamp cover Cover the ring, remove the round lamp, take out the long projection film installed in the inner lamp cover, put in a new projection film, and put it back in reverse according to the same steps.

Steps to replace transparencies



将圆形投影片放到圆形透明上盖中 Place the circular projector in the round transparent upper cover transparent upper cover

After sales support

Product warranty card

Telephone

Telephone

Date of purchase

Customer information

Dealer information

Name

Name

Address

Model

Within one year from the date of purchase, please contact the dealer to deal with the quality problem of non-human damage (rechargeable battery belongs to consumables, and the specific after-sales process can be consulted with the merchant).

E-mail

Remote control description

Remote control distance: 3-5M

	Bluetooth remote control	Music box remote
	PROJECTION LAMP	PROJECTION LAMP
	USETINGUP Dimming III (NO OFF	
	W Y B ALL	W Y B ALL
	ECHISTRE SIBNITS ALL UN SOLUME.	BEO'RINGE SHIWITE VOLUME-
	1 2 3 4	1 2 3 4
	5 6 7 8	5 6 7 8
	24 KEY INFRARED REMOTE CONTROL	24 KEY INFRARED REMOTE CONTROL
	Ļ	\downarrow
	When using the remote control for the first time	
	Please point the transmitter of the remo	·
	According to the icon marked on the be operated	

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.