
현대카드_보조배터리_설명서_영문

저면



후면

Product description Product specification Product name 4000mAh BATTERY Model No CMO_05_BA 85.5*54.0*20.0 mm / 108g Model No. Size / Weight Material capacity Rated input Rated output ABS 4,000 mAh 9V/1200mA, 10.8W 9V/1200mA, 10.8W Importer Wireless charging area Manufacturer INTECO(Dongguan) Trading Co., Ltd. Manufacture Y/M 2021.11 Country of origin **Precautions** 1. To preserve the battery life, it must be used and charged at least once every three months. 2. If you use it at emperature shipfer or lower than 10°C to 40°C, the product may be damaged. Sattery life can be shortened. 3. If you use it in lot and humid places for a long time, damage to products such as battery deformation, life, explosing, et. A fire may occur. 4. Keep it out of reach of children or pets. Input / Power button Output port LED indicator **-recept volution result for the state of t How to use product with the contre. So Don't place magnet or metal objects on the wireless changing unit. It causes over heiring and mail notion. 91 facredit card or information storage medium is placed dose to the wireless changing unit, the storage information will be stored. It can be damage to 16 flycuse as the kick assor a metal call planner case, Changing may not be smooth. 11. Don't and their places are made land planner case, Changing may not be smooth. 12. Don't cut service floates metal fly care pair the product. 12. Don't cut service floates metal fly care pair the product. 13. After completely dischanging the product at the end of Si Ilis, separate litin the waste cell box to prevent lift om being incinerated. battery charged in the auxiliary battery. You can check it out. Journal of the auxiliary battery by connecting a cable to the input Journal or charge the auxiliary battery by connecting a cable to the input Journal or charge electronic devices such as a smartphone or tablet. 3. Place a device that supports wireless charging on the wireless charging unit at the top of the product. You can charge it. Press the power button twice in a row to turn off the power **E** FC