





更换配对设备及回连 斯开当前於对後蓋亚牙,耳机指示打紅蓮女替內炼,其他设备即可搜 索對以4。 点击连接以4時件写用机支持自过四连配对设备。正常开机 同即会自动四连最后一次连接的设备。请确保前端(如手机蓝牙)正 常开起。 长按+键开关键约3-5秒即会关机,揭示灯熄灭 正常连接,手机会显示耳机电量,如电量显示红色,即表示需要充电,插入充电线充电即可. 备注: 5V充电设备如手机充电器都可进行充电.

长按+键开机键约3-5秒,当指示灯红蓝交替闪烁,表示耳机已经开机.

首次使用,耳机正常开机后,会进入蓝牙配对状态,此时手机蓝牙设置里可搜索到X14,点击连接成功后指示订蓝灯呼吸,播放音乐蓝灯

中英文提示音切换: 蓝牙未连接状态, 四击+键 切换 播放状态 双击+键 -----长按+键 ----长按-键 单击-键 单击-键 来电状态 双击+键----- 接听 双击+键-----挂断 长按+键-----挂断 指示灯说明

操作说明

+键复合机

长按"+"键----- 耳机开关机 三击"+"键: 唤醒Siri

红蓝交替: 配对状态 蓝色呼吸:连接成功等待播放状态 红灯常亮: 正在充电 蓝灯常亮: 充满电量

产品参数 \* 짜목:X14 \* 版本:5.0 \* 重量约:30g \* 电池:230mAh

\* 充电:约2小时 \* 播放约:6-8H& 70%音量 \* 通话:-42dB \* 防水:IPX5

\* 距离:蓝牙10米 \* 输入:5V/500mA \* 协议:A2DP,AVRCP,HSP,HFP

确定耳机是否充满电量,按键是否误操作,同时充电激活.

耳机指示灯是否处于红蓝交替闪阶段,如耳机处于蓝灯呼吸状。 表示耳机与其他设备已经连接,需要断开当前连接设备。

确定前端 (如手机蓝牙) 是否正常开启

故障及排除


互机容量较小 手机是否加大音量,需要手机增加或减小音量 領戴方式 是否正确

格证 10 Q.C.Passed 产品保修卡

该卡为产品保修凭证,请妥善保管	
产品名称:	产品型号:
购买日期:	客户名称:
联系方式:	

∃期	不良现象	解决方案





① Indicator light ② Type-C charging port ③ Microphones
③ "+" multi-function button ⑤ "-"button Key
⑥ Memory metal back hang

Parte list 2.Type-C charging cable 3.Instruction Manual

使用说明

蓝牙连接

Instructions
Power on
Long press the multi-function button for 3-5 seconds. When a prom
power or is heard, the red and blue light alternately flashes, it mea
the headphone has been powered on.

Bluetooth connection
For first time use, after turns on, the headphone will enter Bluetooth
pairing state, Search and click "X14" on the device, there is a prompt
"connected" and the indicator will light blue every 5 seconds.

Change Bluetooth devices and Re-connection

Disconnect the current paired device from Bluetooth, the headphone indicator flashes red and blue alternately, Search and click "X14" on the new device. The X14 headphone supports automatically re-connection to last paired Bluetooth device.

Power off Long press the multi-function button for about 3-5 seconds, the headphone will shut down. Indicator light goes out.

How to Charge

Now to Charge
In connected state, the phone will display the headphone battery. If the battery icon displays red, it means the headphone is out of battery, please connect with the original USB-C charging cable (included in the package box) to charge.

Note: 0Y power supply, such as mobile phone adapters, can be used to charge.

Controls

Power on/off Long press "+" for 3-5 seconds

Pause/Play
Double click "+" for Pause/Play

Volume +/-·Click "+" once to Increase volume ·Click "-" once to Reduce volume

Next/Last Track

Answer/End/Reject Phone Call

Double click "+" to Accept the incoming call

Double click "+" to End the on-going call

Long press "+" for 2 seconds to Reject the incoming call Siri Activation

Indicator light description
Alternating red and blue light: Pairing state
Blue light breathing: Connected successfully
Red light is always on: Charging
Blue light is always on: Full charged

Chinese and English tone switching: Bluetooth is not connected, four keystrokes to switch

Specifications

\* Model: X14

\* Bluetooth Version: 5.0

\* Support Profile: HFP/HSP/A2DP/AVRCP/GAVDP

Weight: 30g Battery: 3.7V/230mAh

Charging Time: About 2 hours
Play /Call Time: About 6-8 hours
Transmittance Distance: 10m
Waterproof Level: IPX5
Input Voltage: 5V

Troubleshooting Unable to Power on

heck whether the headphone is fully charged, whether the buttor misoperated, and then charge to activate.

Unable to Pair

Unable to Pair Make sure the headphone indicator is in the alternately flashing stage of red and blue. If it is in the breathing state of blue light, it means that the headphone has been connected to other device and needs to disconnect the current connected device.

Can't Re-connect to last device

Make sure the Bluetooth has already been turned on properly.

Headphone volume is low Check and adjust the volume of the phone. If volume settings of both the phone and headphone are high enough, please check whether the wearing is in the right place.

Made in China FC (€ RoHS 🐧

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCD Rates. These limits are resident and the properties of the Part 15 of the FCD Rates. These limits are residential installation. This equipment generates usee and on maddle radio frequency energy and, if not installed and used in accordance with the instructions, many causes harmful inferterence to add communications. However, there is no many causes harmful inferterence to see communications the convert. The see determined by turning the equipment of faid on, the user is exocurged to by correct the site/ference by one or more of the following measures: — Reduction testedos the including similar and many control of — Reduction testedos the including similar and many control of — Reduction testedos the including similar and — Reduction testedos the reducting similar and — Reduction testedos the reduction similar and — Reduction test

Increase the separation between the equipment and receive

 Connect the equipment into an outlet on a circuit different from that to which the eceiver is connected. Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement in
portable exposure condition without restriction.