## **Baseus Energy Column Pro Car Wireless MP3 Charger**

User Manual

# **Package Including**

Car charger Operation manual Warranty card After-sales service card

## **Product Specifications and Basic Information**

Name: Baseus Energy Column Pro Car Wireless MP3 Charger

Model: BS-CH002

Color: Tarnish

Input: 12-24V

Output 5: 5V/3A 9V/3A 12V/2.5A 20V/1.5A

Type-C: 5V/3A 9V/3A 12V/2.5A 5V/2A 20V/1.5A

Total:5V/3A

Output ⁄ ↓ : 5V/0.5A

Wireless version: 5.0

USB flash disk playing: support

Size: 89.25mm\*20.9mm\*20.9mm

Weight: ≈32.6g

## **Operating Instructions**

- 1. Wireless connection: After inserting the product into the car cigarette lighter port, search for "BS-01" name on the mobile phone wireless interface to connect, after connecting successfully, the LED indicator lights blue;
- 2. USB flash disk playing: Insert the disk into the USB port for music play, "USB" displays on the screen, with voice recognition reminding of USB mode, and automatically switches to USB mode to play music in the disk.

# **Description of Button Functions**

| Music Play / Pause                  | Under wireless music or U disk music playing mode, press the multi-function button once to pause and play. |
|-------------------------------------|--|
| Volume Adjustment                   | When operating, rotate the multi-function button left to turn  |
|                                     | down the volume and right to turn up the volume. (Volume adjustment range is V00~V30.)                     |
| Select Music                        | Under wireless music or U disk music playing mode, rotate the  |
|                                     | knob left once to play the previous song, and right once to play the next song.                            |
| U disk / Wireless<br>mode switching | When operating, press down the knob for 5S downward to   |
|                                     | switch wireless/U disk mode, the voice assistant will tell you the current mode.                           |
| Answer phone calls                  | Press down the knob once and initiate CAL mode to answer incoming calls.                                   |
| Hang up                             | When dialing or in the middle of a call, press down the knob once to hang up.                              |
|                                     |  |

| Reject a call                     | When there is an incoming call, press the knob downwards for 2S to reject the call.                          |
|-----------------------------------|--|
| Redial                            | Under wireless mode, press down the knob twice to dial the last outgoing number, "CAL" shows on the screen . |
| Chinese / English<br>voice switch | Press down the knob for 5S after turning on to switch between Chinese and English voices.                    |

# Instructions for LED indicators

| Light flashes swiftly<br>between blue and<br>green | Wireless is not connected                      |
|--|--|
| Blue light on                                      | Wireless connected successfully / Music pauses |
| Blue light flashes slowly                          | Playing wireless music                         |
| Green light flashes slowly                         | Playing U disk music                           |
| Green light on                                     | U disk music pauses / during calls             |

### **Safety Warnings**

Please read these instructions and tips carefully before use.

Please be sure to attach these tips and the operation manual when you give the product to a third party for use.

### **Health and Safety Protections**

- 1 Please do not use this product if there is obvious damage;
- 2 Please do not let children or pets play with this product or its packaging and accessories, to avoid swallowing by mistake;
- 3 Please keep this product away from items that are susceptible to magnetic fields, such as cardiac pacemakers, or any other medical supplies;

#### Precautions

- ① Please store and use this product at room temperature and avoid long-time exposure to high and low temperatures;
- 2 Do not expose this product to rain or humid environment;
- 3 Do not bash, squeeze it or put it into fire;
- 4 Do not dismantle, repair or modify this product by yourself;

### **FCC Statement**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### RF warning:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.