

























<p>Band7-10MHz-16QAM-21100-1RB#0-30~1000-PASS</p>	<p>Band7-10MHz-16QAM-21100-1RB#0-1000~2000-PASS</p>
<p>Band7-10MHz-16QAM-21100-1RB#0-20000~26500-PASS</p>	<p>Band7-10MHz-16QAM-21400-1RB#0-30~1000-PASS</p>
<p>Band7-10MHz-16QAM-21400-1RB#0-1000~2000-PASS</p>	<p>Band7-10MHz-16QAM-21400-1RB#0-20000~26500-PASS</p>























