





NTVN-N78-3700-3800-PC3-30-15-M-DFT-QPSK-Edge_1RB_Left-6000-18000-Ant1-PASS

NTVN-N78-3700-3800-PC3-30-15-M-DFT-QPSK-Edge_1RB_Left-18000-40000-Ant1-PASS





NTVN-N78-3700-3800-PC3-30-15-H-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS

NTVN-N78-3700-3800-PC3-30-15-H-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-15-H-DFT-QPSK-Edge_1RB_Left-30-1000-Ant1-PASS

NTNV-N78-3700-3800-PC3-30-15-H-DFT-QPSK-Edge_1RB_Left-1000-6000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-15-H-DFT-QPSK-Edge_1RB_Left-6000-18000-Ant1-PASS


NTNV-N78-3700-3800-PC3-30-15-H-DFT-QPSK-Edge_1RB_Left-18000-40000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-20-L-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-20-L-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-20-L-DFT-QPSK-Edge_1RB_Left-30-1000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-20-L-DFT-QPSK-Edge_1RB_Left-1000-6000-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-20-L-DFT-QPSK-Edge_1RB_Left-6000-18000-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-20-L-DFT-QPSK-Edge_1RB_Left-18000-40000-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-20-M-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-20-M-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-20-M-DFT-QPSK-Edge_1RB_Left-30-1000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-20-M-DFT-QPSK-Edge_1RB_Left-1000-6000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-20-M-DFT-QPSK-Edge_1RB_Left-6000-18000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-20-M-DFT-QPSK-Edge_1RB_Left-18000-40000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-20-H-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS





NTNV-N78-3700-3800-PC3-30-20-H-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS



NTNV-N78-3700-3800-PC3-30-20-H-DFT-QPSK-Edge_1RB_Left-30-1000-Ant1-PASS





NTNV-N78-3700-3800-PC3-30-20-H-DFT-QPSK-Edge_1RB_Left-1000-6000-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-20-H-DFT-QPSK-Edge_1RB_Left-6000-18000-Ant1-PASS

NTVN-N78-3700-3800-PC3-30-20-H-DFT-QPSK-Edge_1RB_Left-18000-40000-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-25-L-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS


NTVN-N78-3700-3800-PC3-30-25-L-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-25-L-DFT-QPSK-Edge_1RB_Left-30-1000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-25-L-DFT-QPSK-Edge_1RB_Left-1000-6000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-25-L-DFT-QPSK-Edge_1RB_Left-6000-18000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-25-L-DFT-QPSK-Edge_1RB_Left-18000-40000-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-25-M-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS





NTVN-N78-3700-3800-PC3-30-25-M-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS



NTVN-N78-3700-3800-PC3-30-25-M-DFT-QPSK-Edge_1RB_Left-30-1000-Ant1-PASS





NTVN-N78-3700-3800-PC3-30-25-M-DFT-QPSK-Edge_1RB_Left-1000-6000-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-25-M-DFT-QPSK-Edge_1RB_Left-6000-18000-Ant1-PASS

NTVN-N78-3700-3800-PC3-30-25-M-DFT-QPSK-Edge_1RB_Left-18000-40000-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-25-H-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS


NTVN-N78-3700-3800-PC3-30-25-H-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-25-H-DFT-QPSK-Edge_1RB_Left-30-1000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-25-H-DFT-QPSK-Edge_1RB_Left-1000-6000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-25-H-DFT-QPSK-Edge_1RB_Left-6000-18000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-25-H-DFT-QPSK-Edge_1RB_Left-18000-40000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-30-L-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS





NTNV-N78-3700-3800-PC3-30-30-L-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS



NTNV-N78-3700-3800-PC3-30-30-L-DFT-QPSK-Edge_1RB_Left-30-1000-Ant1-PASS





NTNV-N78-3700-3800-PC3-30-30-L-DFT-QPSK-Edge_1RB_Left-1000-6000-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-30-L-DFT-QPSK-Edge_1RB_Left-6000-18000-Ant1-PASS

NTVN-N78-3700-3800-PC3-30-30-L-DFT-QPSK-Edge_1RB_Left-18000-40000-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-30-M-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS


NTVN-N78-3700-3800-PC3-30-30-M-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-30-M-DFT-QPSK-
Edge_1RB_Left-30-1000-Ant1-PASS







NTNV-N78-3700-3800-PC3-30-30-M-DFT-QPSK-
Edge_1RB_Left-1000-6000-Ant1-PASS





NTNV-N78-3700-3800-PC3-30-30-M-DFT-QPSK-
Edge_1RB_Left-6000-18000-Ant1-PASS





NTNV-N78-3700-3800-PC3-30-30-M-DFT-QPSK-
Edge_1RB_Left-18000-40000-Ant1-PASS






NTNV-N78-3700-3800-PC3-30-30-H-DFT-QPSK-
 Outer_Full-6000-18000-Ant1-PASS

NTNV-N78-3700-3800-PC3-30-30-H-DFT-QPSK-
 Outer_Full-18000-40000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-40-L-DFT-QPSK-
 Edge_1RB_Left-0.009-0.15-Ant1-PASS


NTNV-N78-3700-3800-PC3-30-40-L-DFT-QPSK-
 Edge_1RB_Left-0.15-30-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-40-L-DFT-QPSK-Edge_1RB_Left-30-1000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-40-L-DFT-QPSK-Edge_1RB_Left-1000-6000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-40-L-DFT-QPSK-Edge_1RB_Left-6000-18000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-40-L-DFT-QPSK-Edge_1RB_Left-18000-40000-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-40-M-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS





NTVN-N78-3700-3800-PC3-30-40-M-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS



NTVN-N78-3700-3800-PC3-30-40-M-DFT-QPSK-Edge_1RB_Left-30-1000-Ant1-PASS





NTVN-N78-3700-3800-PC3-30-40-M-DFT-QPSK-Edge_1RB_Left-1000-6000-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-40-M-DFT-QPSK-Edge_1RB_Left-6000-18000-Ant1-PASS

NTVN-N78-3700-3800-PC3-30-40-M-DFT-QPSK-Edge_1RB_Left-18000-40000-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-40-H-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS


NTVN-N78-3700-3800-PC3-30-40-H-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-40-H-DFT-QPSK-
Edge_1RB_Left-30-1000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-40-H-DFT-QPSK-
Edge_1RB_Left-1000-6000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-40-H-DFT-QPSK-
Edge_1RB_Left-6000-18000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-40-H-DFT-QPSK-
Edge_1RB_Left-18000-40000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-50-L-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS







NTNV-N78-3700-3800-PC3-30-50-L-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-50-L-DFT-QPSK-Edge_1RB_Left-30-1000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-50-L-DFT-QPSK-Edge_1RB_Left-1000-6000-Ant1-PASS







NTNV-N78-3700-3800-PC3-30-50-M-DFT-QPSK-
Edge_1RB_Left-30-1000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-50-M-DFT-QPSK-
Edge_1RB_Left-1000-6000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-50-M-DFT-QPSK-
Edge_1RB_Left-6000-18000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-50-M-DFT-QPSK-
Edge_1RB_Left-18000-40000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-50-H-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS





NTNV-N78-3700-3800-PC3-30-50-H-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS



NTNV-N78-3700-3800-PC3-30-50-H-DFT-QPSK-Edge_1RB_Left-30-1000-Ant1-PASS





NTNV-N78-3700-3800-PC3-30-50-H-DFT-QPSK-Edge_1RB_Left-1000-6000-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-50-H-DFT-QPSK-Edge_1RB_Left-6000-18000-Ant1-PASS

NTVN-N78-3700-3800-PC3-30-50-H-DFT-QPSK-Edge_1RB_Left-18000-40000-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-60-L-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS


NTVN-N78-3700-3800-PC3-30-60-L-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-60-L-DFT-QPSK-Edge_1RB_Left-30-1000-Ant1-PASS





NTNV-N78-3700-3800-PC3-30-60-L-DFT-QPSK-Edge_1RB_Left-1000-6000-Ant1-PASS



NTNV-N78-3700-3800-PC3-30-60-L-DFT-QPSK-Edge_1RB_Left-6000-18000-Ant1-PASS





NTNV-N78-3700-3800-PC3-30-60-L-DFT-QPSK-Edge_1RB_Left-18000-40000-Ant1-PASS





NTVN-N78-3700-3800-PC3-30-60-M-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS

NTVN-N78-3700-3800-PC3-30-60-M-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS





NTVN-N78-3700-3800-PC3-30-60-M-DFT-QPSK-Edge_1RB_Left-30-1000-Ant1-PASS

NTVN-N78-3700-3800-PC3-30-60-M-DFT-QPSK-Edge_1RB_Left-1000-6000-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-60-M-DFT-QPSK-Edge_1RB_Left-6000-18000-Ant1-PASS

NTVN-N78-3700-3800-PC3-30-60-M-DFT-QPSK-Edge_1RB_Left-18000-40000-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-60-H-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS


NTVN-N78-3700-3800-PC3-30-60-H-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-60-H-DFT-QPSK-Edge_1RB_Left-30-1000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-60-H-DFT-QPSK-Edge_1RB_Left-1000-6000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-60-H-DFT-QPSK-Edge_1RB_Left-6000-18000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-60-H-DFT-QPSK-Edge_1RB_Left-18000-40000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-70-L-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-70-L-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-70-L-DFT-QPSK-Edge_1RB_Left-30-1000-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-70-L-DFT-QPSK-Edge_1RB_Left-1000-6000-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-70-L-DFT-QPSK-Edge_1RB_Left-6000-18000-Ant1-PASS





NTVN-N78-3700-3800-PC3-30-70-L-DFT-QPSK-Edge_1RB_Left-18000-40000-Ant1-PASS



NTVN-N78-3700-3800-PC3-30-70-M-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS





NTVN-N78-3700-3800-PC3-30-70-M-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS





NTVN-N78-3700-3800-PC3-30-70-M-DFT-QPSK-
 Edge_1RB_Left-30-1000-Ant1-PASS

NTVN-N78-3700-3800-PC3-30-70-M-DFT-QPSK-
 Edge_1RB_Left-1000-6000-Ant1-PASS





NTVN-N78-3700-3800-PC3-30-70-M-DFT-QPSK-
 Edge_1RB_Left-6000-18000-Ant1-PASS

NTVN-N78-3700-3800-PC3-30-70-M-DFT-QPSK-
 Edge_1RB_Left-18000-40000-Ant1-PASS





NTVN-N78-3700-3800-PC3-30-70-H-DFT-QPSK-
 Edge_1RB_Left-0.009-0.15-Ant1-PASS

NTVN-N78-3700-3800-PC3-30-70-H-DFT-QPSK-
 Edge_1RB_Left-0.15-30-Ant1-PASS





NTVN-N78-3700-3800-PC3-30-70-H-DFT-QPSK-
 Edge_1RB_Left-30-1000-Ant1-PASS

NTVN-N78-3700-3800-PC3-30-70-H-DFT-QPSK-
 Edge_1RB_Left-1000-6000-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-70-H-DFT-QPSK-Edge_1RB_Left-6000-18000-Ant1-PASS

NTVN-N78-3700-3800-PC3-30-70-H-DFT-QPSK-Edge_1RB_Left-18000-40000-Ant1-PASS




NTVN-N78-3700-3800-PC3-30-80-L-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS


NTVN-N78-3700-3800-PC3-30-80-L-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS




NTNV-N78-3700-3800-PC3-30-80-L-DFT-QPSK-
Edge_1RB_Left-30-1000-Ant1-PASS





NTNV-N78-3700-3800-PC3-30-80-L-DFT-QPSK-
Edge_1RB_Left-1000-6000-Ant1-PASS



NTNV-N78-3700-3800-PC3-30-80-L-DFT-QPSK-
Edge_1RB_Left-6000-18000-Ant1-PASS





NTNV-N78-3700-3800-PC3-30-80-L-DFT-QPSK-
Edge_1RB_Left-18000-40000-Ant1-PASS





NTVN-N78-3700-3800-PC3-30-80-M-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS

NTVN-N78-3700-3800-PC3-30-80-M-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS





NTVN-N78-3700-3800-PC3-30-80-M-DFT-QPSK-Edge_1RB_Left-30-1000-Ant1-PASS

NTVN-N78-3700-3800-PC3-30-80-M-DFT-QPSK-Edge_1RB_Left-1000-6000-Ant1-PASS



NTVN-N78-3700-3800-PC3-30-80-M-DFT-QPSK-Edge_1RB_Left-6000-18000-Ant1-PASS

NTVN-N78-3700-3800-PC3-30-80-M-DFT-QPSK-Edge_1RB_Left-18000-40000-Ant1-PASS



NTVN-N78-3700-3800-PC3-30-80-H-DFT-QPSK-Edge_1RB_Left-0.009-0.15-Ant1-PASS

NTVN-N78-3700-3800-PC3-30-80-H-DFT-QPSK-Edge_1RB_Left-0.15-30-Ant1-PASS