# PORTABLE WIRLESS SPEAKER

# Instruction Manual

Item Number:MU03035



### **Contents:**

- Bluetooth speaker x 1
- Charging cable x1
- Instruction Manual x 1

# **Product Specification:**

Battery Capacity: 500 mAh/3.7V

Play Time: 3-4 Hours

Charging Time: around 3 Hours

Speaker Output: 3W x 1
Range: 33ft / 10 m

Frequency Response: 20Hz-20KHz
Operating temperature range: 0-45 °C

Includes 11.81" Micro USB charging cable


Dimension: 3.54in. X 1.73in. X 3.11in. (9cm x 4.4cm x 7.9cm)

Weight: 196g Input: 5V --- 500mA

#### Part Name:

- 1. " <sup>ტ</sup> " On / Off
- 2. " + " Volume Up / Next song
- 3. " ◀ " Pause/Play
- 4. " " Volume Down / Previous song





# **How To Use:**

- Power on: Press the power key " o" 1 second when it is off. The blue LED light will be on and flash, and a voice will prompt, this indicates the BT Speaker is in pairing mode.
- Pairing: Activate the bluetooth function on your phone within range and select "PROTABLE BT SPEAKER" from the list shown. When the blue LED light stops flashing, it has paired successfully and you will hear a tone. The blue LED will flash slowly when playing music.
- Play/Pause: When it is playing, press the center key "◄" to pause, then press again to play.
- Volume up: Hold down "+" to increase the volume.
- Volume down: Hold down "-" to decrease the volume.
- Previous song: Press the "-" once to play the previous song.
- Next song: Press the "+" once to play the next song.
- Power off: When the speaker is standby or operating, press and hold the speaker key "φ" 3 seconds to shut down the speaker.

## **Front**

**Low Battery:** LED indicator turns off and a short tone will prompt **To Charge:** 

- 1. Insert the USB connector end of the included cable (see packing list) into the USB jack on the charger or insert the type c end of the included cable into the speaker's type c charging port.
- 2. The indicator light will be red while charging.
- 3. When the speaker is fully charged, the indicator light will turn off.

Please unplug your charger from the power source.

- 4. Please use a qualified charger to recharge your speaker, otherwise it may result in damage or even explosion.
- 5. Repeated charging and discharging of the speaker will lead to decreased battery life over time, which is normal for rechargeable batteries.
- $\ensuremath{\mathrm{6}}$  . You must charge the Bluetooth speaker if it has not been used for more than  $\ensuremath{\mathrm{6}}$  months.

## **WARNING:**

- Charge and operate only as indicated in this manual, as improper use may result in damage to the product or injury.
- To avoid risk of shock or injury, do not dismantle the device or insert any objects into the speaker.
- To avoid electronic interference and/or compatible conflicts, turn off the product in any facilities where posted notices instruct you to do so.
- Do not pull the speaker charging cable. Damage may result to the cable.
- Keep out of reach of children. This is not a toy.
- Avoid exposure to moisture, liquids, heat, flame and high voltage equipment.
- Retain these instructions as they contain important information.
- Do not short circuit the input terminals of the speaker.
- Do not drop, place heavy weight or allow heavy impact to the speaker.
- PCB of battery should not be crushed and twisted.
- Battery body should not be bended.
- Do not disassemble and Do not dispose of in fire.

## RF warning statement:

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

Tips: Please do not turn the volume knob to the maximum level to prevent hearing damage and to prolong the service life of the system.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two condiions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

-"WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

-"NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications."

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help." FCC ID: 2AYB6-MU03035

FCC ID. ZAT BO-WIO03033

Distributed By: 1616 Holdings, Inc 701 Market Street, Suite 200, Philadelphia,PA 19106 Made in China

