

# WS001

Wireless Headphones

## Quick start guide


### 1 Power on

1. Open the charging case
2. Press and hold the function button for 3 seconds, the earbuds are now ready for pairing



### 2 Bluetooth Pairing

Turn on Bluetooth on your phone, select "WS001" and follow up the introduction to complete pairing.



### 3 Tap controls

(Under the condition of wearing both ears) :  
Answer calls/hang up , double tap the right earbud during calls, removing both earbuds, audio can be switched to the device. Reinsert them, audio can be switched to the earbuds.

Play /stop music , double tap the right earbud. Removing either one of your earbuds will pause the audio. Reinsert it to resume playback.



### 4 Noise Cancellation

(Under the condition of wearing both ears) :  
Turn on/off noise cancellation;  
Double tap the left earbud.


Remark:

1. ANC Off in normal
2. Noise cancellation mode cannot be turned on when only wearing one ear
3. Removing either one of your earbuds will turn off ANC. Reinsert it back to resume ANC



### 5 Charging your earbuds

Place your earbuds into the charging case to start charging them.



### 6 Charging the charging case

Wired charging : Use the USB-C charging cable included to charge the charging case.  
When charging ,the indicator shows red , and green indicates full.



### FCC WARNING:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.