


Thank You For Purchasing Your BusyBox® Smart Sign


Follow these instructions for a smooth setup

- 1** Remove or rotate open the cover.
The charging port is located on the right side. The cover is held on with strong magnets.

Connect the USB-C cable into your BusyBox. A full charge takes about 3 hours.




- 2** Use the remote. You can select from a variety of colors and presets by using the remote.



- 3** Scan the code below to access a list of all the preset, there are over 350 built in!



- 4** Stick the 3M Command Strips to the back of the BusyBox mounting plate. Place the mounting plate on your door or wall. Attach your BusyBox.



Enjoy your interruption-free space!

For the most up-to-date technical help, email us at Hello@BusyBoxSign.com or go to www.YouTube.com/busyboxsign.

Important Information


SAFETY INSTRUCTIONS:

Read, keep and follow these instructions and all instructions found on, and updated from time to time, on our website. **Heed all warnings.**



DO NOT EXPOSE TO RAIN

To reduce the risk of ⚡ fire or ⚡ electric shock do not expose this apparatus to rain. Do not use this apparatus near water.



DO NOT DISASSEMBLE

Dismantling, rewiring, removing components or otherwise altering the function of the unit may cause unexpected behavior and will invalidate your warranty.

Do not block ventilation openings.

We warranty that BusyBox will be free from manufacturer's defects for 90 days. If the device should stop working on it's own after 90 days, please contact us as we might be able to help.

FCC WARNINGS

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to connect the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

FCC ID: 2AYDY-BZYBXR



Thank you for purchasing this BusyBox® sign.
If you need any additional help please email us at:
support@BusyBoxSign.com

2023 BusyBox Corp., Patents Pending

© 2023 BusyBox® is a product of BusyBox Corp. PO BOX 482,
Whitinsville, MA 01588 USA

