

**User Manual**  
True Wireless Earbuds

**FIND YOUR FIT**  
Choose your comfortable size

(Put the earwing below the auricle) (Slightly adjust to your comfortable angle)

X1 X1 X1 X1

**PAIRING**  
1. Open the lid of the charging case first (Blue flash and enter the pairing mode)

- 2 -

2. Turn on the pairing function via BT on your device

- 3 -

3. From the list of available devices and select "Calcini SweatPro 3"

- 4 -

**Music**

**Play/Pause**  
Double click the left or right earbud

**Prev Track**  
Long press the left earbud for 2s

**Next Track**  
Long press the right earbud for 2s

- 5 -

**Calls**

**Dial via voice assistant**  
Long press left or right earbud for 4s can activate Siri or other voice assistant  
Double click left or right earbud can cancel call

**Answer/End calls**  
Click the left or right earbud  
**Hang up or Reject**  
Double click the left or right earbud

- 6 -

**Volume -**  
Click the left earbud

**Volume +**  
Click the right earbud

- 7 -

68mm

96mm

**Game Mode**

Triple click left or right earbud (Double click again switch to music mode)

- 10 -

**WaterProof (IPX8)**

The earbuds will NOT RECEIVE the BT signal in the following situations:  
1. Diving with earbuds  
2. Earbuds are submerged in water while swimming (You can take shower with earbuds)

Signal Reception Explanation Picture:

- 11 -

**Reset the earbuds**

You need reset your earbuds in following case:  
1. Bad signal, slow connection  
2. Your earbuds are connected with other device

**Starting with the earbuds**  
1. Take both earbuds out of the case  
2. Touch and hold on the touch-control panels on both earbuds for 6s to power off until red flashing  
3. Touch and hold on the touch-control panels on both earbuds for 10s. (Blue flashing indicate it is power on and red flashing 3 times indicate it be reset successfully)  
4. Put both earbuds into the charging case and close the lid  
5. Open the lid again, and both earbuds will turn on then enter the pairing mode. (Please refer the page 3-5)

- 12 -

**Package Contents**

- A Pairs of Earbuds with charging case
- USB-C Cable
- SIML Ear Tips
- SIML Ear Wings
- User Manual
- Thank Card

**Product Diagram**

LED Battery Level Indicator Charging Input LED Status Indicator and Microphone

- 13 -

**Getting Started Charging**

Fully charge the charging case before the first use. To charge, connect the charging case to a USB charger or charging port with the included USB-C cable.

- 14 -

**Controls & LED Indicators Streaming Audio**

Once paired, you can wirelessly stream audio on your device via earbuds. Music will automatically get paused when you receive an incoming phone call and will be resumed once the call ends

Play or pause music	Double click the left or right earbud
Skip to previous track	Long press the left earbud for 2s
Skip to next track	Long press the right earbud for 2s
Answer call	Click the left or right earbud
Hang up or Reject	Double click the left or right earbud
Cancel call	Double click left or right earbud
Volume +	Click the right earbud
Volume -	Click the left earbud
Same low latency	Triple click left or right earbud
Switch to music mode	Double click left or right earbud

**Earbuds**

LED Status Indicator	Status
Blue flashing	Pairing
Red and blue flashing alternately	TWS pairing
Red flashing 3 times	Reset

**Charging Case**

LED Status Indicator	Status
Blue flashing 10S	Earbuds charging
Blue always flashing	Charging case charging
Blue turn off	Charging case fully charged

**Turning On/Off**

Turn On	Open the lid of the charging case or touch and hold on the touch-control panels on one of the earbuds that you want to turn on for 6s
Turn Off	Return the earbuds to the charging case and close the lid or touch and hold on the touch-control panels on one of the earbuds that you want to turn off for 6s

- 15 -

**Specifications**

Model	EA07
Technology	A2DP, AVRCP, HFP, HSP, AAC
Speaker Sensitivity	90dB±3dB@1kHz
Frequency Range	20Hz-20KHz
Impedance	16Ω
Charging Time	1.5h
Battery Life	>5h
Battery Type	Li-polymer (2 x 50mAh)
Operating Range	10m/30m
Weight	39g

**Charging Case**

Charging Input	5V
Charging Time	1.5h
Battery Type	Li-polymer 500mAh
Number of Earbuds Recharges	4 times
Weight	39g

- 16 -

**Pairing**

Starting with the earbuds in the case:  
1. Open the lid of charging case, both earbuds will be turned on.  
2. Take the earbuds out of the charging case and then enter pairing mode.  
3. Turn on the pairing function via BT on the device you want to pair with the earbuds.  
4. From the list of available devices and select "Calcini SweatPro 3"

**Regular Use After Pairing**

Once the earbuds are successfully paired with your device, they can be switched on and off as follows:  
1. Open the lid of the charging case, then both earbuds will turn on and connect with each other automatically.  
2. To turn off, put the earbuds back in the charging case and close the lid. They will begin charging

**Product Care & Use**

- Keep away from liquids and extreme heat
- Don't use the earbuds at high volume for extended periods, as this may cause permanent hearing damage or loss

- 17 -

**FCC Warning Statement:**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy. If not installed and used in accordance with the instruction may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following.

**Measures:**

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference.  
(2) This device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement.

**Contact us :**

Join member

Official Website: [www.calcini.com](http://www.calcini.com)  
Support Service: [support@calcini.com](mailto:support@calcini.com)  
B2B Distributor: [distributors@calcini.com](mailto:distributors@calcini.com)

- 18 -

**Measures:**

-Reorient or relocate the receiving antenna.  
-Increase the separation between the equipment and receiver.  
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference.  
(2) This device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement.

- 19 -

尺寸公差			要求		品名	SweatPro 3 说明书 (线上)	比例	1:1	日期 DATE	2021.12.29
位数	尺寸	角度								
X / X . X	±1mm	±0.5°			料号	A	DESIGNED	HOY	审核 CHECKED	
X . XX	±0.5mm	±0.5°								
					版本 FORMAT		制图 DRAWN		批准 APPROVED	
记事					变更NO.	年/月/日	深圳市激沃科技有限公司 SHENZHEN WEWO TECH CO., LTD			