

第二版：亚马逊中端

60*60mm

双面印刷

COTOGNI

P3

User Manual

True Wireless Earbuds

PACKAGE CONTENTS

- 1x Charging Case
- 1x USB-C Cable
- 1x User Manual
- 1 Pair of Earbuds

OVERVIEW

CHARGING

1. Charging earbuds

Put earbuds back to charging case and close the charging case,earbuds white indicator will flashing

2. Charging case

Plug in the cable to the charging case port,white indicator will flashing

SWITCH CONTROL

Turn On

Take the earbuds out of the charging case Or press the touch panel on earbud for 6s

Turn Off

Return the earbuds to the charging case and close the lid Or touch and hold the earbuds touch panel for 6s (when both earbuds are used, it cannot be turned off when acting on one earbud)

EARBUDS PAIRING

Open the charging case lid, then take earbuds out of the case,white indicator flashing means earbuds power on and enter the pairing mode

Once connecting your device successfully first time,earbuds reconnect your device automatically when you take them out of the charging case again

DEVICE CONNECTING

1. Turn on the Bluetooth on your device
2. Take earbuds out of charging case

3. Select "Cotogni P3" from the list of available devices

Once connecting your device successfully first time,earbuds reconnect your device automatically when you take them out of the charging case again

contact us

support@cotogni.com
info@cotogni.com

active lifetime warranty

DEVICE CHANGING

1. Touch and hold the both earbuds for 10s, earbuds will disconnect from previous device
2. Select the 'cotogni P3' from your new devices bluetooth list

MUSIC

Double tap the L / R earbud

Prev Track

Touch and hold the L earbud for 2s

Next Track

Touch and hold the R earbud for 2s

VOLUME

Volume-

Triple tap the L earbud

Volume+

Triple tap the R earbud

CALLS

Answer/Hang Up Calls

Double tap L/R earbud

Reject Calls

Touch and hold L/R for 2s

CONTROLS & LED INDICATORS

Play /Pause	Double Tap L/R earbud
Prev Track	Touch and hold L earbud for 2s
Next Track	Touch and hold R earbud for 2s
Answer/Hang Up Calls	Double tap L/R earbud
Reject Calls	Touch and hold L/R for 2s
Volume -	Triple tap the L earbud
Volume +	Triple tap the R earbud

LED Status Indicator	Status
White flashing	Pairing
White always on	Charging
No indicator	Fully charged

LED Status Indicator	Status
White flashing	Charging
White always on	Fully charged

SPECIFICATIONS

Earbuds	
Model	E408A
Technology	A2DP AVRCP HFP HSP AAC_SBC
Speaker Sensitivity	95dB ± 3dB@1KHz
Frequency Range	20Hz - 20KHz
Impedance	32Ω
Charging Time	1H
Battery Life	5H x2 (max volume)
Battery Type	Li-polymer (30mAh x 2)
Operating Range	10m/33H
Weight	3.5g x 2

Charging Case	
Charging Input	DC 5V
Charging Time	1.5H
Battery Type	Li-polymer 300mAh
Number of Earbuds Recharges	3 times (pair)
Weight	38g

ATTENTION:

- You need take earbuds out of the charging case then them will power on. It will power off after it be backed into the charging case and close the lid.
- Please take the earbuds out of the charging case before connecting to the phone.
- Once it connected device successfully first time, earbuds will connect your device automatically after you take them out of the charging case next time.
- Before to connect the new device, you should turn off the previous connected device's Bluetooth or forget the pairing data.
- When earbuds charging, please close the charging case lid.
- Keep away from corrosive liquid and fire source.
- When the earbuds can't be charged normally, please try to manually return the earbuds to the correct position in charging case.
- Each earbud just control itself separately,Each earbud can be used individually.

FCC WARNING STATEMENT:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device,pursuant to Part 15 of the FCC Rules.These limits are designed to provide reasonable protection against harmful interference in a residential installation.This equipment generates uses and can radiate radio frequency energy. If not installed and used in accordance with the instructions,may cause harmful,interference to radio communications.However, there is no guarantee that interference will not occur in a particular installation.If this equipment does cause harmful interference to radio or television reception,which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following.

MEASURES:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC Rules.Operation is subject to the following two conditions:

- This device may not cause harmful interference
- This device must accept any interference received,including interference that may cause undesired operation.The device has been evaluated to meet general RF exposure requirement.

The device has been evaluated to meet general RF exposure requirement.