

亚马逊中端

尺寸：52*60mm 材质：128g双铜纸（双面印刷）

User Manual

support@cologni.com | info@cologni.com

P6

FCC ID: 2AYH6-EA12

PACKAGE CONTENTS

- 1x Charging Case
- 1x USB-C Cable
- 1x User Manual
- 2x Ear Cap
- A Pair of Earbuds

OVERVIEW

Microphone

Indicator

Touch Panel

Digital Display

Charging Port

charging interface

CHARGING

1. Charging earbuds

Put earbuds back to charging case and close

Put earbuds back to charging case, the indicators on earbuds flash.

2. Charging case

Plug in the cable to the charging case port, The blue light will flashing: the digital display on charging case flashes

SWITCH CONTROL

6S

6S

Turn On

Take the earbuds out of the charging case

Or press the touch panel on earbud for 6s

6S

6S

Turn Off

Return the earbuds to the charging case and close the lid,

Or touch and hold the earbuds touch panel for 6s (when both earbuds are used, please touch and hold the both earbuds touch panel for 6s to turn them off. It cannot be turned off if you operate on single earbud)

DEVICE CONNECTING

- Turn on the Bluetooth on your device
- Take earbuds out of charging case

3. Select "P6" from the list of available devices

Once connecting your device successfully first time, earbuds reconnect your device automatically when you take them out of the charging case again

MUSIC

Play/Pause

Double tap the L / R earbud

Prev Track

Next Track

Touch and hold the L earbud for 2s

Touch and hold the R earbud for 2s

VOLUME

Volume-

Volume+

Triple tap the L earbud

Triple tap the R earbud

CALLS

Answer/End Calls

Answer/Hang Up Calls

Double tap L/R earbud

Reject Calls

Touch and hold L/R for 2s

RESET THE EARBUDS

In the following cases, you can disconnect your current headset link and search for the headset signal link again:

- You want to connect the headset to a new device
- After multiple devices are connected to the headset, you cannot find which device is connected, and you want to ignore the current headset connect

Starting with the earbuds

- Take both earbuds out of the charging case

10S

10S

- Long press the touch panels on both earbuds for 6s to power off until red flashing

10S

10S

- Press and hold the touch panel on the two earbuds for 10 seconds to reset (then release the earbuds and see the blue lights on the left and right sides flashing slowly, indicating that the pairing of the left and right earphones has been completed, and you can search and pair the wireless earphones again)

CONTROLS & LED INDICATORS

Play /Pause	Double Tap L/R earbud
Prev Track	Touch and hold L earbud for 2s
Next Track	Touch and hold R earbud for 2s
Answer/HangUp Calls	Double tap L/R earbud
Reject Calls	Touch and hold L/R for 2s
Volume -	Triple tap the L earbud
Volume +	Triple tap the R earbud

Earbuds	
LED Status Indicator	Status
blue flashing	Pairing
blue always on	Charging
No indicator	Fully charged

Charging Case	
LED Status Indicator	Status
Red flashing	Charging
Red always on	Fully charged

SPECIFICATIONS

Earbuds	
Model	EA12
Technology	A2DP, AVRCP, HFP, HSP, AAC, SBC
Speaker Sensitivity	99dB±3dB@1KHz
Frequency Range	20Hz ~ 20KHz
Impedance	32Ω
Charging Time	1.5H
Battery Life	5H (max volume)
Battery Type	Li-polymer (35mAh x 2)
Operating Range	10m/33ft
Weight	3.5g x 2

Charging Case	
Charging Input	DC 5V
Charging Time	1.5H
Battery Type	Li-polymer 250mAh
Number of Earbuds Recharges	3 times (pair)
Weight	41g

ATTENTION:

- Take the earbuds out of the charging case before you use it. The earbuds will power on and enter into pairing mode automatically. Return the earbuds back to the charging case after use, they will power off automatically.
- Once the earbuds has been successfully connected to your device, they will automatically reconnect to your device when you take them out of the charging case next time.
- Before you want to connect a new device, please turn off the Bluetooth on the current device or as per the DEVICE CHANGING in this manual.
- When the earbuds are charging, please close the case lid.
- Keep this products away from liquid or fire. Do not put the earbuds into the charging case when they are wet.
- When the earbuds can't be charged, please check and make sure the connector of the earbuds&charging case are clean and dry.
- If you need to use single earbud, please take one earbud from the charging case and then connect to your device. Also you can return one earbud back to the charging case when you are using both earbuds, keep using the other earbud without extra operation.

FCC WARNING STATEMENT:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy. If not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following.

MEASURES:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - This device may not cause harmful interference
 - This device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement.