





E05说明书

72x97mm

User Manual	<h3>Product Overview</h3>  <p>The diagram shows the earbuds with indicator lights, the charging case with a Type-C USB port, and the charging port on the case.</p>	<h3>What's in the Box</h3> <table border="1"><tr><td>Earbuds</td><td>x 2</td></tr><tr><td>Charging Case</td><td>x 1</td></tr><tr><td>Silicone Ear Tips (S/M/L)</td><td>x 3</td></tr><tr><td>Type-C USB Cable</td><td>x 1</td></tr><tr><td>User Manual</td><td>x 1</td></tr></table> <h3>How to pair</h3> <ol style="list-style-type: none">Open the charging case, The headset starts automatically and the left and right ears start to connect, when L&R earbuds is connected successful, the red and white LED will flash slowly alternately, and the earbuds will flash once in 5 seconds to enter the pairing mode.Select " " under bluetooth menu on your device. The pairing is successful.  <p>The screenshot shows the Bluetooth settings on a smartphone, with the device name 'E05' and a 'connect' button.</p>	Earbuds	x 2	Charging Case	x 1	Silicone Ear Tips (S/M/L)	x 3	Type-C USB Cable	x 1	User Manual	x 1	<ol style="list-style-type: none">3. Congratulations, your earbuds are connected successfully. You can choose to use them at TWs Mode or MONO Mode.4. The next time you use it,open the charging case, it will automatically connect to your device, after the connection is successful, the white LED in the left and right earbuds flash synchronously, 5s flashes once.  <p>The image shows the charging case and the two earbuds.</p>	<h3>Touch Control</h3>  <p>The diagram shows the touch controls on the earbuds: Phone Mode, Reject a call, Accept a call/Hangup a call, Switching three way call, Music Mode, Play/Pause, Right ear Next (R), Idle Mode, Activate voice assistant, Left ear Switch to ANC mode (L).</p> <p>* Note : Support Siri,Google Assistant,Alexa,etc.</p> <h3>Power on</h3> <p>-- Open the charging case.</p> <h3>Power off</h3> <p>-- Close the charging case.</p> <h3>If you are in a call and another call comes in</h3> <p>-- Double Click to answer the new call and keep the original call; -- Long touch 1s to reject the second call. -- Three strikes to switch calls between two sides, Double strikes to hang up the current call .</p>	<h3>Charging</h3> <p>After putting the earbuds back into the charging case, close the cover.</p> <h3>Earphone low power</h3> <p>When low battery, the voice announcement will remind you to charge every5 minutes.</p> <h3>Charging the Charging Case</h3> <p>Charging the charging case, you can use the Type-C cable or wireless charger, the red indicator flashes and is always on.</p> <h3>Charging box Charges the headset</h3> <table border="1"><tr><td>Open the charging box: seconds and goes out.</td><td>white light goes on for five</td></tr><tr><td>Close the charging box: seconds and goes out.</td><td>white light goes on for five</td></tr><tr><td>Low power of charging box</td><td>Red flashing.</td></tr></table>	Open the charging box: seconds and goes out.	white light goes on for five	Close the charging box: seconds and goes out.	white light goes on for five	Low power of charging box	Red flashing.	<h3>Factory data reset</h3> <p>Try to reset as following instructions when two earbuds are unable to connect.</p> <ol style="list-style-type: none">In the single headset re pairing mode, click three times. After the headset clears the pairing record, the headset will turn off automatically.Repeat with the other headset.To connect the left and right ears, the earphone should be paired with TWS. After the earphone is turned on, it will automatically enter into pairing.The TWS pairing between the left and right ears will search for connection with each other. After connection, the main camera will flash red and white lights alternately and flash 5S once from the phone. <h3>FAQ</h3> <ol style="list-style-type: none">How to change from Mono Mode to Dual Mode.<ol style="list-style-type: none">When you just only use the right earbud, take out the left earbud from charging case, the music will come out from the left and right earbuds at the same time.When you just only use the left earbud, take out the right earbud from charging case, the music will come out from the left and right earbuds at the same time.How to change from Dual Mode to Mono Mode.<ol style="list-style-type: none">When you put your right earbud into the charging case, the left earbud will continue playing music.When you put your left earbud into the charging case, the right earbud will continue playing music.	<ol style="list-style-type: none">3. The earbuds cannot reconnect to my device automatically If your earbuds are connected to several devices before, they will reconnect automatically with the recently connected device.<ol style="list-style-type: none">Make sure the Bluetooth of the mobile phone is turned on, close the cover again,and turn on the headset again.If the left and right ear lights flash synchronously for 5S once after the earphone is turned on, it indicates that the headset has been connected to other mobile phones. Turn off the Bluetooth of the mobile phone that has been connected to the headset. The red and white lights ofthe host flash slowly and flash once from the machine for 5S, and the headset will automatically enter into pairing Mode, and then search the connection with the current mobile phone.Let the headset reset to factory settings, and then use the current phone to search for the connection again.5. No sound from left/right earbud. Please put your earbuds into the charging case, and then take out them again. if still not solve this problem, please carry out restoring the factory settings(Page 7),and then put your earbuds into charging case and then take out them again.6. Can't turn on my earbuds.<ol style="list-style-type: none">Put the earbuds into the charging case again,and make sure that the earbuds is in the compartment and there is no shaking.Close the cover, then charge the charging case.After flushing for a period of time,open the cover again and try to activate the headset.	<h3>FCC Compliance Statement</h3> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>RF Exposure Information The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> <h3>Federal Communication Commission Interference Statement</h3> <p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: · Reorient or relocate the receiving antenna. · Increase the separation between the equipment and receiver. · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. · Consult the dealer or an experienced radio/TV technician for help.</p>	<h3>FCC Caution</h3> <p>Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.</p> <h3>Important Safety Information</h3> <p>Handle this earbuds with care.They contain sensitive electronic components and batteries, which can be damaged or cause injury if dropped/ durned/punctured/crushed/disassembled, or exposed to excessive heat or liquid. Do not use damaged earbuds.Please follow the instructions:</p> <p>Do not use this product near water. Clean only with dry cloth. Only use accessories specified by the manufacturer Refer servicing to qualified personnel.</p> <div style="border: 1px solid black; padding: 5px;"><p>CAUTION: Prevention of Hearing Loss Permanent hearing loss may occur if earbuds are used at high volume for prolonged periods of time.</p></div>
Earbuds	x 2																								
Charging Case	x 1																								
Silicone Ear Tips (S/M/L)	x 3																								
Type-C USB Cable	x 1																								
User Manual	x 1																								
Open the charging box: seconds and goes out.	white light goes on for five																								
Close the charging box: seconds and goes out.	white light goes on for five																								
Low power of charging box	Red flashing.																								