SPORTS SMART WATCH

USER MANUAL

MODEL：LOTUS S13

THANK YOU FOR CHOOSING OUR SMART WATCH. YOU CAN FULLY UNDERSTAND THE USE AND OPERATION OF THE EQUIPMENT BY READING THIS MANUAL.

THE COMPANY RESERVES THE RIGHT TO MODIFY THE CONTENTS OF THIS MANUAL WITHOUT ANY PRIOR NOTICE WITHOUT PRIOR NOTICE.

THE PRODUCT CONTAINS: A PACKING BOX, A MANUAL, A HOST, AND A DATA CABLE.

1. WATCH FUNCTION DESCRIPTION

1.1 BUTTON DESCRIPTION:

On the dial interface, short press to turn on the screen and turn off the screen / one key on the function interface to return to the main dial

Long press switch, choose X to not shut down, choose √ to shut down

1.2 Charging instructions:

Magnetic charging, as shown in the figure below.

*Please note that the two contacts of the charging cable cannot contact the conductor at the same time, which will cause the circuit to burn.

1.1 Shortcut function:

1) Swipe left to enter the step counter interface, swipe down to view the number of steps, distance, and calorie consumption of the day. Swipe left again to enter the heart rate test and sleep record.
2) Scroll down to enter brightness adjustment, weather, do not disturb mode, settings, call Bluetooth switch, check version and Bluetooth address.
3) Swipe right to enter the message notification (used after connecting to Bluetooth).
4) Swipe up to enter the menu interface, and slide up and down to find the corresponding function.
5) Long press the dial interface to slide to switch dials, and then touch to set successfully.

1.2 Push message
1) When the watch is bound to the APP, and the notification permission is turned on, the new messages received in the notification bar of the mobile phone will be pushed to the watch. A total of 10 messages can be saved, and the messages received after 10 messages will be overwritten one by one. news.
2) Slide to the bottom and press the delete icon to clear all message records.

1.3 Drop-down menu
The dial interface slides down to open the drop-down menu interface.
1) Power display; Bluetooth connection status; time display, week .
2) The first icon can debug brightness adjustment.
3) The second icon, the weather and temperature of the day (connected to APP).
4) The third icon, do not disturb mode, turn on Do not disturb only for message information, but not for phone audio.
5) The fourth icon, shortcut function setting.
6) The fifth icon, turn on or off Bluetooth for audio calls.
7) The sixth icon, about.

1.4 Phone/Call History
1. When the phone is not connected to the Bluetooth call, enter the phone, you can turn on/off the Bluetooth phone. When the Bluetooth phone is turned on, it will prompt you to pair + Bluetooth name + the last four digits of the Bluetooth address. After the Bluetooth connection is successful, you can use the watch to use it. Bluetooth phone answering/hanging up.
2. Call record, can save the record of connected and dialed calls. (It can save more than 50 call records, and it will be automatically overwritten when 128 records are full. Click any call record to call back)
3. Dial the keyboard, you can enter the phone number to make a call.

1.5 message
The watch is successfully bound to the APP, the corresponding notification authority in the mobile phone system is opened, and the mobile phone information can be synchronized with the watch.
1.5.1. Call notification:
Turn on the call reminder in the personal application. When the phone receives the call reminder, the watch will light up and vibrate.
1.5.2. SMS notification:
The SMS notification is enabled in the personal application. When one or more SMS messages are received on the mobile phone, the watch will receive one or more SMS reminders at the same time.

1.5.3. Other application message notifications:

Turn on the corresponding application message notification switch in personal applications, such as WeChat, QQ, Outlook, Facebook and other applications. When the mobile terminal receives one/multiple application message notifications, the watch terminal will receive one/multiple corresponding message reminders at the same time Notice.

1.6 Frequently used contacts

1. You can connect to the APP. In the device of the APP" select frequently used contacts" add contacts (up to 20 contacts can be added), which can be synchronized to the watch, and the watch can display up to 20 contacts.

1.7 Fitness data

The fitness data is turned on by default. Swipe the watch to the right to enter the fitness data interface, and slide it down to display the current steps, distance, and calories of the watch. The data is cleared at 12 o'clock in the morning every day.

1.8 Sports modes (strike, running, cycling, skipping rope, badminton, basketball, football)

1.8.1 Select the corresponding exercise mode, click the start button on the screen to enter the corresponding exercise mode; click the start button of the exercise being calculated to pause the exercise, click the end button to end the exercise and save the data.

1.8.2 The exercise data can be saved when the exercise time is greater than 1 minute; when the exercise is saved under this condition, it will prompt "Too little data to save". (After exiting, exercise data can only save step data)

1.9 Heart rate

Put the watch on your wrist (left/right) correctly, enter the heart rate menu, you can measure the heart rate value in a single time, the data will be output in 10 seconds, and the measurement will be completed in 10-20 seconds.

1.10 ECG

Put the watch on your (left/right) wrist correctly, enter the ECG menu (need to open the APP "ECG monitor" interface), you can measure the ECG value in a single time, the data is output in 10 seconds, and the measurement is completed in 10-20 seconds. A single ECG can be saved in the APP synchronously, this function needs to be connected to the APP to use.

2.0 blood pressure

Put the watch on your (left/right) wrist correctly, enter the blood pressure menu, you can measure a single blood pressure value, the data is output in 10 seconds, and the measurement is completed in 10-20 seconds.

2.1 Blood oxygen

Wear the watch correctly on your wrist (left/right hand), enter the blood oxygen menu, you can measure a single blood oxygen value, the data is output in 10 seconds, and the measurement is completed in 10-20 seconds.

2.2 Remote music

Connecting to the APP, you can control the phone's music/start/pause/previous/next song, and the speaker sound appears on the phone.

Connect the call Bluetooth, you can control the phone music/start/pause/previous/next song, and the speaker sound appears on the watch.

2.3 Sleep

Sleep monitoring time period: 18:00 in the evening to 10:00 the next day, the watch generates data. After exiting the sleep monitoring, the sleep data on the watch can be synchronized to the APP for viewing after connecting to the app.

2.4 stopwatch

Click the stopwatch to enter the timing interface, and you can record the time at a time.

2.5 Weather

After the watch is connected to the app and the data is synchronized, the weather information of the day will be displayed when the watch terminal clicks on the weather, and the weather conditions can be displayed in Celsius and Fahrenheit.

2.6 Find mobile phone

After the watch is bound to the app, click to find the phone on the watch side, and the phone will vibrate or ring tones.

2.7 Meteorology

Click on the weather on the watch side to display the day's ultraviolet (UV), atmospheric pressure, and altitude conditions.

2.8 Breathing

There are three modes of breathing: slow, moderate, and fast, which can be selected. You can breathe according to the mode selected by the user. You can select 1, 2, and 3 minutes to measure the breathing data. Select 1, 2, and 3 minutes to automatically end the breathing measuring.

2.9 massager

Click the green button to start the massage, and the watch is in vibration state, click the red button to end the massage state.

3.0 Female assistants

Record the status of women's menstrual period, and you can view the data of the last month end time, the length of the menstrual period, and the number of days between menstrual periods on the app.

3.1 Menu style

There are 3 menu styles to choose from. After setting, the menu style of the watch will also be changed.

3.2 Settings

1) To switch the watch face, slide right to select the next watch face, select a watch face, click once to set this watch face, slide left to return to the previous watch face.
2) Screen on time; 5 to 30 seconds off screen time can be selected.
3) Vibration intensity; click to set reminder vibration intensity, support level 1, level 2, level 3 vibration intensity selection.
4) Bluetooth phone; Bluetooth phone can be turned on/off. After turning it on, the user will be prompted: Please pair the Bluetooth device, and find the device name in the Bluetooth of the phone settings to connect to the phone Bluetooth.
5) Restore factory settings; click √ to enable factory reset, the watch will be restored to the factory state, click X to cancel the factory reset.

2.. Bind APP

1. APP download method

1.1 Scan the QR code to download

1.2 Application market search and download
Android side:
　　App treasure, Google play app market search WearPro to download
IOS side:
　　Search for WearPro in the APP Store to download
Android phones: WearPro is installed and the application icon is shown in the

figure:

Apple mobile phone: WearPro is installed and the application icon is shown in the

figure:

2. Bind Bluetooth

2.1 Not connected state:

After the watch is turned on, the Bluetooth is always in the searched state. After opening the APK/APP, go to Device "Add Device" and click Start Search, select and click the corresponding watch device name to successfully bind the watch to the app.

2.2 Bind app status:

Watch time synchronization: The watch is successfully bound to the app. Click to synchronize the time between the watch and the mobile phone.
2.3 Bind audio call
On the dial interface, slide down from top to bottom, enter the drop-down interface,

turn on the audio call switch , click on , check the Bluetooth name, turn on the Bluetooth in the settings of the mobile phone, find the corresponding Bluetooth name, and click connect.

3. Find the device

The watch is successfully bound with the app. Click to find the watch on the mobile app and the watch will vibrate once when the screen is on.

4. Camera

Tap the camera to wake up the watch device's camera mode, tap the camera button to take a photo, and the picture will be automatically saved to the phone system album.

5. Data synchronization

The watch is successfully bound to the app, and the watch data can be synchronized to the app.

6. Raise your hand to brighten the screen

6.1 Open

Wear the watch correctly on your wrist (left hand/right hand). When you turn on the hand-up button, when you lift your wrist to look at the watch, the watch will automatically brighten the screen.

6.2 Close

Wear the watch correctly on your wrist (left hand/right hand). When the hand-up button is turned on, when the wrist is raised up to look at the watch, the watch is in a black screen, and you need to press the power button to turn on the screen.

7. Do not disturb mode

In the APP Device>More, set the start to end time, such as: 12:00 to 14:00 noon for the do not disturb mode, during this time there will be no phone calls and message sound reminders on the watch.

8. Daily alarm clock

8.1 New alarm

In the APP in the APP Device>More, set the start to end time, the alarm can be set only once or repeatedly select the date (week) setting, and the alarm can be turned on/off.

8.2 Delete alarm

Select and hold a set alarm clock and swipe to the right to delete the set alarm.

9. Sedentary reminder

Set the start to end time period and the sedentary time interval (minutes) in the APP, click to enter the repeat setting only once or select the sedentary reminder date (week). When the sedentary time is reached, the watch will vibrate and there will be a sedentary icon.

10. Drink water reminder

Set the start to end time period and frequency (minutes) in the APP, click to enter the repeat setting, select the drinking reminder date (week), check the drinking reminder and save it. When the reminder time for drinking water arrives, the watch will vibrate and there will be a drink icon.

11. Dial push

11.1 Push an existing watch face

Connect to the app, go to Device>Dial Push>Select Dial>, and make sure to replace it with this dial. After the dial is synchronized, the watch will automatically restart and then automatically connect to the app.

11.2. Custom watch face

Connect to the APP, select in Device>Dial Push>(Dials with pen icons belong to custom dials) Customize Dial Settings>Select a custom background. After the dial is synchronized, the watch will automatically restart and then automatically connect to the app.

12. Firmware version

Display the version of the watch, and users can choose to upgrade the firmware version.

13. Unbind

Bind the watch to the app, unbind in the device, click OK and unbind, the IOS system needs to go to the phone settings to ignore the Bluetooth device.

●**Frequently asked questions and answers**

*Please avoid exposing the device to extreme temperatures that are too cold or too hot for a long time, which may cause permanent damage.

*Why can't I take a hot bath with my watch?

The temperature of the bathwater is relatively high, it will produce a lot of water vapor. The water vapor is in the gas phase, and its molecular radius is small, and it is easy to seep in from the gap of the smartwatch case. When the temperature drops, it re-forms into liquid water droplets, which is easy to cause The internal circuit of the smartwatch is short-circuited, which damages the circuit board of the smartwatch and damages the smartwatch.

*No power on, no charging

If you receive the smartwatch that does not turn on, it may be that a collision occurred during the transportation of the smartwatch and the battery Seiko board was protected, so plug in the charger to activate it.

If the battery is too low, or the smartwatch does not turn on after a long time without using the smartwatch, please plug in the charger and charge for more than half an hour to activate.

Warranty description:

1. When this product is in normal use, if there are product quality problems caused by manufacturing, materials, design, etc.,

Starting from the date of purchase, the motherboard is guaranteed for free within one year, and the battery and charger are guaranteed for half a year.

2. No free warranty is provided for failures caused by the user's personal reasons, as follows:

1). Failure caused by unauthorized disassembly or modification of the watch.

2). Failure caused by accidental falls during use.

3). All person-made, faults and misuses of a third party (such as water in the host, external force cracks, scratches, damage to peripheral components, etc.) are not covered by the warranty.

3. When requesting a free warranty, please provide a warranty card with the date of purchase and the stamp of the place of purchase.

4. When the user repairs the product, please take the product to our company or our company's dealership.

5. All functions of the product are based on physical objects.

FCC Statement

1.This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a determined particular installation. If this equipment does cause harmful interference to radio or television reception, which can be by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 5mm between the radiator & your body.

Purchase date:

IMEI code:

Purchase store：

Customer signature:　　　　　**Sales clerk signature：**　　　　**Store stamp：**