

# MATTE 200G THICK

## IMPORTANT NOTE:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

**UP-TECH®**

## SAFETY INFORMATION:

Do not attempt to disassemble the device.  
Doing so, may result in an electric shock.  
Do not use this device on an aircraft or in a hospital.  
Do not expose this device to direct sunlight, heat or open flame.  
Device may become warm while charging.

## CAUTION:

Any changes or modifications to this device, not expressly approved by the party responsible for compliance, could void the user's authority to operate this device.  
This device and its antenna(s) must not be co-located or operated in conjunction with any other antenna or transmitter.

## This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference
2. This device must accept any interference received, including interference that may cause undesired operation.

**UP-TECH®**



**sound+time**  
Wireless Speaker Alarm Clock

## SPECIFICATIONS

Bluetooth Version: 5.0  
Output Power: 3W  
Transmission Distance: 33ft  
Play Time: \*3.5h  
Charging Time: 2.5h  
Battery: 500mAh  
S/N: ≥86dB  
Inputs: 3.5mm Aux, USB, TF Card and Micro USB  
\* Estimate based on continuous play at 60% volume  
Bluetooth Frequency Range: 2.4GHz to 2.480GHz  
Thank you for choosing the **Sound + Time Wireless Speaker Alarm Clock**.  
Please take the time to read this manual carefully, even if you are already familiar with a similar product.

14cm

20cm

## 🔌 CHARGING YOUR BLUETOOTH SPEAKER

Your **Sound + Time Wireless Speaker Alarm Clock** comes with a built-in rechargeable battery and a Micro USB charging cable. Charge fully before use. The battery indicator will turn red when charging.

## ↔️ PAIRING DEVICE:

Power ON the speaker. The speaker will automatically enter Bluetooth Pairing mode once powered on. The BT icon with display underneath the time. On your device's Bluetooth menu, find and select "UPTECH SOUND TIME". (you may be required to enter a password "0000").

## M / ⏻ POWER ON/OFF AND SELECT MODE

Press and hold to Power ON, press and hold again to Power OFF. Short press to select the Bluetooth Mode, Radio Mode, and Clock Mode. Aux Mode and TF/Micro SD Mode become available when an Aux cable or a TF/Micro SD card is inserted.

## ⏮️ PREVIOUS TRACK

Music Mode: Short press to select the previous track.  
Radio Mode: Short press to select the previous radio stations.

## ⏸️ PLAY / PAUSE / ANSWER CALL

Music Mode: Short press the button to play or pause music.  
Radio Mode: Press twice to scan for available FM stations. The speaker will automatically save all stations for future use. Please allow 1-2 minutes for the initial scan to be completed.  
Call Mode: Short press the button once to accept calls. Short Press again to end the call and resume music. Press twice to reject the incoming call.

## ⏭️ NEXT TRACK

Music Mode: Short Press to select the next track.  
Radio Mode: Short Press to select the next radio stations.

## 🕒 CLOCK SETTING

**Time Setting:** Long press in clock mode to set the time, the time display will flicker. Press -/+ to set the hour. After setting the hour press the clock button again to set the minutes. Press -/+ to set the minutes.

**Alarm 1 Setting:** After setting the time press the clock button again to set ON/OFF the alarm using the -/+ buttons. Press the clock button again to set the alarm time. Repeat the time setting process to set the alarm time.

**Alarm 2 Setting:** After setting the alarm 1 press the clock button again. Repeat the alarm 1 setting process to set the alarm time.

**Sound Setting:** After alarm 2 is set press the clock button again to set the sound using the -/+ buttons. Once selected long press the clock button to save the selection. Once alarms are set the display will show the following icons 🕒 🕒

## ⏴ VOLUME DOWN

Press to decrease the volume

## ⏵ VOLUME UP

Press to increase the volume

## TF/MICRO SD CARD SLOT

Insert your TF/ Micro SD card into the designated slot and TF MODE will be activated automatically. Once you insert the TF card, use the control buttons to play the media.

## USB PORT

Insert your USB KEY into the designated slot and USB MODE will be activated automatically. Once you insert the USB KEY, use the control buttons to play media.

## AUX AUDIO PORT

Using a 3.5mm AUX audio cable connect the speaker with your non-Bluetooth enabled mobile phone/MP3 player/PC/laptop and select the appropriate mode to play media.

## MICRO USB CHARGING PORT

DC 5V: Use the included Micro USB Cable to connect device to a computer's USB port or a compatible AC power adapter with USB to charge.

