

料号:
7106500157

| 版本 | 时间 | 修改内容 |
|-----|------------|--------------------------|
| 1.0 | 2021.12.17 | 第一次制作文件 |
| 2.0 | 2022.03.29 | 根据A10(7106500144)制作A11文件 |
| 3.0 | 2022.03.31 | 修改“显示白灯3秒”及磁吸部分文案删除 |

Pencil A11
User Manual

Packaging List
Pencil x 1
User Manual x 1
Type C Cable x 1
Pen Tip x 1

▼ Quick Guide

- 1. Turn on**
Press the button to turn on the Pencil; the indicator light turns white for 3 seconds and then turns off.
- 2. Turn off**
Press and hold the button for 2 seconds or let it stand for 5 minutes in the power-on state, the device will shut down, and the indicator will turn red for 3 seconds then turn off.
- 3. Bluetooth Pairing**
The pencil will directly enter the pairing state, when the device is turned on for the first time. If the pencil is paired, press and hold the key for 5 seconds, the pencil will clear the previous pairing information and enter the pairing state. The indicator will flash alternately between red and white in the pairing state.
- 4. Shortcut Keys**
When the Pencil is paired, click the button to cancel the previous operation; double-click the button to switch to the eraser tool (support Goodnotes&Procreate); in the camera mode, three-click the button to take a remote photo.
- 5. Charging**
Use a Type-C charging cable to charge the Pencil. The indicator light will be red breathing when charging, and it turns white when it is fully charged.
- 6. Magnetic**
Pencil can be magnetic stored on the iPad pro, iPad Air, iPad Mini series Apple Pencil.
- 7. Replace the nib**
Unscrew the tip counter-clockwise to exact, and clockwise to secure.

*Do not support wireless charging.

Pencil A11
说明书

包装清单
Pencil x 1
说明书 x 1
Type C 充电线 x 1
笔尖 x 1

▼ 使用指南

- 1. 开机**
单击按钮开机, 开机时指示灯显示白色3s后熄灭。
- 2. 关机**
开机状态下长按按钮2秒或是静置5分钟, 设备将自动关机, 关机时指示灯显示红色3秒后熄灭。
- 3. 蓝牙配对**
首次使用Pencil时, 开机直接进入配对状态, 已配对的Pencil在开机状态下长按5秒钟清除之前配对信息, 进入配对状态。配对状态下红白灯交替闪烁。
- 4. 快捷按键**
配对iPad后, 单击按钮撤销上一步操作; 双击按钮切换至橡皮擦工具(支持Goodnotes&Procreate); 相机模式下三击按钮远程拍照。
- 5. 充电**
使用Type-C充电线可以为Pencil充电, 充电时指示灯为红色呼吸灯, 充满时指示灯变为白色。
- 6. 磁吸**
Pencil可以吸附在iPad pro, iPad Air, iPad Mini系列。
- 7. 更换笔尖**
如需更换笔尖, 请逆时针旋出旧笔尖, 然后顺时针旋入新笔尖。

*不支持无线充电。

Pencil A11
取扱説明書

梱包明細
Pencil x 1
取扱説明書 x 1
Type C 充電ケーブル x 1
ペン先 x 1

▼ クイックガイド

- 1. 電源を入れます**
ボタンをクリックしてオンにすると、インジケータライトが3秒間白くなり、その後オフになります。
- 2. シャットダウンします**
デバイスの電源がオンになったら、ボタンを2秒間押し続けるか、5分間放置すると、デバイスが自動的にシャットダウンします。シャットダウンすると、インジケータライトが3秒間赤になり、その後消灯します。
- 3. Bluetoothペアリング**
初めて鉛筆を使用する場合は、電源を入れると直接ペアリング状態になります。ペアリングした鉛筆をオンにした場合は、5秒間押し続けると、前のペアリング情報がクリアされ、ペアリング状態になります。ペアリング状態では、赤と白のライトが交互に点滅します。
- 4. ショートカットキー**
iPadとペアリングした場合は、ボタンをクリックして前の操作をキャンセルします。ボタンをダブルクリックして消しゴムツール (Goodnotes & Procreateをサポート) に切り替えます。カメラモードでは、ボタンを3回クリックしてリモートで写真を撮ります。
- 5. 充電**
鉛筆はType-C充電ケーブルを使用して充電できます。インジケータライトは充電中は赤色の呼吸灯で、充電完了になると白色になります。
- 6. 磁気吸引力**
Pencilは、iPad pro、iPad Air、iPad Miniシリーズに接続できます。
- 7. ペン先を交換します**
ペン先を交換する必要がある場合は、古いペン先を反対時計回りに回してから、新しいペン先を時計回りにねじ込みます。

*ワイヤレス充電はサポートしていません。

▼ Compatible Devices

iPad Air (3rd Generation or later)
iPad Mini (5th Generation or later)
iPad (9th Generation or later)
iPad Pro 11-inch
iPad Pro 12.9-inch (3rd Generation or later)
* All iPad Models must be updated to iOS 12.2 or above.
* If your iPad was paired with an Apple pencil before, please unpair it before using the Pencil.

▼ 兼容设备

iPad Air (第三代及以后)
iPad Mini (第五代及以后)
iPad (第九代及以后)
iPad Pro 11英寸
iPad Pro 12.9英寸(第三代及以后)
* iPad必须升级至iOS 12.2及以上
* 如果您的iPad之前配对过Apple Pencil, 在使用此设备前请解除配对。

FCC statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement Caution:

This equipment complies with FCC exposure limits set forth for an uncontrolled environment.

"This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help."

7106500157

成品尺寸:
48*115mm 展开尺
寸: 144*192mm 材
质: 80g书写纸
折页方式: 风琴折
印刷: 单色黑印刷

| 深圳市千分一智能技术有限公司 Shenzhen Qianfenyi Intelligent Technology Co. LTD. | | | |
|--|------------|-----|---|
| 机 型 | pencil A11 | 颜 色 | / |
| 料 号 | 7106500157 | 底 色 | / |
| 材 质 | 80g书写纸 | | |
| 尺 寸 | 48*115mm | | |