



APPENDIX 1 PHOTOS OF TEST SETUP**E-Field Strength and H-Field Strength
Position C (Distance 15cm)****E-Field Strength and H-Field Strength
Position D (Distance 15cm)**

**E-Field Strength and H-Field Strength
Position A (Distance 15cm)****E-Field Strength and H-Field Strength
Position B (Distance 15cm)**

**E-Field Strength and H-Field Strength
Position E (20cm)****E-Field Strength and H-Field Strength
Position C (10cm)****Intertek Testing Services Shanghai**

Address: Building 86, No. 1198 Qinzhou Road(North), Shanghai 200233, P.R. China
Tel: +86 21 61278200 Fax: +86 21 54262353

**E-Field Strength and H-Field Strength
Position D (10cm)****E-Field Strength and H-Field Strength
Position A (10cm)**


**E-Field Strength and H-Field Strength
Position B (10cm)****E-Field Strength and H-Field Strength
Position E (10cm)****Intertek Testing Services Shanghai**

Address: Building 86, No. 1198 Qinzhou Road(North), Shanghai 200233, P.R. China
Tel: +86 21 61278200 Fax: +86 21 54262353

**E-Field Strength and H-Field Strength
Position C (0cm)****E-Field Strength and H-Field Strength
Position D (0cm)**

**E-Field Strength and H-Field Strength
Position A (0cm)****E-Field Strength and H-Field Strength
Position B (0cm)**

**E-Field Strength and H-Field Strength
Position E (0cm)**



Intertek Testing Services Shanghai

Address: Building 86, No. 1198 Qinzhou Road(North), Shanghai 200233, P.R. China
Tel: +86 21 61278200 Fax: +86 21 54262353