



























FRONT

3.75"  
95.25mm

 <p>100135769_EN_231222</p>	<h3>WHAT'S INCLUDED</h3> <table border="1"> <thead> <tr> <th>Part</th> <th>Description</th> <th>Picture</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Streaming Device x1</td> <td></td> </tr> <tr> <td>2</td> <td>Quick Start Guide x1</td> <td></td> </tr> <tr> <td>3</td> <td>Remote Control x1</td> <td></td> </tr> <tr> <td>4</td> <td>Batteries x2</td> <td></td> </tr> <tr> <td>5</td> <td>HDMI Cable x1</td> <td></td> </tr> <tr> <td>6</td> <td>Power Adapter x1</td> <td></td> </tr> </tbody> </table>	Part	Description	Picture	1	Streaming Device x1		2	Quick Start Guide x1		3	Remote Control x1		4	Batteries x2		5	HDMI Cable x1		6	Power Adapter x1		<h3>SAFETY INFORMATION</h3> <p><b>WARNING</b></p> <ul style="list-style-type: none"> <li>No parts should be repaired by users.</li> <li>Place the device on a flat, firm and stable surface. Do not put it on a carpet or rug.</li> <li>Protect the device from high temperatures, humidity, water and dust.</li> <li>Do not mix old and new batteries and do not mix alkaline, standard (carbon-zinc) or rechargeable (ni-cd, ni-mh, etc.) batteries.</li> <li>Do not place any objects near your device that may damage it (e.g. liquid-filled objects or candles).</li> <li>Place the device in a well-ventilated location to prevent the accumulation of internal heat.</li> <li>Presence of live parts inside the device! Do not open. Risk of electric shock!</li> </ul>	<h3>SAFETY INFORMATION</h3> <p><b>CAUTION</b></p> <h4>Battery Replacement</h4> <p>Risks of explosion if the battery is replaced by an incorrect type:</p> <ul style="list-style-type: none"> <li>replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types)</li> <li>disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion</li> <li>leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas</li> <li>a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas</li> </ul> <h4>The Environment for Device</h4> <ul style="list-style-type: none"> <li>Appropriate Operating Temperature: 32°F to 104°F</li> <li>Appropriate Operating Humidity: 5% - 85% Non-condensing.</li> </ul>	<h3>STREAMING DEVICE</h3> <p>1. Front Panel</p>  <p>2. Back Panel</p> 	<h3>REMOTE CONTROL</h3> <p>Standby on/off, Profile, Enter, Up/Down, Back, Volume Up, Volume Down, Quick Launch Buttons</p>  <p>Customizable Google Assistant Dashboard, Left/Right, Live TV Guide Channel Up, Channel Down Mute</p>	<h3>REMOTE CONTROL</h3> <p>Customizable Button</p>  <p>You can set the <b>Star</b> button to open a favorite app or display TV inputs.</p> <p>Open a favorite app, Display TV inputs</p>	<h3>HOW TO POSITION</h3> <p>Position Your Streaming Device</p>  <p>Recommend 12 inches away</p> <p>Please position your Streaming Device 12 inches away from any other devices. Please do not position your Streaming Device in any closed cabinet.</p>	<h3>SETUP</h3> <p>1. Start Up TV</p> <p>Turn on your TV before using Streaming Device.</p> <p>2. Set Input Source On TV</p> <p>After your TV is turned on, go to the Inputs page where you can switch the input source. Select HDMI Input, e.g. HDMI1.</p> 	<h3>SETUP</h3> <p>3. Connection</p> <p>3.1 Connection To Your TV</p> <p>Connect HDMI to HDMI port of the device and TV set.</p>  <p>3.2 Connection With Power</p> <p>Connect the included power adapter to the Streaming Device which will power on the unit.</p> 	<h3>SETUP</h3> <p>4. Follow On-Screen Setup</p> <p>Follow the on-screen instructions to set up Google TV™ on your Streaming Device.</p> <p>4.1 Remote Pairing</p> <p>Insert the 2 AAA batteries into the remote. Hold both <b>BACK</b> and <b>HOME</b> button on the remote until pairing is successful.</p> 	 <p>We'd love to hear from you. Scan with your smartphone camera and let us know what you think.</p>
Part	Description	Picture																														
1	Streaming Device x1																															
2	Quick Start Guide x1																															
3	Remote Control x1																															
4	Batteries x2																															
5	HDMI Cable x1																															
6	Power Adapter x1																															
				1047.75mm																												

BACK

3.75"  
95.25mm

<h3>SETUP</h3> <p>4.2 Select language</p> <p>Follow the on-screen instructions to select your language and region.</p>  <p>4.3 Set up with the Google Home app or on the TV</p> <p>1. On the Google Home app: Install the Google Home app from your phone's app store, then open the Google Home app and scan the QR code on the right side of TV.</p> <p>2. On TV: Follow the on-screen setup.</p> 	<h3>SETUP</h3> <p>4.4 Wi-Fi Connection</p> <p>Select your Wi-Fi network and enter the password.</p>  <p>4.5 Sign in to your Google Account</p> <p>Log in for a personalized Google TV experience.</p> 	<h3>SETUP</h3> <p>4.6 Select your services</p> <p>Follow the on-screen instructions to select which streaming services you use.</p>  <p>4.7 Remote Control Set Up</p> <p>Follow the on-screen instructions to set up your remote.</p> 	<h3>SETUP</h3> <p>5. Start Exploring</p> <p>Browse 700,000+ movies and TV episodes, plus live TV, from across your streaming services — in one place.</p> 	<h3>GOOGLE ASSISTANT</h3> <p><b>Hey Google</b></p> <p>Talk to Google Assistant to control your TV with just your voice</p> <p>The hands-free mic can be activated in settings. (Settings &gt; Accounts &amp; Sign-in &gt; Select Account &gt; Google Assistant &gt; Hands-free Mic)</p> <p>With hands free voice control, you can set aside your remote and simply use your voice to search and access entertainment, get answers, control the TV and smart home devices, and streamline your day. Just say "Hey Google" to get started.</p> <p>1. Enjoy entertainment "Hey Google, find action movies" "Hey Google, search for funny shows"</p> <p>2. Control your smart home "Hey Google, dim the lights" "Hey Google, show me the front door camera"</p> <p>3. Get answers and plan your day "Hey Google, what's the weather today?" "Hey Google, what is on my agenda today?"</p> 	<h3>INDICATOR STATE</h3> <p><b>Mute State</b></p> <p>When the microphone is off, indicators will light up in red.</p>  <p><b>Unmute State</b></p> <p>When the microphone is on, indicators will light up in white after you say "Hey Google" to indicate that Google Assistant has been activated.</p> 	<h3>SOUND OUTPUT</h3> <p>1. TV off, HDMI cable is connected</p>  <p>2. TV on, HDMI cable is unconnected</p>  <p>When TV is off or HDMI cable is unconnected, all the sound will be output by Streaming Device itself. (Refer to scenario 1 and scenario 2 above)</p>	<h3>FIND MY REMOTE</h3>  <p>Within a range up to 30ft (360 inches), by pressing the Find my remote Button, the remote control will emit a sound for 30s.</p> <p>The sound can be turned off by pressing any button on the remote control.</p>	<h3>TROUBLESHOOTING</h3> <ul style="list-style-type: none"> <li><b>No display after power on?</b> <ul style="list-style-type: none"> <li>Confirm the HDMI cable is plugged in properly.</li> <li>Make sure your TV has not entered sleep mode. Press the power button on the remote control to wake up your TV.</li> </ul> </li> <li><b>TV has images but no sound?</b> <ul style="list-style-type: none"> <li>Make sure your TV is not in mute or low volume.</li> <li>Fail to connect to the network?           <ul style="list-style-type: none"> <li>Make sure Wi-Fi is functional and your box has a strong enough signal from your router.</li> </ul> </li> <li>Remote control failure?           <ul style="list-style-type: none"> <li>Replace the battery of the remote control with a new one, and make sure it is placed in the correct polarity.</li> <li>If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:               <ul style="list-style-type: none"> <li>Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</li> <li>Consult the dealer or an experienced radio/TV technician for help.</li> </ul> </li> </ul> </li> </ul> <p><b>Please use the original accessories to ensure safety and a better experience.</b></p> </li></ul>	<h3>COMPLIANCE</h3> <h4>FCC Statement</h4> <p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> <li>Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</li> <li>Consult the dealer or an experienced radio/TV technician for help.</li> </ul>	<h3>COMPLIANCE</h3> <h4>FCC Radiation Exposure Statement</h4> <p>This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons.</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> <ol style="list-style-type: none"> <li>(1) this device may not cause harmful interference, and</li> <li>(2) this device must accept any interference received, including interference that may cause undesired operation.</li> </ol> <p>Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p>	<h3>COMPLIANCE</h3>  <p>Manufactured under license from Dolby Laboratories. Dolby, Dolby Vision, Dolby Atmos, and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation.</p>  <p>The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.</p> <p>Google TV is the name of this device's software experience and a trademark of Google LLC. Google, YouTube and Google Home are trademarks of Google LLC. Netflix is a trademark of Netflix, Inc. All brands contained herein are trademarks of their respective owners.</p>
				1047.75mm							

- Cut line
- - - Fold line
- Copy safe area
- Outside bleed