

Figure 7
Inside of the EUT



Figure 8
Inside of the EUT



Figure 9
Inside of the EUT




Figure 10
Inside of the EUT




Figure 11
Inside of the EUT




Figure 12
Inside of the EUT




Figure 13
Inside of the EUT




Figure 14
Inside of the EUT



Figure 15
Inside of the EUT



Figure 16
Inside of the EUT




Figure 17
Power Board of the EUT




Figure 18
Power Board of the EUT




Figure 19
Main Board of the EUT




Figure 20
Main Board of the EUT




Figure 21
Main Board of the EUT




Figure 22
Main Board of the EUT




Figure 23
Main Board of the EUT




Figure 24
Main Board of the EUT




Figure 25
Main Board of the EUT




Figure 26
PCB of the EUT




Figure 27
PCB of the EUT




Figure 28
PCB of the EUT




Figure 29
USB of the EUT




Figure 30
USB of the EUT





Figure 31
RF Module**Figure 32**
Power Cable

Figure 33
Remote Controller



Figure 34
Remote Controller

