

<div><div>60mm</div><div><div>Projector CC180/CC180W</div><div>105mm</div></div></div> <div><div>Quick Start Guide</div><div><p>Technical Support : For more detailed usage instructions, please download the CC180C180W user manual at https://www.hp-projector.com/support</p><p>© GT Technology (Changling) Limited The manufacturer under the license of HP Inc.</p><p>Email: support@hp-projector.com Web: www.hp-projector.com</p></div></div>	<div><div>Package Contents:</div><div><p>HP CC180 or HP CC180W *1 "Random Accessories" • Power Adapter *1 • Remote Control *1 • Remote Control Battery (AAA) *2 • Quick Start Guide *1 • Warranty Card *1 • Product Safety Information *1 • HP Projector Service Information Sheet *1</p></div></div> <div><div>Remote Control:</div><div><p>Power InfraRed HDMI USB DC-IN</p></div></div>	<div><div>Specifications:</div><div><p>Model: HP CC180C180W Resolution: 1280x720 Throw ratio: 1.35 Horizontal Keystone: 0% Focus Method: Remote Control Electric Motor Focus</p><p>Power Supply: Input: 100-240V~1.6A/50-60Hz Output: 50W (20W, 3.25A) DC-IN: USB-C</p></div></div> <div><div>Electrical Specifications:</div><div><p>Input Voltage: USB-C 15V, 3A Power Input: 100-240V~1.6A/50-60Hz Power Output: 50W (20W, 3.25A) DC-IN: 5.0V/3.0A, 12.0V/3.0A, 15.0V/3.0A, 45.0W</p><p>Other: Operating Environment: Working temperature: 0-35°C, altitude below 3000M Dimensions (HxWxD): 140*106*162mm Net weight (product): 0.86kg</p></div></div> <div><div>Start Using:</div><div><p>1. Power connection In addition to using the included HP power adapter, the CC180C180W also supports power supply via a 65W (20W, 3.25A) fast-charging power bank through the USB-C port. Friendly reminder: The CC180C180W requires a large amount of power. When using a power bank for power supply, please ensure that the power bank is dedicated for supplying power to the CC180C180W and not to other devices.</p><p>2. Power On/Off Power On: Press and hold the power button on the remote control or the projector for 1 second. Power Off: Press and hold the power button on the remote control or the projector for 1 second. The screen will display the power options. Click on the power off option to shut down the machine.</p></div></div>	<div><div>DUAL Screen Mirroring/Multi-Player Screen Mirroring</div><div><p>Enter the Android screen mirroring interface of CC180W, open the video player software on the device, click "D" and select HP CC180W for connection.</p><p>5. Wireless Screen Mirroring Display for HP CC180W The manufacturer under the license of HP Inc.</p><p>Email: support@hp-projector.com Web: www.hp-projector.com</p></div></div>
<div><div>PC</div><div><p>HP CC180 or HP CC180W Resolution: 1280x720 Throw ratio: 1.35 Horizontal Keystone: 0% Focus Method: Remote Control Electric Motor Focus</p><p>Power Supply: Input: 100-240V~1.6A/50-60Hz Output: 50W (20W, 3.25A) DC-IN: USB-C</p></div></div> <div><div>Technical Support : For more detailed usage instructions, please download the CC180C180W user manual at https://www.hp-projector.com/support<p>© GT Technology (Changling) Limited The manufacturer under the license of HP Inc.</p><p>Email: support@hp-projector.com Web: www.hp-projector.com</p></div></div>	<div><div>Product I/F:</div><div><p>Power Key</p><p>InfraRed 3.5mm HDMI USB DC-IN</p></div></div> <div><div>Specifications:</div><div><p>Model: HP CC180C180W Resolution: 1280x720 Throw ratio: 1.35 Horizontal Keystone: 0% Focus Method: Remote Control Electric Motor Focus</p><p>Power Supply: Input: 100-240V~1.6A/50-60Hz Output: 50W (20W, 3.25A) DC-IN: USB-C</p></div></div> <div><div>Electrical Specifications:</div><div><p>Input Voltage: USB-C 15V, 3A Power Input: 100-240V~1.6A/50-60Hz Power Output: 50W (20W, 3.25A) DC-IN: 5.0V/3.0A, 12.0V/3.0A, 15.0V/3.0A, 45.0W</p><p>Other: Operating Environment: Working temperature: 0-35°C, altitude below 3000M Dimensions (HxWxD): 140*106*162mm Net weight (product): 0.86kg</p></div></div> <div><div>Start Using:</div><div><p>1. Power connection In addition to using the included HP power adapter, the CC180C180W also supports power supply via a 65W (20W, 3.25A) fast-charging power bank through the USB-C port. Friendly reminder: The CC180C180W requires a large amount of power. When using a power bank for power supply, please ensure that the power bank is dedicated for supplying power to the CC180C180W and not to other devices.</p><p>2. Power On/Off Power On: Press and hold the power button on the remote control or the projector for 1 second. Power Off: Press and hold the power button on the remote control or the projector for 1 second. The screen will display the power options. Click on the power off option to shut down the machine.</p></div></div>	<div><div>3. Focus</div><div><p>To ensure a vivid and clear display during use, please adjust the focus before using. Use the Focus (F) and Focus (F) buttons on the remote control to adjust the focus. The screen will display a focus icon. Adjust it to achieve the optimal viewing experience according to personal preference.</p><p>Menu/Tab Tip: The recommended viewing distance for CC180C180W is 2.1 meters (6.9 ft), which refers to the distance from the projector to the screen.</p></div></div> <div><div>DUAL Screen Mirroring/Multi-Player Screen Mirroring</div><div><p>Enter the Android screen mirroring interface of CC180W, open the video player software on the device, click "D" and select HP CC180W for connection.</p><p>5. Wireless Screen Mirroring Display for HP CC180W The manufacturer under the license of HP Inc.</p><p>Email: support@hp-projector.com Web: www.hp-projector.com</p></div></div>	<div><div>DUAL Screen Mirroring/Multi-Player Screen Mirroring</div><div><p>Enter the Android screen mirroring interface of CC180W, open the video player software on the device, click "D" and select HP CC180W for connection.</p><p>5. Wireless Screen Mirroring Display for HP CC180W The manufacturer under the license of HP Inc.</p><p>Email: support@hp-projector.com Web: www.hp-projector.com</p></div></div>
<div><div>HP</div><div><p>Projector CC180/CC180W</p></div></div> <div><div>Quick Start Guide</div><div><p>Technical Support : For more detailed usage instructions, please download the CC180C180W user manual at https://www.hp-projector.com/support</p><p>© GT Technology (Changling) Limited The manufacturer under the license of HP Inc.</p><p>Email: support@hp-projector.com Web: www.hp-projector.com</p></div></div>	<div><div>Package Contents:</div><div><p>HP CC180 or HP CC180W *1 "Random Accessories" • Power Adapter *1 • Remote Control *1 • Remote Control Battery (AAA) *2 • Quick Start Guide *1 • Warranty Card *1 • Product Safety Information *1 • HP Projector Service Information Sheet *1</p></div></div> <div><div>Remote Control:</div><div><p>Power InfraRed HDMI USB DC-IN</p></div></div>	<div><div>Specifications:</div><div><p>Model: HP CC180C180W Resolution: 1280x720 Throw ratio: 1.35 Horizontal Keystone: 0% Focus Method: Remote Control Electric Motor Focus</p><p>Power Supply: Input: 100-240V~1.6A/50-60Hz Output: 50W (20W, 3.25A) DC-IN: USB-C</p></div></div> <div><div>Electrical Specifications:</div><div><p>Input Voltage: USB-C 15V, 3A Power Input: 100-240V~1.6A/50-60Hz Power Output: 50W (20W, 3.25A) DC-IN: 5.0V/3.0A, 12.0V/3.0A, 15.0V/3.0A, 45.0W</p><p>Other: Operating Environment: Working temperature: 0-35°C, altitude below 3000M Dimensions (HxWxD): 140*106*162mm Net weight (product): 0.86kg</p></div></div> <div><div>Start Using:</div><div><p>1. Power connection In addition to using the included HP power adapter, the CC180C180W also supports power supply via a 65W (20W, 3.25A) fast-charging power bank through the USB-C port. Friendly reminder: The CC180C180W requires a large amount of power. When using a power bank for power supply, please ensure that the power bank is dedicated for supplying power to the CC180C180W and not to other devices.</p><p>2. Power On/Off Power On: Press and hold the power button on the remote control or the projector for 1 second. Power Off: Press and hold the power button on the remote control or the projector for 1 second. The screen will display the power options. Click on the power off option to shut down the machine.</p></div></div>	<div><div>DUAL Screen Mirroring/Multi-Player Screen Mirroring</div><div><p>Enter the Android screen mirroring interface of CC180W, open the video player software on the device, click "D" and select HP CC180W for connection.</p><p>5. Wireless Screen Mirroring Display for HP CC180W The manufacturer under the license of HP Inc.</p><p>Email: support@hp-projector.com Web: www.hp-projector.com</p></div></div>
<div><div>HP</div><div><p>Projector CC180/CC180W</p></div></div> <div><div>Guide de démarrage rapide</div><div><p>Technical Support : For more detailed usage instructions, please download the CC180C180W user manual at https://www.hp-projector.com/support</p><p>© GT Technology (Changling) Limited The manufacturer under the license of HP Inc.</p><p>Email: support@hp-projector.com Web: www.hp-projector.com</p></div></div>	<div><div>Package Contents:</div><div><p>HP CC180 or HP CC180W *1 "Random Accessories" • Power Adapter *1 • Remote Control *1 • Remote Control Battery (AAA) *2 • Quick Start Guide *1 • Warranty Card *1 • Product Safety Information *1 • HP Projector Service Information Sheet *1</p></div></div> <div><div>Remote Control:</div><div><p>Power InfraRed HDMI USB DC-IN</p></div></div>	<div><div>Specifications:</div><div><p>Model: HP CC180C180W Resolution: 1280x720 Throw ratio: 1.35 Horizontal Keystone: 0% Focus Method: Remote Control Electric Motor Focus</p><p>Power Supply: Input: 100-240V~1.6A/50-60Hz Output: 50W (20W, 3.25A) DC-IN: USB-C</p></div></div> <div><div>Electrical Specifications:</div><div><p>Input Voltage: USB-C 15V, 3A Power Input: 100-240V~1.6A/50-60Hz Power Output: 50W (20W, 3.25A) DC-IN: 5.0V/3.0A, 12.0V/3.0A, 15.0V/3.0A, 45.0W</p><p>Other: Operating Environment: Working temperature: 0-35°C, altitude below 3000M Dimensions (HxWxD): 140*106*162mm Net weight (product): 0.86kg</p></div></div> <div><div>Start Using:</div><div><p>1. Power connection In addition to using the included HP power adapter, the CC180C180W also supports power supply via a 65W (20W, 3.25A) fast-charging power bank through the USB-C port. Friendly reminder: The CC180C180W requires a large amount of power. When using a power bank for power supply, please ensure that the power bank is dedicated for supplying power to the CC180C180W and not to other devices.</p><p>2. Power On/Off Power On: Press and hold the power button on the remote control or the projector for 1 second. Power Off: Press and hold the power button on the remote control or the projector for 1 second. The screen will display the power options. Click on the power off option to shut down the machine.</p></div></div>	<div><div>DUAL Screen Mirroring/Multi-Player Screen Mirroring</div><div><p>Enter the Android screen mirroring interface of CC180W, open the video player software on the device, click "D" and select HP CC180W for connection.</p><p>5. Wireless Screen Mirroring Display for HP CC180W The manufacturer under the license of HP Inc.</p><p>Email: support@hp-projector.com Web: www.hp-projector.com</p></div></div>
<div><div>HP</div><div><p>Projector CC180/CC180W</p></div></div> <div><div>GUIDA RAPIDA</div><div><p>Technical Support : For more detailed usage instructions, please download the CC180C180W user manual at https://www.hp-projector.com/support</p><p>© GT Technology (Changling) Limited The manufacturer under the license of HP Inc.</p><p>Email: support@hp-projector.com Web: www.hp-projector.com</p></div></div>	<div><div>Package Contents:</div><div><p>HP CC180 or HP CC180W *1 "Random Accessories" • Power Adapter *1 • Remote Control *1 • Remote Control Battery (AAA) *2 • Quick Start Guide *1 • Warranty Card *1 • Product Safety Information *1 • HP Projector Service Information Sheet *1</p></div></div> <div><div>Remote Control:</div><div><p>Power InfraRed HDMI USB DC-IN</p></div></div>	<div><div>Specifications:</div><div><p>Model: HP CC180C180W Resolution: 1280x720 Throw ratio: 1.35 Horizontal Keystone: 0% Focus Method: Remote Control Electric Motor Focus</p><p>Power Supply: Input: 100-240V~1.6A/50-60Hz Output: 50W (20W, 3.25A) DC-IN: USB-C</p></div></div> <div><div>Electrical Specifications:</div><div><p>Input Voltage: USB-C 15V, 3A Power Input: 100-240V~1.6A/50-60Hz Power Output: 50W (20W, 3.25A) DC-IN: 5.0V/3.0A, 12.0V/3.0A, 15.0V/3.0A, 45.0W</p><p>Other: Operating Environment: Working temperature: 0-35°C, altitude below 3000M Dimensions (HxWxD): 140*106*162mm Net weight (product): 0.86kg</p></div></div> <div><div>Start Using:</div><div><p>1. Power connection In addition to using the included HP power adapter, the CC180C180W also supports power supply via a 65W (20W, 3.25A) fast-charging power bank through the USB-C port. Friendly reminder: The CC180C180W requires a large amount of power. When using a power bank for power supply, please ensure that the power bank is dedicated for supplying power to the CC180C180W and not to other devices.</p><p>2. Power On/Off Power On: Press and hold the power button on the remote control or the projector for 1 second. Power Off: Press and hold the power button on the remote control or the projector for 1 second. The screen will display the power options. Click on the power off option to shut down the machine.</p></div></div>	<div><div>DUAL Screen Mirroring/Multi-Player Screen Mirroring</div><div><p>Enter the Android screen mirroring interface of CC180W, open the video player software on the device, click "D" and select HP CC180W for connection.</p><p>5. Wireless Screen Mirroring Display for HP CC180W The manufacturer under the license of HP Inc.</p><p>Email: support@hp-projector.com Web: www.hp-projector.com</p></div></div>

<div><div>Projector CC180/CC180W</div><div>Guía de Inicio Rápido</div><div><p>Technical Support: Para obtener instrucciones de uso más detalladas, descargue el Manual de Usuario de HP CC180C180W en https://www.hp-projector.com/support</p><p>© GT Technology (Changling) Limited The manufacturer under the license of HP Inc.</p><p>Email: support@hp-projector.com Web: www.hp-projector.com</p></div></div>	<div><div>Interfaz de producto:</div><div><p>InfraRed 3.5mm HDMI USB DC-IN</p></div></div>	<div><div>Especificaciones:</div><div><p>Modelo: HP CC180C180W Resolución: 1280x720 Relación de proyección: 1.35 Corrección horizontal de inclinación: 0% Método de enfoque: Enfoque motorizado Modo de control remoto: USB-C</p><p>Alimentación eléctrica: Voltaje de salida: USB-C 15V, 3A Potencia de entrada: 100-240V~1.6A/50-60Hz Potencia de salida: 50W (20W, 3.25A) DC-IN: 5.0V/3.0A, 12.0V/3.0A, 15.0V/3.0A, 45.0W</p><p>Otros: Entorno de funcionamiento: Temperatura de trabajo: 0-35°C, altitud inferior a 3000m Dimensiones (HxWxD): 140*106*162mm Peso neto del producto: 0.86 kg</p></div></div>	<div><div>Comenzar a usar:</div><div><p>1. Conexión de alimentación Además de utilizar el adaptador de corriente incluido de HP CC180C180W, también admite la alimentación a través de un banco de energía compatible de 65W (20W, 3.25A) a través del puerto USB-C.</p><p>2. Encendido/Apagado Encendido: Mantenga presionado el botón de encendido en el control remoto o el proyector durante 1 segundo para encender el proyector. Después, mantenga presionado el botón de encendido en el control remoto o el proyector durante 1 segundo. La pantalla mostrará las opciones de apagado. Haga clic en la opción de apagado para apagar la pantalla.</p><p>3. Enfoque Para asegurar una imagen nítida y clara durante el uso, ajuste el enfoque antes de utilizarlo. Utilice los botones [Enfoque (+)] y [Enfoque (-)] del control remoto para ajustar el enfoque. La pantalla mostrará un icono de enfoque. Ajuste el enfoque a su preferencia para obtener la mejor experiencia de visualización.</p><p>Consejo: Utilice la distancia recomendada de visualización para CC180C180W de 2.1 metros (6.9 ft), que se refiere a la distancia desde el proyector hasta la pantalla.</p><p>4. Reproducción de imágenes Puede conectar CC180 al dispositivo de entrada de medios HDMI para proyectar fuentes externas como teléfonos móviles, tabletas, computadora portátil, etc. Si desea ver también videos en pantalla, mantenga o toque el botón de reproducción de videos en la memoria o en un dispositivo USB.</p><p>5. Comparar pantalla inalámbricamente todo para HP CC180W El CC180W admite tres métodos de comparación pantalla de forma inalámbrica: DUAL, dispositivos iOS y dispositivos Android. Antes de conectar a compatible pantalla, asegure de que el CC180W y el dispositivo deseado (teléfono/</p></div></div>
<div><div>Projector CC180C180W</div><div>Rychlý průvodce</div><div><p>Technical Support: Chcete-li získat podrobnější pokyny k použití, stáhněte si uživatelský manuál HP CC180C180W na https://www.hp-projector.com/support</p><p>© GT Technology (Changling) Limited The manufacturer under the license of HP Inc.</p><p>Email: support@hp-projector.com Web: www.hp-projector.com</p></div></div>	<div><div>Produktové rozhraní:</div><div><p>InfraRed 3.5mm HDMI USB DC-IN</p></div></div>	<div><div>Specifikace:</div><div><p>Model: HP CC180C180W Rozlišení: 1280x720 Vztah projekce: 1,35 Korekce horizontálního sklonu: 0% Metoda zaostření: Elektrické motorové zaostření Metoda ovládacího zařízení: USB-C</p><p>Elektrické specifikace: Napětí výstupu: USB-C 15V, 3A Vstupní napětí: 100-240V~1.6A/50-60Hz Výstupní napětí: 50W (20W, 3.25A) DC-IN: 5.0V/3.0A, 12.0V/3.0A, 15.0V/3.0A, 45.0W</p><p>Ostatné: Provozní prostředí: Pracovní teplota: 0-35°C, výšková nadmořská výška: pod 3000m Rozměry (HxWxD): 140*106*162mm Hmotnost výrobku: 0,86 kg</p></div></div>	<div><div>Začítání používání:</div><div><p>1. Napájení Kromě použití přiložené adaptéru HP pro napájení HP CC180C180W také můžete použít rychlonabíječku s výkonem 65W (20W, 3.25A) přes port USB-C.</p><p>2. Zapnutí/Vypnutí Zapnutí: Stiskněte tlačítko napájení na ovládacím zařízení nebo na projektoru po dobu 1 sekundy, aby se zařízení zapnulo. Vypnutí: Stiskněte tlačítko napájení na ovládacím zařízení nebo na projektoru po dobu 1 sekundy. Na obrazovce se zobrazí nabídka s možností nastavení. Klikněte na možnost "Vypnutí".</p><p>3. Zaostření Abyste zajistili ostrou a živou obrazovku, proveďte před použitím nastavení zaostření. Použijte tlačítka [Zaostření (+)] a [Zaostření (-)] na ovládacím</p></div></div>
<div><div>Projector CC180/CC180W</div><div>ウィクスタートガイド</div><div><p>Technical Support: 詳細な使用法の手引きを得るには、HP CC180C180Wのユーザーマニュアルを https://www.hp-projector.com/support からダウンロードしてください。</p><p>© GT Technology (Changling) Limited The manufacturer under the license of HP Inc.</p><p>Email: support@hp-projector.com Web: www.hp-projector.com</p></div></div>	<div><div>製品のI/F:</div><div><p>電源ボタン 赤外線 3.5mm HDMI USB DC-IN</p></div></div>	<div><div>仕様:</div><div><p>モデル: HP CC180C180W 解像度: 1280x720 投影比: 1.35 水平方向の歪み補正: 0% フォーカス調整方法: リモートコントロールフォーカス USB-C</p><p>電源仕様: 2. 電源ON/OFF 電源ON: リモコンまたはプロジェクトリモコンの電源ボタンを1秒間押し続けると、電源がONになります。 電源OFF: リモコンまたはプロジェクトリモコンの電源ボタンを1秒間押し続けると、電源がOFFになります。 電源ON/OFF: リモコンまたはプロジェクトリモコンの電源ボタンを1秒間押し続けると、電源がON/OFFになります。</p><p>その他: 動作環境: 動作温度: 0°C ~ 35°C、標高: 3000m以下 寸法 (HxWxD): 140*106*162mm 製品重量: 0.86kg</p></div></div>	<div><div>使用を開始する:</div><div><p>1. 電源接続 HP CC180C180Wは、付属のHP電源アダプター（出力: USB-C 15V, 3A）または65W（20W, 3.25A）の急速充電ポートをUSB-Cポートに接続して使用することができます。</p><p>2. 電源ON/OFF 電源ON: リモコンまたはプロジェクトリモコンの電源ボタンを1秒間押し続けると、電源がONになります。 電源OFF: リモコンまたはプロジェクトリモコンの電源ボタンを1秒間押し続けると、電源がOFFになります。</p><p>3. フォーカス調整 Sharpness: Sharpness (Sharpness) を調整して、映像を鮮明にします。</p><p>4. 映像の拡大/縮小 Zoom In/Zoom Out: Zoom In/Zoom Out ボタンを使用して、映像を拡大または縮小します。</p><p>5. フォーカス調整 Focus: Focus (Focus) を調整して、映像を鮮明にします。</p><p>6. スクリーンミラーリング/スクリーンキャスト スクリーンミラーリング/スクリーンキャスト: スクリーンミラーリング/スクリーンキャスト機能を使用して、他のデバイスと映像を共有します。</p></div></div>
<div><div>Projector CC180C180W</div><div>دليل التشغيل السريع</div><div><p>Technical Support: للحصول على تعليمات الاستخدام التفصيلية، يرجى تنزيل دليل المستخدم HP CC180C180W من https://www.hp-projector.com/support</p><p>© GT Technology (Changling) Limited The manufacturer under the license of HP Inc.</p><p>Email: support@hp-projector.com Web: www.hp-projector.com</p></div></div>	<div><div>Interface produit:</div><div><p>InfraRed 3.5mm HDMI USB DC-IN</p></div></div>	<div><div>Spécifications:</div><div><p>Modèle: HP CC180C180W Résolution: 1280x720 Rapport de projection: 1,35 Correction horizontale du trapezoïde: 0% Méthode de mise au point: Mise au point électrique à distance Méthode de contrôle à distance: USB-C</p><p>Spécifications électriques: Tension d'entrée: USB-C 15V, 3A Puissance d'entrée: 100-240V~1.6A/50-60Hz Puissance de sortie: 50W (20W, 3.25A) DC-IN: 5.0V/3.0A, 12.0V/3.0A, 15.0V/3.0A, 45.0W</p><p>Autres: Environnement de fonctionnement: Température de travail: 0-35°C, altitude inférieure à 3000m Dimensions (HxWxD): 140*106*162mm Poids net du produit: 0,86 kg</p></div></div>	<div><div>Commencer à utiliser:</div><div><p>1. Connexion électrique En plus d'utiliser l'adaptateur secteur HP inclus, le CC180C180W prend également en charge l'alimentation via une batterie externe de charge rapide compatible de 65W (20W, 3.25A) à travers le port USB-C.</p><p>2. Mise en marche/arrêt Mise en marche: Appuyez et maintenez enfoncé le bouton d'alimentation sur le télécommande ou le projecteur pendant 1 seconde pour allumer le projecteur.</p><p>3. Mise en marche/arrêt Arrêt: Appuyez et maintenez enfoncé le bouton d'alimentation sur le télécommande ou le projecteur pendant 1 seconde. L'écran affichera les options d'arrêt. Cliquez sur l'option d'arrêt pour éteindre l'appareil.</p><p>4. Mise au point Pour assurer une image nette et claire lors de la projection, veuillez régler la mise au point avant de commencer. Utilisez les boutons [Mise au point (+)] et [Mise au point (-)] du télécommande pour ajuster la mise au point. L'écran affichera un icône de mise au point. Ajustez-le à votre préférence pour obtenir la meilleure qualité d'affichage selon vos préférences.</p><p>5. Mise en marche/arrêt Arrêt: Appuyez et maintenez enfoncé le bouton d'alimentation sur le télécommande ou le projecteur pendant 1 seconde pour éteindre l'appareil.</p><p>6. Mise en marche/arrêt Arrêt: Appuyez et maintenez enfoncé le bouton d'alimentation sur le télécommande ou le projecteur pendant 1 seconde pour éteindre l'appareil.</p></div></div>
<div><div>Projector CC180/CC180W</div><div>GUIDA RAPIDA</div><div><p>Technical Support: For more detailed usage instructions, please download the CC180C180W user manual at https://www.hp-projector.com/support</p><p>© GT Technology (Changling) Limited The manufacturer under the license of HP Inc.</p><p>Email: support@hp-projector.com Web: www.hp-projector.com</p></div></div>	<div><div>Interfaccia prodotto:</div><div><p>InfraRed 3.5mm HDMI USB DC-IN</p></div></div>	<div><div>Specifiche:</div><div><p>Modello: HP CC180C180W Risoluzione: 1280x720 Rapporto di proiezione: 1,35 Correzione trapezoidale: 0% Metodo di messa a fuoco: Regolazione a distanza con telecomando USB-C</p><p>Specifiche elettriche: Tensione di ingresso: USB-C 15V, 3A Potenza di ingresso: 100-240V~1.6A/50-60Hz Potenza di uscita: 50W (20W, 3.25A) DC-IN: 5.0V/3.0A, 12.0V/3.0A, 15.0V/3.0A, 45.0W</p><p>Altro: Ambiente operativo: Temperatura di lavoro: 0-35°C, altitudine inferiore a 3000m Dimensioni (HxWxD): 140*106*162mm Peso netto del prodotto: 0,86 kg</p></div></div>	<div><div>Inizio l'uso:</div><div><p>1. Collegamento di alimentazione Oltre all'utilizzo dell'adattatore HP incluso, il CC180C180W supporta anche l'alimentazione tramite una power bank di carica rapida da 65W (20W, 3.25A) attraverso il port USB-C.</p><p>2. Accensione/Arresto Accensione: Premere e tenere premuto il pulsante di accensione sulla telecomando o sul proiettore per 1 secondo. Lo schermo visualizzerà le opzioni di spegnimento. Fare clic sull'opzione di spegnimento per spegnere l'apparecchio.</p><p>3. Accensione/Arresto Arresto: Premere e tenere premuto il pulsante di accensione sulla telecomando o sul proiettore per 1 secondo. Lo schermo visualizzerà le opzioni di spegnimento. Fare clic sull'opzione di spegnimento per spegnere l'apparecchio.</p><p>4. Regolazione dello zoom Per garantire un'immagine nitida e chiara durante l'uso, è importante regolare la messa a fuoco prima di iniziare la proiezione. Utilizzare i pulsanti [Messa a fuoco (+)] e [Messa a fuoco (-)] sul telecomando per regolare la messa a fuoco. Lo schermo visualizzerà un'icona di messa a fuoco. Regolare in base alle proprie preferenze per ottenere la migliore esperienza di visione in base alle preferenze personali.</p><p>5. Suggerimento: La distanza di visione consigliata per CC180C180W è di 2.1 metri (6.9 ft), che si riferisce alla distanza dal proiettore allo schermo.</p><p>6. Riproduzione di immagini Puoi collegare il CC180 al dispositivo di ingresso di media HDMI per visualizzare fonti esterne come: telefoni cellulari, tablet, computer, laptop, ecc. Se desideri guardare. Puoi anche visualizzare direttamente immagini o video memorizzati nella memoria o su una chiavetta USB.</p><p>7. Confronto schermo wireless tutto per CC180W Il CC180W supporta modalità di condivisione wireless dello schermo: DUAL, dispositivi iOS e dispositivi Android. Prima di connettersi a</p></div></div>

料号	82-304-10000-101	品名	CC180 QSG
刀模料号	82-000-00008-000	设计制作者	李昆昇
类别	<input type="checkbox"/> 彩盒 <input type="checkbox"/> 外箱 <input type="checkbox"/> 内箱 <input checked="" type="checkbox"/> 说明书 <input type="checkbox"/> Label <input type="checkbox"/> 机身LOGO <input type="checkbox"/> 其他	日期	2023.8.22
材质	128g哑粉纸	版本	2.0
制法	<input type="checkbox"/> 模具雕刻 <input type="checkbox"/> 铜板印刷 <input checked="" type="checkbox"/> 平板印刷 <input type="checkbox"/> POLY <input type="checkbox"/> 压凸 <input type="checkbox"/> 压凹 <input type="checkbox"/> 其他		
印色	<input type="checkbox"/> 单色(特别色) <input checked="" type="checkbox"/> 单色(黑色) <input type="checkbox"/> 三色 <input type="checkbox"/> 四色 <input type="checkbox"/> 五色 <input type="checkbox"/> 其他		
尺寸	<input type="checkbox"/> A4 <input type="checkbox"/> A5 <input type="checkbox"/> A6 <input type="checkbox"/> 3"x3"(76x76mm) <input type="checkbox"/> 5"x3"(126x76mm) <input type="checkbox"/> 6"x4"(152x102mm) <input checked="" type="checkbox"/> 其他		