



正面

Bobtot Sound Air2 Portable Wireless Speaker **Bobtot Sound Air2** Bobtot Sound Air2 Bobtot Sound Air2 Bobtot Sound Air2 **Bobtot Sound Air2** Portable Wireless Speaker Warning How to Set TWS Sync Mode? Resetting your device interference to radio communications. However, there is no success of our business. To help us achieve this goal Connect your device with the speaker via 3.5mm audio cable Do NOT drop, hit or shake the device. Press and hold the 🔘 8s until the power off. Then long press guarantee that interference will not occur in a particular we have put together the following customer care guide *When using the audio input mode, control audio playback via the Do NOT disassemble, repair or modify the speaker. the \bigcirc to reset. installation. If this equipment does cause harmful interference connected device. Do NOT use cleaning products that contain benzene, solvents or to radio or television reception, which can be determined by *When aux cable is plugged, play mode will automatically switch to We understand that our customers' time is valuable, so we turning the equipment off and on, the user is encouraged to AUDIO in mode will respond to any inquiries within 24 hours. Do NOT expose the speaker to excessive heat or direct sunlight for try to correct the interference by one or more of the following **Troubleshooting:** Do NOT store the device in a place with high humidity or dust. - Reorient or relocate the receiving antenna. 1. Automatic shut down: when the battery power is low, the We know that our customers are the heart of our business Do NOT use the speaker near a microwave oven or wireless $\ensuremath{\mathsf{LAN}}$ Step1, Long press the power button (5) about 2s speakers - Increase the separation between the equipment and receiver. speaker will turn off automatically, please charge it. so we value your feedback. We encourage you to share - Connect the equipment into an outlet on a circuit different 2. Unable to play music: Reset the speaker and connect the bt to turn the first speaker on. your thoughts and ideas with us. again. If the music file store in the USB or TF card, check if the **FCC** Requirement from that to which the receiver is connected Step 2, Turn on the BT searching mode on your device, search "Bobtot Sound Air 2" and connected right connect mode, double press the 🕟 to choose the - Consult the dealer or an experienced radio/TV techniciar Any changes or modifications not expressly approved by the If our customers encounter any issues, we will try our best Step 3, Long press the power button (S) about 2s to turn the party responsible for compliance could void the user's authority 3. Unable to connect to the computer: Check if the computer has The device has been evaluated to meet general RF exposure to find a guick and efficient solution that meets your needs. to operate the equipment requirement. The device can be used in portable exposure Step 4, Quickly triple-click the light button of either speaker. bt function. If not, please connect the speaker and computer by This device complies with Part 15 of the FCC Rules. Operation Support capacity: max file size 64Gb You can hear a indicates sound, which means connect the AUX cable and choose the right model by pressing the Our customers are our first priority, and we are committed is subject to the following two conditions Support files: mp3.flac.way. successfully 4. The button does not respond or the function is disordered: to providing the highest quality service. If you have any Play in order: music will play in the download/copy order. try again after reset. (1) this device may not cause harmful interference, and (2) this questions or concerns, please don't hesitate to reach out Automatically play: when the TF card/ USB drive is inserted, the 5. Stuck in an abnormal situation: press the power button for 8 device must accept any interference received, including to us.We will be happy to assist you: play mode will automatically switch to TF mode/ USB mode. seconds to reset. interference that may cause undesired operation. Call or Message: +1 888 572 1718 (Normally the speaker would play the last inserted media.) *While stereo pairing, the speaker will reconnect with the device if Need help? Note: This equipment has been tested and found to comply with Email: service@bobtot.net they used to be connected. Triple press button to the limits for a Class B digital device, pursuant to Part 15 of the disconnect the stereo pairing. FCC Rules. These limits are designed to provide reasonable At our company, we strive to provide exceptional custome protection agains tharmful interference in a residential installation *When you are listening to the music from one speaker and want to bobtot.net care to every one of our clients. We believe that building This equipment generates, uses, and can radiate radio frequency set up the stereo pairing , triple-click the button, 2023 BORTOT//Features and specifications are strong relationships with our customers is essential to the energy, and if not installed and used in accordance with the would enter into stereo pairing mode. subject to change and or improvement without notice instructions, may cause harmful 3 25 5 6

ET22A 说明书

成品尺寸: 122.5x70mm

材质工艺: 128g双铜,风琴折

深圳市恩科电子有限公司 SHENZHEN CITY ENKOR ELECTRONICS LTD

| THE PROPERTY OF THE PROPERTY O | | | | | | | | | | | | |
|--|-----|------|------|------|--|------|----------|------|----------|----------|-----|--------------|
| 设计绘图 | 技术员 | 品质经理 | 业务经理 | 产品经理 | | 研发经理 | 客户品牌 | 内部型号 | 零件名称 | 材料 | 単 位 | 版本 |
| | | | | | | | | | | | MM | V1. 0 |
| 料号 | | | | | | | 研发部 | PMC | 采购部 | 品管部 | 木箱部 | 生产部 |
| BZ0-ET22ASMSB03 | | | | | | 部 门 | √ | | √ | √ | | \checkmark |