


WS20012-B

尺寸: 62*105mm
材质: 105g双铜

105.0 mm

62.0 mm


Multi-Function Makeup Mirror-Wireless Charging



WS20012-B

Instruction Manual

Product schematic diagram:



- ① Multi-function Beauty Mirror
- ② Light touch button
- ③ Mobile phone wireless charging mobile phone holder
- ④ 10 x magnetic magnifying glass
- ⑤ TYPE-C charging Jack

- 1 -

Packing list:

- Multi-function makeup mirror-wireless charging x1
- 10 x magnetic magnifying glass x1
- Type-c charging cable x1
- Instructions x1

Product parameters:

Product name: Multi-functional cosmetic mirror-wireless charging
Input: DC 5V/2A
Wireless charge output: DC 5V/1A
Cosmetic Mirror Battery: 4000mAh
Size: 350*220*100mm
Weight: 755g

Wireless charging method:

- ① This product has 1 white LED indicator. When the power comes on, the LED lights flicker and then go out.
- ② After electrifying, the mobile device for wireless charging shall be placed in the wireless charging area. During the charging process, the LED indicator light is always on.
- ③ The phone will start charging automatically.

Attention: When using the wireless charging function, if the LED indicator flashes, the device does not support wireless charging or there is foreign body interference between the device and the wireless charging surface, or overheating.

Light usage of cosmetic mirror:

- ① This product has a touch button, press it lightly and the light turns on.
- ② Do not let go of the long touch button, light with the length of time, from dark to light, adjust to their own appropriate light, let go of fingers, makeup mirror light will not change.

- 2 -

105.0 mm

62.0 mm

- ③ Press the touch button again and the light goes off.
- ④ 10 X magnetic magnifying glass in use, please keep the distance between the eyes within 15 cm. Too far, distance, will produce vertigo, belong to the normal physical phenomenon.
- ⑤ When charging the mirror, the red light flashes. When the mirror is fully charged, the red light is on.

Attention: In the use of the process, LED brightness will decrease with the decrease in voltage. A fully charged battery can be used for LED lighting for up to 2 hours without a power supply. Therefore, in the cosmetic mirror LED lighting use, the best connection on the power supply.

Points to note:

- Before using this product, please be sure to read the product manual carefully, and according to the instructions of the use of the correct operation.
- Do not disassemble the device by yourself. This product is not equipped with any self-disassembly/maintenance parts.
- 10 x magnetic magnifying glass in use, placed in the makeup mirror back recess (indicated picture ●). After use, please take down the magnifying glass to prevent the mirror from falling down and damaging.
- The wireless charger has multiple protection functions. When the charging is abnormal, check the status of the mobile phone and place the mobile phone again after handling.
- In order to give full play to the best charging performance, the use of the company's Charger is recommended.
- If the mobile phone is not placed correctly, it may lead to the mobile phone can not be charged properly.
- Don't put anything between the phone and the charger.

Attention: Placing a magnetic stand, protective case, metal or room card, bus card, bank card, passport or other items with an NFC or RFID chip between the phone and the charger may degrade the Charger's performance, cause fever and even damage to articles.

- Please stop using the product immediately if there is any abnormal fever.

- 3 -

Security information:

Please read and follow the following notes before using and operating the device.

- In medical and health care establishments where the use of this product is expressly prohibited, please comply with the regulations of the premises and shut down the equipment.
- When using this device, keep at least 30 cm away from the implanted medical device (such as pacemaker, cochlear implant, etc.).
- Please keep the equipment dry. Please do not use the equipment in the dusty, damp place, in order to avoid causing equipment failure.
- Please do not use this equipment in the thunderstorm day, lest cause the equipment failure or the electric shock danger.
- Use the device at a temperature range of -10 °C to 40 °C and store it at a temperature range of -40 °C to 70 °C to avoid device faults.
- Do not expose your equipment to high temperatures or heat, such as sunlight, heaters, microwaves, ovens, or water heaters.
- Don't overcharge the product. The temperature may rise when the product is overused. When full, please remove. It is forbidden to charge the product for more than 7 hours at a time.
- Do not use this product beyond its maximum output parameters. Overload output may result in a risk of fire or injury.
- Please treat the equipment according to the local regulations. Do not treat the equipment as domestic waste. Please comply with the local ordinance on the handling of this equipment and its accessories and support the recall action.
- Do not allow children or pets to swallow equipment as this may cause harm to them.
- This equipment and its accessories may contain some small parts, please put the equipment and its accessories in a place out of reach of children. Children may inadvertently damage the device and its accessories, or swallow small parts causing asphyxiation or other hazards.
- Please do not drop, squeeze or puncture equipment, so as to avoid causing equipment failure.
- Use of unauthorized or incompatible power supplies, chargers, or batteries can cause fire or other hazards.

- 4 -

Warranty card

Sincerely thank you for buying and using our products!
This product has passed the strict quality inspection. According to the warranty card, we will be responsible for the free maintenance during the warranty period if the hardware malfunction is caused by the quality problem of the product. For more information, please consult US, thank you!

Warranty description (warranty scope is limited to the main unit only, not including accessories and freebies)

1. Customers who purchase our series products will enjoy after-sales service according to the relevant regulations of the state.
2. If there is a quality issue with the product you purchase. It can be replaced within 15 days without man-made damage, disassembly and repair, and packing intact.
3. Purchase this product to enjoy one year free maintenance service.
4. The warranty shall expire and maintenance services shall be provided free of charge, provided that the corresponding accessories and manual repair fees shall be charged for the maintenance:

- ① The damage caused by human factors, including abnormal working conditions, not according to the use of the manual, caused by damage, etc.
- ② The user disassembles the machine, repairs and refits by himself, and is maintained by a maintenance department of the company or by an unauthorized organization.
- ③ Damaged by force majeure.
- ④ Without the product warranty card and valid purchase certificate, and unable to verify the user's information files.
- ⑤ The Bar Code and the date of manufacture of the goods were torn (outer packing) .
- ⑥ Past expiration date.

Form filling	
User Name	Date Of Purchase:
Contact Number:	Sales Unit:
Model:	Sales Address:
Client Address:	

*This warranty card is properly kept by the customer as the warranty certificate of the product without any alteration.

- 5 -

FCC COMPLIANCE STATEMENT:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement. The device can be used in mobile(min20cm) exposure condition.

红色线和字都不印刷
黑色

背面