FSC Certified Cork Fast Wireless Charging Mouse Pad

Instruction Manual 7143-45



Functions:

- 1 LED Indicator
- 2. Type-C Input Port
- 3. Wireless Charging Surface
- 4 Mouse Pad

What's included:

- 1 x Wireless Charging Pad
- 1 x USB to Type-C Cable 1 x Instruction Manual

Tech Specifications

- Input: 5V/2A, 9V/1.5A
- · Wireless Charging Pad Output: 5W/7.5W/10W

Instructions

- 1 Wireless Charging Mobile phones and other electronic devices:
- . Insert the USB-C output of charging cable (included) into the input port of wireless charging pad and connect the USB output of the cable to a certified wall adapter (not included) or USB-A output of lanton
- . LED indicator (1) will flash WHITE once when the device is in wireless charging standby
- Place the wireless charging supported. mobile device on the wireless charging surface(3) besure to center your device on the wireless charging symbol
- . LED will allow WHITE when device is charging
- . Phone will begin to charge automatically. Once fully charged, remove your device
- from the charging pad and disconnect the charging cable.
- ** Note: When wireless charging, be sure there is no object between the device and charging surface that would interfering with the charging process.

SAFETY PRECAUTIONS:

- WARNING-When using this product basic precautions should always be followed:
- 1 Read all the instructions before use 2. Never store or use this product in temperatures below 32°E(0°C) or above
- 115°F(45°C) 3 Do not overcharge your phone. The unit may become hot under excessive use Remove your phone once it is fully charged. Never charge your phone for more than 7 hours at a time
- 4. To reduce the risk of injury, close supervision is required when the product is used near children
- Do not expose the device to moisture. 6 Do not use the device in excess of its
- output rating. Overload outputs above the rating may result in a risk of fire or injury
- 7. Do not use the device if damaged or modified
- 8 Do not disassemble the device For repairs seek a qualified service professional, incorrect reassembly may result in a risk of fire or injury
- 9. Do not expose the device to fire or excessive temperature. Exposure to fire or temperatures above 104°F may cause explosion
- Ensure that qualified service professionals. use only identical replacement parts to ensure product safety.
- 11. Attachments on the back of your phone can impede the effectiveness of the wireless charger, and lead to overheating Please remove any attachments from the phone before charging on this device.

FCC Statement

- This device complies with Part 15 of the FCC Rules Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference
- (2) This device must accept any interference received including interference that may cause undesired operation
- Warning Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment





MIX Packaging from responsible sources

FSC® C161647





FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technic ian for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.