

# ZIZO

# Amplify

PORTABLE LED BLUETOOTH® | TWS SPEAKER

QUICK START GUIDE

## PACKAGE CONTENTS

### In The Box


1 x Amplify Speaker

1 x USB Charging Cable

1 x 3.5mm Audio Cable

1 x Quick Start Guide

1 x Warranty Card



## GETTING STARTED

Ensure the speaker is fully charged before using for the first time.

### Charging

Plug the charging cable into the speaker's charging port with the included cable.

The device will automatically begin charging once the adapter is connected to the unit. The unit will also power on when connected to a power source even if the battery power is low. When the battery is full, the charging indicator light on the front panel will turn off.

The device takes approximately 5 hours to fully charge. With standard usage, a fully charged battery can play for about 2 hours.

### Power ON / OFF

1. To turn on speakers, press the power button on.
2. To turn off, press the power button off.

### Bluetooth® Pairing

1. When using the Bluetooth, please tap settings, then open "Bluetooth".
2. Scan from your phone, tablet, notebook for AMPLIFY, and pair the device to the speaker, turn on your music in the device, then you can listen audio files through the speaker.
3. Unpair from speaker when finished listening.

## USING YOUR DEVICE

### TWS:

Turn on Bluetooth® mode, then press and hold the **TWS** button to enter TWS function. Once confirmed, link two **ZIZO Ampify** speakers together with the same bluetooth device. Press and hold the **TWS** button again to cancel TWS function.

### FM Function:

1. Choose "Mode" to switch to FM radio.
2. Choose "PLAY/PAUSE" for automatic searching and saving.
3. Choose "PREV" and "NEXT" to switch channels.

### Microphone:

1. Plug in your microphone into the microphone jack on unit main control panel.
2. Use the "ECHO" knob to control microphone echo.

### AUX:

1. Press the audio input on unit on main panel on the top.
2. Insert the Aux cable plug into the Aux input, then connect with your device.
3. Pull out the cable when finished listening.

# ZIZO

ZIZOWIRELESS.COM



@ZIZOWIRELESS

## ADDITIONAL FEATURES

**TWS Technology:** Wirelessly connect two ZIZO AMPLIFY together, and play the left and right music channels with these two speakers to double your audio output.

**Water Resistant:** IPX5 splash-proof, rainproof, perfect for outdoor activities.

**Smart Device Compatible:** With A2DP Bluetooth, wireless stream music from any Bluetooth-enabled device such as your mobile phone, notebook, iPhone or iPad.

**AUX Port:** Connect to audio from a smartphone, tablet, media player, laptop, PC, or other audio source with a 3.5mm output.

**USB Port:** Supports USB flash drives and plays MP3 and WAV formats (FAT32).

**Micro SD Card Slot:** Supports up to 32GB USB Micro SD card and plays MP3 and WAV formats (FAT32).

**Headphone Input:** 3.5mm interface

**Charge Protection:** Equipped with charge and discharge protection for a safe music experience.

**LED Lights:** Light up the party with its color-changing LED lights.

**Built-in Handle:** Designed for maximum portability.

## TECHNICAL SPECIFICATIONS

### SPECIFICATIONS

#### Model:SPK-AMPFY

Output Power: Maximum 20 W

Input Power: DC 5V

Speaker Size: 6.5 inches

Dimensions: 9.45 x 5.51 x 12.6 inches

Frequency Response: 80Hz-20kHz

Transmission Distance: Up to 35 ft.

Battery Capacity: 2400 mAh/3.7

Charging Time: 5 Hours

Playback Time: Up to 2 Hours

Weight: 5.07 lbs

#### Important Safeguards:

1. Do not allow water to spill onto the surface or into the product.
2. Children should be supervised while operating device.
3. If the product surface is damaged or if there is a mechanical or electrical malfunction, do not use the unit. Contact ZIZO customer support.
4. Do not shake the product.
5. Do not place product in water.
6. Do not place the product in direct heat. This unit is to be placed in a dry and ventilated place.
7. Do not place heavy objects on the unit.

## WARRANTY INFORMATION

At ZIZO, we are 100% committed to your satisfaction. We stand behind our products and offer a 1 year manufacturer warranty against defects in materials or workmanship of your new ZIZO speaker.

Should you find your item to be defective, simply visit [zizowireless.com/warranty](https://zizowireless.com/warranty) to submit a brief Warranty Service Request form. Warranty applies to products purchased from ZIZO Authorized resellers. International product registration is not available at this time. U.S. customers only.

## ZIZO CUSTOMER SERVICE

#### Email

[info@zizowireless.com](mailto:info@zizowireless.com)

#### Telephone

+1(909) 444-7992 (English)

#### Website

[zizowireless.com/support](https://zizowireless.com/support)



© 2022 ZIZO, All Rights Reserved. The Bluetooth wordmark and logos are registered trademarks owned by Bluetooth SIG, Inc. any use of such marks by Balaji Trading Inc. is under license. Other trademarks and trade names are those of their own respective owners.

Images on packaging used for illustration purposes. Actual product may vary due to continuous refinements.

# ZIZO

# Amplify

PORTABLE LED BLUETOOTH® | TWS SPEAKER

GUIDE DE DÉMARRAGE RAPIDE

## CONTENU DU COLIS

### Dans la boîte


1 x ZIZO Amplify Haut-parleurs

1 x Câble de chargement USB

1 x Câble audio de 3,5 mm

1 x Guide de démarrage rapide

1 x Carte de garantie



## COMMENCER

Assurez-vous que le haut-parleur est complètement chargé avant la première utilisation.

### Charge

Branchez le câble de charge dans la prise de charge 5V des haut-parleurs avec le câble inclus. L'appareil commencera automatiquement à se charger une fois l'adaptateur connecté à l'appareil. L'appareil s'allumera également lorsqu'il est connecté à une source d'alimentation, même si la puissance de la batterie est faible. Lorsque la batterie est pleine, le voyant de charge sur le panneau avant s'éteint.

L'appareil prend environ 5 heures pour se recharger complètement. Avec une utilisation standard, une batterie complètement chargée peut jouer pendant environ 2 heures.

### Éteindre / Allumer

1. Pour allumer les haut-parleurs, appuyez sur le bouton d'alimentation.
2. Pour éteindre, appuyez sur le bouton d'alimentation.

### Bluetooth® Appariement

1. Une fois allumé, appuyez sur Mode pour sélectionner Bluetooth®.
2. Accédez aux paramètres Bluetooth® de votre appareil.
3. Sélectionner "ZIZO ROAR Z7" dans la liste des appareils disponibles.

## UTILISER VOTRE APPAREIL

### TWS:

1. Allumez les deux enceintes du même modèle (AMPLIFY), appuyez et maintenez
2. Appuyez sur le clavier lecture/pause/TWS pendant quelques secondes et connectez les deux haut-parleurs.
3. Assemblez les haut-parleurs, activez le mode sans fil sur votre appareil (mobile), trouvez le forum que vous voulez poster est un appareil. Une fois les deux enceintes connectées, vous pouvez entendre les deux enceintes en même temps.s.

### Function FM:

1. Choisissez "Mode" pour passer à la radio FM.
2. Choisissez "PLAY/PAUSE" pour une recherche et une sauvegarde automatiques.
3. Choisissez "PREV" et "NEXT" pour changer de chaîne.

### Microphone:


1. Branchez votre microphone dans la prise microphone du panneau de commande principal de l'appareil.
2. Utilisez le bouton "ECHO" pour contrôler l'écho du microphone.

### AUX:

1. Appuyez sur l'entrée audio de l'appareil sur le panneau principal en haut.
2. Insérez la fiche du câble Aux dans l'entrée Aux, puis connectez-vous à votre appareil.
3. Retirez le câble lorsque vous avez fini d'écouter.

# ZIZO

ZIZOWIRELESS.COM



@ZIZOWIRELESS

## CARACTÉRISTIQUES SUPPLÉMENTAIRES

**Technologie TWS:** Connectez sans fil deux ZIZO AMPLIFY ensemble et lisez les canaux de musique gauche et droit avec ces deux haut-parleurs pour doubler votre sortie audio.

**Résistant à l'eau:** IPX5 anti-éclaboussures, anti-pluie, parfait pour les activités de plein air.

**Compatible avec les appareils intelligents:** Avec Bluetooth A2DP, diffusez de la musique sans fil depuis n'importe quel appareil compatible Bluetooth tel que votre téléphone portable, ordinateur portable, iPhone ou iPad.

**Port AUX:** Connectez-vous à l'audio d'un smartphone, d'une tablette, d'un lecteur multimédia, d'un ordinateur portable, d'un PC ou d'une autre source audio avec une sortie de 3,5 mm.

**Port De Carte Micro SD:** Prend en charge la carte Micro SD et lit les formats MP3 et WAV (FAT32).

**Emplacement pour carte Micro SD:** Prend en charge jusqu'à 32 Go de carte Micro SD USB et lit les formats MP3 et WAV (FAT32).

**Entrée casque:** Interface 3,5 mm

**Protection de charge:** Équipé d'une protection de charge et de décharge pour une expérience musicale sûre.

**Lumières LED:** Illuminez la fête avec ses lumières LED à changement de couleur.

**Poignée intégrée:** Conçue pour une portabilité maximale.

## SPÉCIFICATIONS TECHNIQUES

### SPÉCIFICATIONS

#### Model: SPK-AMPFY

Puissance de sortie : 20 W maximum  
Puissance d'entrée : 5 V CC  
Taille du haut-parleur : 6,5 pouces  
Dimensions : 9,45 x 5,51 x 12,6 pouces  
Réponse en fréquence : 80Hz-20kHz  
Distance de transmission : jusqu'à 35 pieds.  
Capacité de la batterie : 2400 mAh/3,7  
Temps de charge : 5 heures  
Temps de lecture : jusqu'à 2 heures  
Poids : 5,07 livres

#### Garanties importantes:

1. Ne laissez pas l'eau se renverser sur la surface ou dans le produit.
2. Les enfants doivent être surveillés lors de l'utilisation de l'appareil.
3. Si la surface du produit est endommagée ou en cas de dysfonctionnement mécanique ou électrique, n'utilisez pas l'appareil. Contactez le service client ZIZO.
4. Ne secouez pas le produit.
5. Ne placez pas le produit dans l'eau.
6. Ne placez pas le produit à la chaleur directe. Cet appareil doit être placé dans un endroit sec et endroit aéré.
7. Ne placez pas d'objets lourds sur l'appareil.

## INFORMATIONS DE GARANTIE

Chez ZIZO, nous nous engageons à 100% pour votre satisfaction. Nous soutenons nos produits et offrons une garantie fabricant de 1 an contre les défauts de matériaux ou de fabrication de votre nouveau haut-parleur ZIZO.

Si vous trouvez que votre article est défectueux, visitez simplement [zizowireless.com/warranty](https://www.zizowireless.com/warranty) pour soumettre un bref formulaire de demande de service de garantie. La garantie s'applique aux produits achetés auprès des revendeurs agréés ZIZO. L'enregistrement international des produits n'est pas disponible pour le moment. Clients américains uniquement.

## SERVICE CLIENT ZIZO

#### Email

[info@zizowireless.com](mailto:info@zizowireless.com)

#### Téléphone

+1(909) 444-7992 (English)

#### Site Internet

[zizowireless.com/support](https://www.zizowireless.com/support)



© 2022 ZIZO, Tous droits réservés. Le mot-symbole et les logos Bluetooth sont des marques déposées appartenant à Bluetooth SIG, Inc. toute utilisation de ces marques par Balaji Trading Inc. est sous licence. Les autres marques et noms commerciaux appartiennent à leurs propriétaires respectifs.

Images sur l'emballage utilisées à des fins d'illustration. Le produit réel peut varier en raison des améliorations continues.



**FCC Warning**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .