



## Internal photos



The external antenna is permanently connected, any removal will render the antenna inoperable.

