




# User Manual

# GETTING STARTED

1. Power on the tablet, find  and tap it to launch.
2. After launching, simply select your language, tap **Accept** and **Continue**, then tap **Allow** in the following 4 pop-up windows to visit KIDOZ as a **Guest**.



# KIDOZ REGISTRATION

## CREATE PARENT ACCOUNT

Tap  on the top navigation bar, then start to create the parent account with a valid email address following the instructions of KIDOZ. A verification email from KIDOZ stands for the successful registration.



# CREATE KID PROFILE

## Step 1:

Set your kid's gender, name, birthday and choose up to three languages, then tap

**Create Profile**



## Step 2:

Change the profile photo from gallery (My Pictures in KIDOZ or by taking one with the camera). If you have more kids, you can add more kid profiles. Tap


**Start KIDOZ** to enter the main interface.



## MAIN INTERFACE




 show pictures taken by the camera in KIDOZ

 set / cancel the safe environment


 exit from KIDOZ


 download apps from KIDOZ Store


 watch online videos

 play online games

 visit online websites


 take photos, then save to My Pictures in KIDOZ and Photos in tablet

 change the wallpaper of KIDOZ


 switch between the main interface and kid's center

 go to Parental Control center


## DESCRIPTION OF ICONS IN VIDEOS & GAMES & WEBSITES

 favorite videos/games/websites

 view history

 create new channel for videos/websites

 check all the latest videos/games/websites

 allow or hide specific video channels/games/websites by parents

# PARENTAL CONTROL CENTER



## MANAGE CONTENT



\*Tap **Apps** to show or hide one or more apps in KIDOZ;



\*Tap **Video Channels/Online Games/Websites** to allow or hide one or more options;

## MANAGE ACCOUNT



\*Tap **Account** to manage the parent account and kid's account. You can change password of parent account, edit Kid's account, delete Kid's account, etc..




\*Tap **Time Limit** to activate Time Limit Control. You can set the amount of time (e.g. 1.5 hours) and the daily time frame (e.g. 5:00 PM-8:00 PM) for using KIDOZ.



\*Tap **Security** to enable/disable different security options as required.



# SET UP THE SAFE ENVIRONMENT

- in order to ensure the safety of your children, KIDOZ comes with a child lock that prevents your kids from exiting the safe environment.
- In Safe Mode - your child will be safe inside KIDOZ, ad links and app purchases will be blocked as long as the device is not turned off.
- In Extra Safe Mode - KIDOZ will act as the default launcher as long as the app is running. And even if you power off your device, when you turn it back on, your child will still be safe inside KIDOZ.
- Select the safety level you want for your child by tapping the Lock icon  and choosing the relevant setting.
- For Extra Safe Mode, you'll be asked to set KIDOZ as default launcher; you can follow the instructions on screen. This will not affect your device use in normal mode.



# KID'S CENTER

Tap  on the top navigation bar to enter kid's center.

Tap  to change the photo of your kid's profile.

Tap  **Switch Profile** to switch to another kid profile or create another kid profile.

Tap  **Buy Coins** to buy coins with your credit card.

 **My Favorites** Your kid's favorite videos, games and websites.



# ANXONIT

WWW.PROFESSIONAL.COM/DIGITAL/PRINT/20

## Contact Us

For any inquiries, please feel free to contact us, we will respond within 24 hours.

E-mail: [sales@anxonit.com](mailto:sales@anxonit.com)

Tel: +1 909-833-5767

**FCC Warning Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC Radiation Exposure Statement**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.