

ANXONIT®

Instructions

Product performance

Model No.: Cylinder X2/X2 Pro
 Power: 5V-2A(please use only the default power come with the projector in box)
 Working Temperature: 0°C~ +40°C



Accessories List

Following list for reference, please take which you received as final

Items	Accessories	Unit	QTY
1	Adapter	PCS	1
2	Charging cable	PCS	1
3	User Manual	PCS	1
4	Warranty Card	PCS	1

Product View

View for product understanding, product appearance shall prevail



Adjust the focal length

Turn on the projector, slowly turn the focus ring until the projected picture clear. PS: The best projection distance is 0.3m~3m


Turn on / Turn off

Turn on: When projector is off, press and hold power key for 3 seconds to turn on the unit.
Turn off: When projector is on, press and hold the power key on remoter or unit for 3 seconds to turn off the unit.
Factory Reset: setting – system setting- factory reset
Forced shutdown: When projector is on, press and hold the power key for 10 seconds, the unit will be shutdown forced.

Network setup

For the first using, choose "Setting" - "Network Setup" - "WIFI", choose the network you want to connect.

Remoter



Keystroke


- Power** – Press and hold for 3 seconds to turn off the unit
- Flying Mouse** – Switch the selection cursor
- Setting** – System function setting
- MUTE** – Turn on / off the volume
- Arrow Keys (R / L)** – move the cursor as you need, hold the arrow keys to make fast forward or rewind the video when playing.
- OK** – Confirm the current choice
- HOME** – Back to the main interface
- Return** – Back to the last page / interface
- Menu** – Press and hold to view the operation menu
- Volume** – Adjust the volume
- Page up / down** – Go to the last / next page

Charging


Please use only the default adapter and cable for the unit charging. When the unit is off, the top illustration light will be twinkling while charging, and it will cost around 4 hours till full charged. And the timing will be longer when charging while projector under working.

More operation help please go to UserGuide, thank you!

(1) Click on "UserGuide" app



(2) Enter app and browse electronic instructions



Write by the user User information

(Customer Name) _____
 (Telephone No.) _____
 (Address) _____

 (Model No.) _____
 (Remark) _____

Warranty Card

(1) Purchase Date: _____

 (2) Receipt Date: _____

 (3) Serial Number on Projector Bottom : _____

 (4) What help do you need ? _____

 (5) Manufacturer Action: _____

Thank you!

@2019-2021 Anxonit Inc all right reserved.the Anxonit® logo and associated characters,trademarks and design elements are owned and licensed by Anxonit company. www.anxonit.com

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.