


FCC Statement





Changes or modifications not expressly approved by the party responsible for compliance could void the user's warranty.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to communications by radio and television. With certain adjustments, this equipment may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Move the equipment away from the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The equipment should be kept at least 20 cm from the receiver.

This device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation.



1. Light stand introduction

2. Light stand Adjustment

- When the light stand locking knob is released, gently adjust the leg to the needed angle, and then lock the light stand locking knob.
- Turn the locking knob counter-clockwise, pull upwards and reverse the leg 180° to fold the light stand.
- Center Column Adjustment
 - Release the center column locking knob counter-clockwise to release and pull the center column to the desired height.
 - Lock the leg according to the illustration, pull the center column to the needed height, then lock it.

Warnings:

- Do not exceed the light stand maximum load capacity.
- Ensure the light stand is locked.
- Do not operate this light stand when the diffuser is attached. It is not recommended to operate in salivater.
- Do not put this light stand in sunlight or lean it against the glass of car for a long time.
- Do not leave this light stand unattended in public places. It should be removed when use it in independent place.
- Remove the camera from the ballhead during setup or transport.
- It is not necessary to equip lubricant. Please use standard lubricant or grease when necessary.

After-sale mailbox: huanggang@aqznice.com