图纸发布类别: 正式归档图纸

1 Can I share with family and friends? Yes, you can share your cameras with family and friends who will have access to view the camera and control your bulbs, plugs, and other devices. In the app, press the Profile button and click on the "Home Management" button, and you will be able to give or revoke sharing permissions. In order to share, the other user should already have downloaded the app and registered a new account. 2 What's the Wireless Range?	 4 My device can't be connected to network v Make sure the device is under the config quickly) Make sure the Wi-Fi is available and not too Make sure the Wi-Fi password you input is contacted by the sure the sur	
2 What's the Wireless Range?		
The range of your home Wi-Fi is heavily dependent on your home router and the conditions of the room. Check with your router specifications for exact range data.	 5 My device shows offline in my App Make sure the device is powered on Make sure the network is stable and the modified. If not, add device again. If the network is normal, but it's still offline. Or a stable and the network is normal, but it's still offline. 	
3 How many cameras can I control?	connections. You can restart your router to ch	
TuyaSmart app can control an unlimited amount of devices in an unlimited amount of locations. Your router may have a limit of how many devices can be connected to one router.	*You can find much more useful information in the	
3 Plug in	4 Add device	
 How do I reset my device? Press the Reset Button for several seconds until camera starts to beep. Optional: Insert Micro SD card 	 Open TuyaSmart APP, click "+" on the top right corner of the page "HOME", ther select "Smart Camera". Make sure the indicator light on the device is flashing red quickly, then press "Next Step". 	
	 Enter your "Wi-Fi network and password" click "OK". 	
-	 3 How many cameras can I control? TuyaSmart app can control an unlimited amount of devices in an unlimited amount of locations. Your router may have a limit of how many devices can be connected to one router. 3 Plug in How do I reset my device? • Press the Reset Button for several seconds until camera starts to beep. 	

105g	客户			物料名称		设计	
		产品名称					
					 		
/		型号	物料编号	,	时间		

成品尺寸	80x80mm
展开图尺寸:	80x480mm
公差:	±1mm

单位:mm

