


# JYX

## USER MANUAL

MODEL:JYX-66BT



160.00 mm

2020-11-03



深圳市佳誉祥音

## Catalogue

Introduction.....	1
Product functions.....	2-4
Remote control.....	5-6
Technical Indicators.....	7
Packing list.....	7
FQA.....	8

Dear users:


Thanks for your purchasing. Please read the directions carefully before using and follow the correct instructions.

Matters needing attention:

To ensure safety, please read carefully and follow the following safety instructions:

1. The equipment is up to The China Compulsory Certification.
2. The equipment should be used in a dry environment.
3. Do not place a fire source near the equipment.
4. Do not use near water source to avoid corrosion of products and accessories.
5. Do not open or disassemble or repair the battery module by yourself. There will be a risk of explosion if the battery is not replaced properly. Do not put the battery into water, fire or any overheated environment.
6. When taking an airplane, please follow the relevant regulations and regulations of the airline company to turn off this product before the airplane takes off to avoid any hidden danger.
7. The charging cable cannot be squeezed, pulled, bent, knotted, or suspended from heavy objects in order to avoid damage to the insulation layer of it and cause electric shock.

## Guide to control and setting



2

## Operation Guide

- 1.Master: Main volume control knob
- 2.Number Key: Press to switch to the program with the corresponding serial number
- 3.Previous: Short press to switch to the last program; long press to fast backward.
- 4.Reverb: Adjust reverb.
- 5.Play/Pause: Short press to play/pause; In radio mode,long press for automatic radio station search; In bluetooth mode,long press for TWS(only valid for the same model)
- 6.Next: Short press to switch to the next program; long press to fast forward.
- 7.Bass: Adjust bass sound.
- 8.REC: Long press to record audio,during this process, short press to stop recording.When there is a recording file in the storage device,short press is to play the recording file.(The recording function is only available when a storage device is plugged in)
- 9.Mode: short press to switch between bluetooth,flash card,TF card and FM radio.When bluetooth has already connected,long press to disconnect.
- 10.Treble: Adjust treble sound
- 11.MIC VOL: Adjust microphone volume
- 12.MIC Priority:When use microphone while playing audio, press this button to reduce the sound of the background audio
- 13.Dynamic Microphone jack(6.35mm)
- 14.Condenser Microphone jack(3.55mm)
- 15.AUX IN Jack
- 16.TF Card Port
- 17.USB Port
- 18.Charging Indicator Light
- 19.5V Charging Port
- 20.Power
- 21.Sound Receiver Hole

3

#### Bluetooth Connection

1. Turn on bluetooth on your mobile device.
2. Press "Mode" key and switch the speaker to BT mode.
3. Select "JYX-66BT" from available devices. (If JYX-66BT is unavailable, please switch back to Bluetooth mode and try again )

#### AUX- IN

Transmit audio without Bluetooth by plug 3.5mm audio cable into AUX IN jack, the speaker will play the audio from input device automatically.

#### USB and TF Input

When insert USB or TF card into speaker, the speaker will play the audio from USB/TF card automatically.

#### FM Radio

1. Pull out the antenna on the top of speaker.
2. Press "Mode" key to switch to radio station.
3. Long press "Play/Pause" key to search and save more available stations automatically.
4. The station searching completed when it no longer switch automatically.
5. Press "Next" or "Previous" to select your own station.

#### REC

1. Plug in a TF card or flash card
2. Long press "REC" to start recording, short press to end recording.
3. Short press "REC" again to play the recording audio.

#### TWS Function

To use this feature, two JYX-66BT systems are required.

1. Turn on the two JYX-66BT and turn them both into Bluetooth mode. Two machines will flash "BLUE" on screen.
2. Long press the "PLAY/PAUSE" button of either of the two machines (Only need to press one button), the other machine will make a prompt tone and stop flashing. TWS function will be activated by then.
3. Connect your device with the speaker and play music.
4. Long press "PLAY/PAUSE" button again to inactivate TWS function.

If you're still wondering about these steps, please contact customer service team for a video tutorial: [service-us@szjyx.com.cn](mailto:service-us@szjyx.com.cn)

#### Remote control



#### Directions of Remote Control

- 1.Silent:press to Silent ON,press again to Silent OFF.
- 2.Mode:Press to switch the system between USB,TF card,Radio station,AUX IN and Bluetooth modes.
- 3.BT:Press to switch to Bluetooth mode in any working state.
- 4.Play/Pause:When in USB/TF card mode,short press to play/pause the program,long press to repeat.When FM works,short press to silent ON,long press is for searching radio stations.
- 5.Next.
- 6.REC
- 7.Digital keys:Press to play the program with the corresponding serial number.
- 8.Repeat:Press for single loop and list loop.
- 9.Vol+
- 10.PREV.
- 11.Vol-
- 12.REC Play:Press to play the recording file.

#### Product Parameters

Model: JYX-65BT

Speaker size: 6.5 inch bass + 2 inch treble

RMS: 15W

Input voltage: 5V

#### Package includes

Speaker system.....	1PC
Charging cable.....	1PC
User manual.....	1PC
Remote control.....	1PC
3.55mm audio cable.....	1PC
Adjustable shoulder strap.....	1PC

## FAQ

Q:The system can not start up.

A:Charging the built-in battery;

Check if the adapter is connected securely.

Q:The system provides no sound.

A:Check if the system is power on.

Adjust the volume.

Q:The Bluetooth connection is not available.

A:Move your device closer to the system.

Check to see if the Bluetooth is engaged.

Q:Unable to connect two system with TWS feature.

A:Make sure the two systems are within one meter of each other.

Q:Reset the system.

A:If the system does not respond to any operations,long press "Power" key for 8 seconds to reset the system.

(Notes:If necessary,contact after-sales team)

## Contact Information

SHENZHEN CITY JIAYUXIANG ACOUSTICS ELECTRONIC CO.,LTD.

JIA YU XIANG(HK)INTERNATIONAL ELECTRONICS CO.,LIMITED

Factor address:NO.7th Building,Houhaixufa Industrial Zone,

Loucun,Gongming town,Guangming District,Shenzhen,China

TEL:+(86)-0755-23410725 FAX:+(86)-0755-27508507

Website:www.szjyx.com.cn E-mail:service-us@szjyx.com.cn

## FCC WARNING

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.