AIHOOR

AIHOOR A2 USER MANUAL

Thank you for purchasing the AIHOOR A2 True Wireless Stereo earbuds. Please read this user manual carefully and keep it for future reference. If you need any assistance, please contact our support team with your product model number and Amazon order number.

In the Box

	Earbuds		USB-C Charging Cable		
	Charging Case		User Manual		
L M	Ear-tips		Quick Start Guide		


-01 -

Specifications

Product Number	AIHOOR A2	
Bluetooth Version	5.2	
Bluetooth Protocol	A2DP / AVRCP/HSP/ HF	
Charging Time	≈2h	
Battery Life	≈30h (with case) ≈5h (earbuds only)	
Earphones Impedance	32Ω	
Maximum Output Power	5mW	
Frequency Range	20Hz-20KHz	
Microphone Sensitivity	-42dB@1KHz	
Battery Capacity	500mAh	
Bluetooth Effective Distance	10m	
Product Weight	35g/4g (each earbud)	
Charging Voltage	DC 5V	
Waterpoof Rating	IPX4	

PRODUCT DETAILS

Please charge the earbuds and the charging case for at least 15 minutes for the first time.



- 03 -

LISTENING COMFORT



Choose the ear-tip with the most comfortable fit and best seal. To change an ear-tip, gently pull it off from the earbud and press on the

Wearing the Earbuds



into the ear and adjust to a comfortable position by rotating them. R is for the right ear, and L for the left.

BATTERY LIFE AND CHARGING


In Bluetooth mode the buds can last for 5 hours of continuous play. Using the charging case, this can be extended to 30 hours.

The light flashes four times when the battery is 0-25% remaining the light flashes three times when the battery is 26%-50% remaining, the light flashes twice when the battery is 51%-75% remaining, the light flashes once when the battery is $76\%\mbox{-}100\%$ remaining.

Charging the earbuds

Place the earbuds in the charging case and they will automatically shut down and begin charging.

Charging the charging case



PLAYBACK CONTROLS

	Left ear	Right ear
Touch Control		
Music Play/Pause	Тар	Тар
Volume + -	long-press volume -	long-press volume +
Next Track	Double-tap	Double-tap
Answer	Тар	Тар
Hang Up	Long-press 2s	Long-press 2s
Decline Call	Long-press 2s	Long-press 2s
Activate Voice Assistant	Triple-tap	Triple-tap

- 06 -

AUTOMATIC CONNECTION

- Starting with the earbuds in the case: 1. Take the left and right earbuds out of the case. They will automatically turn on and connect with each other within 3 seconds. LED light of flashing red and blue for paring
- 3. Turn on the pairing function on the device to be paired with the earbuds.
- 4. From the list of available devices, find and select "AIHOOR A2 from the list of available devices. 5. If the earbuds have connected with your device, the earbuds
- start flashing blue for one second. 6. If a code or PIN code is required for pairing, please enter "0000"

reconnect to the lastpaired device or enter pairing mode if no 2. Forced pairing, 5 tap on either side of the touch button,

1. When you turn on the earbuds, they will automatically

disconnect the current Bluetooth connection, re-enter the pairing mode, the red and blue lights quickly flashes.

- 07 -

3. In pairing mode, the earbuds will automatically turn off after 5 minutes if no devices are paired

-02-

4. Place the earbuds in the charging case then close the charging case, they will automatically shut down and begin charging. 5. If the Bluetooth connection is lost, they will automatically begin

- If one of the earbuds has no sound output, put both earbuds back into the charging case and take them out again
- \bullet The maximum wireless operating range is 10m (33ft). If you exceed this range, the earbuds will disconnect from your paired device. The connection will be re-established if you re-enter the wireless range within 5 minutes. The earbuds will automatically reconnect to the last-paired device. To connect with other devices repeat the previous pairing steps.

SAFETY INSTRUCTIONS

. Do not place the earbuds in extremely high or low ambient temperatures for an extended period of time. Extreme temperatures

- 08 -

2. Use electronic equipment with caution during thunderstorms 3. This product contains small parts which could cause harm if swallowed. Keep out of the reach of children.

4. Using the earbuds for a long time at high volume may affect your hearing. Make sure to use an appropriate level of volume.

BATTERY WARNING

This product contains a lithium battery. Please do not disassemble strike, crush, or place the product into contact with flames. Do not expose to high temperatures or direct sunlight for a prolonged period. If there is any swelling, leakage, odor, or any other abnormality in the battery compartment of the product, cease use immediately. Please dispose of used batteries properly and in accordance with local regulations.

- 09 -

FCC Statement
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which cause harmful interference to radio or television reception, which cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

- help.

 The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition

FCC RF EXPOSURE STATEMENT:

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter

This device complies with FCC radiation exposure limits set forth for

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate

- 10 -

- 11 -

MODE: AZ
AUSOUNDS Intelligence, LLC.
www.aihoor.net | info@aihoor.net
Designed by AUSOUNDS In California USA
FCC ID: 2AZLD-AIHOORA2

