

AHOOOR

AHOOOR A5
USER MANUAL

Thank you for purchasing the AHOOOR A5 True Wireless Stereo earbuds. Please read this user manual carefully and keep it for future reference. If you need any assistance, please contact our support team with your product model number and Amazon order number.

In the Box

	Earbuds		USB-C Charging Cable
	Charging Case		User Manual
	Ear-tips		Quick Start Guide

- 01 -



Specifications

Product Number	AHOOOR A5
Bluetooth Version	5.2
Bluetooth Protocol	A2DP / AVRCP/HSP/ HFP
Charging Time	≈2h
Playtime (varies by volume level and content)	Up to 6 hours (Total 25 hours with the charging case)
Playtime (with ANC mode turned on)	Up to 5 hours (Total 20 hours with the charging case)
Earphones Impedance	32Ω
Maximum Output Power	2.8mW
Frequency Range	20Hz-20KHz
Microphone Sensitivity	-38dB@1KHz
Battery Capacity	520mAh
Bluetooth Effective Distance	10m
Product Weight	42g/4.3g (each earbud)
Charging Voltage	DC 5V
Waterproof Rating	IPX4

- 02 -

PRODUCT DETAILS


Please charge the earbuds in the charging case for at least 15 minutes before first use.



- 03 -


LISTENING COMFORT

Choose the ear-tips that fit your ears best



Choose the ear-tip with the most comfortable fit and best seal. To change an ear-tip, gently pull it off from the earbud and press on the new one.

Wearing the Earbuds



Gently insert the earbuds into the ear and adjust to a comfortable position by rotating them. R is for the right ear, and L for the left.

- 04 -

BATTERY LIFE AND CHARGING

Battery life

6 hours in each earbud in Bluetooth mode, 18+ hours in charging case

Power display


The battery indicator uses 3 colors to indicate the approximate time remaining on the internal battery and the status of the charge process.

RED: 0-30% YELLOW: 31%-70% Green: 71%-100%

Charging the earbuds

Place the earbuds in the charging case and they will automatically shut down and begin charging.

Charging the charging case



- 05 -

PLAYBACK CONTROLS

	Left ear	Right ear
Touch Control		
Music Play/Pause	Tap	Tap
Ambient Sound Control off / Ambient Sound / Noise Canceling	Long-press 2s	Long-press 2s
Next Track		Double-tap
Previous Track	Double-tap	
Answer	Tap	Tap
Hang Up	Long-press 2s	Long-press 2s
Decline Call	Long-press 2s	Long-press 2s
Activate Voice Assistant	Triple-tap	Triple-tap

- 06 -

Model: A5
AUSOUNDS Intelligence, LLC.
www.aihoor.net | info@aihoor.net
Designed by AUSOUNDS In California USA
FCC ID: 2AZLD-ARA5



AUTOMATIC CONNECTION

Pairing:

- Open the charging case, the earbuds will automatically enter pairing mode (red & blue indicator flash alternately).
- Tap on the Bluetooth icon to enable Bluetooth, find and select "AHOOOR A5" from the list of available devices.
- If a code or PIN code is required for pairing, please enter "0000".

Automatic remote connection

- When you open the charging case, the earbuds will automatically reconnect to the last-paired device or enter pairing mode if no paired device is found.
- In pairing mode, the earbuds will automatically turn off after 5 minutes if no devices are paired.
- Place the earbuds in the charging case, they will automatically shut down and start charging.
- If suddenly disconnects is lost, they will automatically begin pairing.

- 07 -

Reset

You might need to reset your earbuds if you experience any connectivity problems or function issues.

- Place the earbuds in the charging case and leave the case open.
- Press and hold the button on the side of the case for 6 seconds until the LED indicators flash red for 4 times. This confirms that the reset is successful.

NOTE:

- If one of the earbuds has no sound output, put both earbuds back into the charging case and take them out again.
- The maximum wireless operating range is 10m (33ft). If you exceed this range, the earbuds will disconnect from your paired device. The connection will be re-established if you re-enter the wireless range within 5 minutes. The earbuds will automatically reconnect to the last-paired device. To connect with other devices, repeat the previous pairing steps.

SAFETY INSTRUCTIONS

- Do not place the earbuds in extremely high or low ambient temperatures for an extended period of time. Extreme temperatures will cause the device to deform.

- 08 -

- Use electronic equipment with caution during thunder storms.
- This product contains small parts which could cause harm if swallowed. Keep out of the reach of children.
- Using the earbuds for a long time at high volume may affect your hearing. Make sure to use an appropriate level of volume.

BATTERY WARNING

This product contains a lithium battery. Please do not disassemble, strike, crush, or place the product into contact with flames. Do not expose to high temperatures or direct sunlight for a prolonged period. If there is any swelling, leakage, odor, or any other abnormality in the battery compartment of the product, cease use immediately. Please dispose of used batteries properly and in accordance with local regulations.

READ ALL INSTRUCTIONS BEFORE USE AND SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

- 09 -

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

This device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

- 10 -

CAUTION!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- 11 -

WARRANTY CARD

NAME:

EMAIL:

DATE OF ORIGINAL PURCHASE:

DEALER

PHONE NUMBER

MODEL

DESCRIPTION OF PROBLEM

- 12 -

A06HT

说明书尺寸：93*93mm

80双铜单色印刷