

0968 WS Monster Truck Instruction Artwork

Revision Date: 13 July 2023




Instruction Manual


Please read instructions before using.
Please keep these instructions as they contain important information.

SETUP:

1. Remove stickers on case, and remove case as illustrated.




2. Hold one end of the remote control and pull upwards. Have an adult remove the screw on the underside of the base and remove the Monster Truck as illustrated.




3. Remove the four Traffic Cones from the bottom of the base as illustrated.




4. Have an adult use a screwdriver to remove the battery cover.




CONTENTS:



5. Insert 2 x "AA" batteries in the correct polarity position, then replace the battery cover.



6. Press any button on the remote control. The Frequency Light will light up to show correct battery installation.




CHARGING:

1. Open the charging cover on the side of the remote control and take out the charging plug.




2. Move the power switch on the remote control to the ON position, insert the charging plug into the charging port on the bottom of the truck, and the charging indicator will light up. Charging is in progress.

Note: The truck can be charged only when the truck's power switch is in the OFF position.





3. The Monster Truck is fully charged when the Charging Indicator turns off.




OPERATING INSTRUCTIONS:

2. Remote Control function:
 - (1) After a button is pressed, the indicator light will light up and the truck will act accordingly.
 - (2) When the Forward/Reverse buttons are pressed, the truck will move forward or backward.
 - (3) When pressing the Forward/Reverse buttons and Left/Right buttons at the same time, the truck will move in that direction.



3. Use the Trim Adjustment on the underside of the truck to adjust the straight-line performance.



Caution:

1. Do not touch the antenna during operation or the remote control range will be affected.
2. Due to the high speed of the car, it cannot decelerate or stop immediately.
3. If the car becomes slow during operation, this may be due to insufficient power. Charge the car as described in the manual.
4. When the car is fully charged, stop charging to avoid overheating the battery.
5. The car cannot be charged when the remote control has insufficient power. When the remote control's indicator light goes dim, replace the old batteries.
6. Pay attention to the charging plug and interface when you charge the car.
7. When not using the car for a long period, make sure the car has more than 50% power and turn off the car. Then remove the batteries from the transmitter.
8. There is a 1.2V (N-MH) rechargeable battery inside the racing car. Charge the car under adult supervision.
9. Open and remove the packaging under adult supervision.
10. Keep this manual for future reference.

Important Battery Information:



- Batteries should be replaced by an adult.
- Do not charge non-rechargeable batteries.
- Supply terminals should not be short-circuited.
- Ensure batteries are inserted with the correct polarity.
- Spent batteries should be removed from the product.
- Rechargeable batteries should be removed from the product and charged under adult supervision.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries, or new and used batteries.
- Do not dispose of batteries in household waste or fire, as batteries may explode. Dispose spent batteries safely at local authorities or approved waste sites.

Keep this packaging as it contains important information.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or experienced radio/TV technician for help.